

Motion Control

Series MCBL 300x CF  
Series MCDC 300x CF  
Series 3564...B CC  
Series 32xx...BX4 CC  
Series 22xx...BX4 CCD

# Communication/ Function Manual

EN

**CANopen**  
with **FAULHABER CAN**

## Imprint

---

Version:  
4th edition, 27.08.2014

Copyright  
by Dr. Fritz Faulhaber GmbH & Co. KG  
Daimlerstr. 23/25 · 71101 Schönaich

All rights reserved, including those to the translation.  
No part of this description may be duplicated, reproduced, stored in an information system or processed or transferred in any other form without prior express written permission of Dr. Fritz Faulhaber GmbH & Co. KG.

This technical manual has been prepared with care.  
Dr. Fritz Faulhaber GmbH & Co. KG cannot accept any liability for any errors in this technical manual or for the consequences of such errors. Equally, no liability can be accepted for direct or consequential damages resulting from improper use of the equipment.

The relevant regulations regarding safety engineering and interference suppression as well as the requirements specified in this technical manual are to be noted and followed when using the software.

Subject to change without notice.

The respective current version of this technical manual is available on FAULHABER's internet site:  
[www.faulhaber.com](http://www.faulhaber.com)

## Overview

### Overview of the FAULHABER Motion Control Drives documents

| Document                                    | Contents  |
|---|---|
| Technical Manual                            | Device installation, safety, specification  |
| Communication and function manual (CANopen) | Initial start-up, function overview, protocol description and parameter description.        |
| Motion Manager instruction manual           | Operation of the "FAULHABER Motion Manager" PC software for configuration and commissioning |
| Product data sheets                         | Technical limit and operating data  |

### Guide to the Document

#### Notes on the initial start-up of a FAULHABER Motion Control system at the PC in the default configuration

Quick Start Page 9

#### Overview of the possible operating modes in Faulhaber mode

Operation in FAULHABER mode Page 17

#### Specification of the CANopen communication protocol

CANopen protocol description Page 59

Extended CAN functions Page 72

#### Overview of the supported drive profiles according to CiA 402

Functional description of the CANopen CiA 402 Page 74

#### Detailed description of the parameters for the implemented Function blocks within the drive

Commissioning Page 98

#### Description of all the drive's parameters and commands, broken down into functional areas

Parameter description Page 122

# Table of Contents

---

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>Important Information</b>                                      | <b>7</b>  |
| 1.1      | Symbols used in this manual                                       | 7         |
| 1.2      | Additional information  | 8         |
| <b>2</b> | <b>Quick Start</b>  | <b>9</b>  |
| 2.1      | Set node number and baud rate                                     | 9         |
| 2.2      | Operation using FAULHABER Motion Manager                          | 10        |
| 2.2.1    | Activate CANopen nodes  | 10        |
| 2.2.2    | Configuring the drives  | 10        |
| 2.2.3    | Operation using FAULHABER commands                                | 11        |
| 2.2.4    | Operation in one of the CANopen CiA 402 drive profiles            | 11        |
| 2.3      | Operation using own host application                              | 15        |
| 2.3.1    | Activate CANopen nodes  | 15        |
| 2.3.2    | Configuring the drives  | 15        |
| 2.3.3    | Operation using FAULHABER commands                                | 15        |
| 2.3.4    | Operation in one of the CANopen CiA 402 drive profiles            | 16        |
| <b>3</b> | <b>Operation in FAULHABER mode</b>                                | <b>17</b> |
| 3.1      | Position control  | 19        |
| 3.1.1    | Set-point presetting via CAN/PDO2                                 | 19        |
| 3.1.2    | Analog positioning mode (APCMOD)                                  | 22        |
| 3.1.3    | External encoder as actual position value (ENCMOD) - not for MCDC | 24        |
| 3.2      | Velocity control  | 27        |
| 3.2.1    | Target velocity via CAN/PDO2                                      | 28        |
| 3.2.2    | Velocity presetting via an analog voltage or a PWM signal         | 30        |
| 3.2.3    | External encoder as actual velocity value (ENCMOD) - not for MCDC | 32        |
| 3.3      | Homing and limit switches   | 35        |
| 3.3.1    | Limit switch connections and switching level                      | 36        |
| 3.3.2    | Motion control commands   | 37        |
| 3.3.3    | Configuration of homing and limit switches                        | 38        |
| 3.4      | Extended operating modes  | 40        |
| 3.4.1    | Stepper motor mode  | 40        |
| 3.4.2    | Gearing mode (electronic gear)                                    | 42        |
| 3.4.3    | Voltage regulator mode  | 44        |
| 3.4.4    | Current control with analog current presetting                    | 45        |
| 3.4.5    | IxR control for MCDC  | 47        |
| 3.5      | Special fault output functions                                    | 48        |

## Table of Contents

---

|          |  |           |
|----------|--|-----------|
| 3.6      | Technical information                                      | 50        |
| 3.6.1    | Ramp generator   | 50        |
| 3.6.2    | Sinus commutation  | 54        |
| 3.6.3    | Current controller and I <sup>2</sup> t current limitation | 54        |
| 3.6.4    | Overtemperature protection                                 | 56        |
| 3.6.5    | Under-voltage monitoring                                   | 56        |
| 3.6.6    | Overvoltage regulation                                     | 56        |
| 3.6.7    | Adjustment of the controller parameters                    | 56        |
| <b>4</b> | <b>CANopen protocol description</b>                        | <b>59</b> |
| 4.1      | Introduction   | 59        |
| 4.2      | PDOs (process data objects)                                | 61        |
| 4.3      | SDO (service data object)                                  | 63        |
| 4.4      | Emergency Object (error message)                           | 65        |
| 4.5      | SYNC object  | 66        |
| 4.6      | NMT (network management)                                   | 67        |
| 4.7      | Entries in the object dictionary                           | 70        |
| <b>5</b> | <b>Extended CAN functions</b>                              | <b>72</b> |
| 5.1      | The FAULHABER channel                                      | 72        |
| 5.2      | Trace  | 72        |
| <b>6</b> | <b>Functional description of the CANopen CiA 402</b>       | <b>74</b> |
| 6.1      | Device Control   | 75        |
| 6.1.1    | State machine of the drive                                 | 75        |
| 6.1.2    | Selection of the operating mode                            | 79        |
| 6.2      | Factor Group   | 80        |
| 6.3      | Profile Position Mode and Position Control Function        | 82        |
| 6.4      | Homing Mode  | 87        |
| 6.5      | Profile Velocity Mode                                      | 91        |
| 6.6      | Drive parameters/Common entries                            | 94        |
| 6.7      | Inputs/Outputs   | 95        |
| 6.8      | Error handling   | 97        |

## Table of Contents

---

|          |   |            |
|----------|---|------------|
| <b>7</b> | <b>Commissioning</b>                                  | <b>98</b>  |
| 7.1      | Node number and baud rate                             | 98         |
| 7.2      | Basic settings  | 100        |
| 7.3      | Configuration using the Motion Manager                | 101        |
| 7.3.1    | Connection setting                                    | 102        |
| 7.3.2    | Motor selection                                       | 103        |
| 7.3.3    | Drive configuration                                   | 103        |
| 7.3.4    | Selection of the operating mode                       | 104        |
| 7.4      | Configuration in FAULHABER mode                       | 105        |
| 7.4.1    | Basic settings  | 105        |
| 7.4.2    | Drive parameters                                      | 108        |
| 7.4.3    | Controller settings                                   | 109        |
| 7.4.4    | I/O connection and use                                | 111        |
| 7.5      | Configuration in a drive profile according to CiA 402 | 113        |
| 7.5.1    | Basic settings  | 113        |
| 7.5.2    | Drive parameters                                      | 115        |
| 7.5.3    | Controller setting                                    | 116        |
| 7.5.4    | I/O connection and use                                | 118        |
| 7.6      | Data set management                                   | 120        |
| 7.7      | Status display  | 121        |
| 7.7.1    | Trace function  | 121        |
| <b>8</b> | <b>Parameter description</b>                          | <b>122</b> |
| 8.1      | Communication objects according to CiA 301            | 122        |
| 8.2      | Manufacturer-specific objects                         | 128        |
| 8.3      | Drive profile objects according to CiA 402            | 130        |
| 8.4      | FAULHABER commands                                    | 136        |
| 8.4.1    | Basic setting commands                                | 137        |
| 8.4.2    | Query commands for basic settings                     | 141        |
| 8.4.3    | Miscellaneous commands                                | 143        |
| 8.4.4    | Motion control commands                               | 144        |
| 8.4.5    | General query commands                                | 145        |
| 8.4.6    | Command overview                                      | 146        |

# 1 Important Information

---

## 1.1 Symbols used in this manual

### **WARNING!**



### **Warning!**

*This pictogram with the wording "Warning!" indicates an imminent danger which can result in physical injuries.*

- ▶ *This arrow points out the appropriate action to take to prevent the imminent danger.*

### **CAUTION!**



### **Caution!**

*This pictogram with the wording "Caution!" indicates an imminent danger which can result in slight physical injuries or material damage.*

- ▶ *This arrow points out the appropriate precautions.*

### **REGULATION!**



### **Regulations, guidelines and directives**

*This pictogram with the wording "Regulation" indicates a statutory regulation, guideline or directive which must be observed in the respective context of the text.*

### **NOTE**



### **Note**

*This "Note" pictogram provides tips and recommendations for use and handling of the component.*

# 1 Important Information

---

## 1.2 Additional information

### **WARNING!**



#### ***Risk of injuries***

*Failure to comply with the safety instructions during installation and operation can result in irreparable damage to the device and a risk of injuries to the operating personnel.*

- ▶ *Please read through the whole of your drive's technical manual before installing the drive.*
- ▶ *Keep this communication and function manual in a safe place for subsequent use.*

### **NOTE**



*Always use the current version of the FAULHABER Motion Manager.*

*The respective current version is available to download from [www.faulhaber.com/Motion Manager](http://www.faulhaber.com/Motion_Manager).*

### **NOTE**



*The information given in this instruction manual refers to the standard version of the drives.*

*Please refer to any additional information sheet provided in the event of differences in information due to a customer-specific motor modification.*

### **NOTE**



*Motion Controllers with a CANopen interface are designed as slaves in a CANopen environment and always require a connection with a CANopen Master to operate.*



## 2 Quick Start

To facilitate introduction, this chapter highlights the initial steps for commissioning and operation of FAULHABER Motion Controllers with CANopen interface. However, the detailed documentation must always be read and taken into account, particularly [Chapter 7.2 “Basic settings”](#)!

### 2.1 Set node number and baud rate

The standard units are delivered without valid node address (Node ID = 0xFF) and with automatic baud rate detection set.

In order to set the baud rate and node address, the unit must first be connected via CAN to an appropriate configuration tool, which supports the LSS protocol according to CiA DSP305.

#### **NOTE**



*FAULHABER Motion Manager installed on a PC with supported CAN interface can also be used for this. The LSS compatible configuration tool can be used to set the node address and baud rate, either in Global mode, if only one drive is connected, or in Selective mode via the serial number, if a drive is to be configured in the network (see [Chapter 7.1 “Node number and baud rate”](#)).*

If the FAULHABER Motion Manager is to be used as the configuration tool, proceed as follows:

The following steps are necessary for commissioning using the default configuration:

1. Connect the drive unit to a voltage source (24V). For details of connection cable assignment and the operating voltage range of the drive, see Chapter 3 “Installation” in the technical manual.
2. Connect drive unit to the CAN interface of the PC and switch on or connect PC to the CAN network.
3. Start FAULHABER Motion Manager.
4. Activate CAN interface as communication interface and configure using the menu item “Terminal – Connections...” or the Connection Wizard.
5. Select menu item “CAN - LSS (DSP305)...”.
6. Select Configuration mode:
  - a. Globally configure individual drive (LSS Switch Mode Global) if only one LSS node is connected and you do not want to enter any further data.
  - b. Selectively configure specified nodes (LSS Switch Mode Selective) if a node is to be configured in the network. If the node has not yet been found in the Node Explorer, enter the serial number of the drive node to be configured here, otherwise the data fields are already correctly preset.
7. In the next dialog, select the required transfer rate or “Auto” and enter the required node number.
8. Press “Send” button.
9. The settings are transferred and are permanently stored in the controller. The Motion Manager then calls up the Scan function again and the node should now be displayed with the correct node number in the Node Explorer. After switching off and on again, the drive will operate with the set configuration.

## 2 Quick Start

---

### 2.2 Operation using FAULHABER Motion Manager

The FAULHABER Motion Manager provides easy access to the CANopen state machine using menu entries, which can be opened either with the Node Explorer's context menu (right-click) or with the "CAN" menu. The required node must have been activated beforehand by double clicking in the Node Explorer. The current statuses are always displayed in the status line at the bottom edge of the Motion Manager window.

Further information on the state machine of a CANopen node is given in [Chapter 4 "CANopen protocol description"](#).

#### **NOTE**



*The FAULHABER commands described below can be entered directly in the command input line or selected from the Commands menu. After sending the command, a command interpreter is activated which converts the command into a corresponding CAN message frame on PDO2.*

#### 2.2.1 Activate CANopen nodes

In order to drive a motor using the Motion Manager, follow the procedure below (assuming a valid node number and matching baud rate are set):

##### 1. Start network nodes.

Select the "CANopen Network Management (NMT) – Start Remote Node" entry in the Node Explorer's context menu or in the "CAN" menu.

The state of the node is then "Operational", FAULHABER commands are now available!

##### 2. Configure drive functions:

A user-friendly dialog that enables the desired settings to be made is available under the menu item "Configuration – Drive functions...".

#### 2.2.2 Configuring the drives

#### **CAUTION!**



##### **Check basic settings**

*Incorrect values in the Motion Controller's settings can result in damage to the controller and/or drive.*

Motion Control systems with electronics built-onto the motor are already preset in the factory. Motion controllers with an externally connected motor must be equipped with current limitation values suitable for the motor and suitable controller parameters before being started up. The Motor Wizard is available in Motion Manager for selection of the motor and basic parameters suitable for the motor.

Other settings, e.g. for the function of the fault output, can be made under the "Configuration – Drive functions" menu item, where a convenient dialog is provided (see [Chapter 7.3 "Configuration using the Motion Manager"](#)). The configuration dialog is also available for direct access in the Wizard bar of the Motion Manager (Configuration Wizard).

Switch to the required mode (Modes of Operation/OPMOD 1, 3, 6 or –1), depending on whether you want to operate the drive using the standard CANopen objects or the FAULHABER commands.

## 2 Quick Start

### 2.2 Operation using FAULHABER Motion Manager

#### 2.2.3 Operation using FAULHABER commands

##### 3. Activate drive:

“EN” command.

Input in command input field and press “Send” button or select the “Enable Drive (EN)” button or the relevant entry from the “Commands – Motion Control” menu.

##### 4. Operate drive (examples):

- Operate drive with 100 rpm velocity control:

“V100” command.

Enter in command input field and press “Send” button or

select from “Commands – Motion control – Initiate Velocity Mode (V)” menu, enter value 100 in dialogue box, press OK and “Send” button.

- Stop drive:

“V0” command.


- Move motor relatively by 10 000 increments:

“LR10000” command to load the relative target position, “M” command to move to loaded target position.

#### 2.2.4 Operation in one of the CANopen CiA 402 drive profiles

##### 3. Activate drive using the CiA 402 state machine:

A CiA 402 drive must be activated according to a fixed sequence of steps. The necessary commands are directly available in the context menu of the drive node:



- Shutdown

Select “Device Control (DSP402) – Shutdown” entry using the context menu in Node Explorer or using the “CAN” menu.

- Switch On

Select the “Device Control (DSP402) – Switch On” entry using the context menu in Node Explorer or using the “CAN” menu.

## 2 Quick Start

---

### 2.2 Operation using FAULHABER Motion Manager

- Enable Operation

Select the "Device Control (DSP402) - Enable Operation" entry using the context menu in Node Explorer or using the "CAN" menu.

Alternatively, you can also simply press the green "Switch on output stage" button or F5, in order to carry out these steps all at once.

#### 4. Drive motor (examples):

Drive motor with 100 rpm velocity control:

Set Profile Velocity mode:


- Select the "Motion Control (DSP402) - modes\_of\_operation (6060h)" entry in the node explorer's context menu or in the "CAN" menu.
- Enter value 3 for the "profile velocity mode" in the dialogue box → the necessary command is entered directly in the command field of the Motion Manager.
- Press "Send" button next to the command field.

## 2 Quick Start

### 2.2 Operation using FAULHABER Motion Manager

Set Target Velocity to value 100 (Object 0x60FF):

- Select the “Motion Control (DS402) - target\_velocity (60FFh)” entry using the context menu of the Node Explorer or using the “CAN” menu.
- Enter value 100 for the target velocity in the dialogue box → the necessary command is entered directly in the command field of the Motion Manager.
- Press “Send” button next to the command field.



Stop motor:

- Set Target Velocity to value 0 (Object 0x60FF) or
- Select “Disable Operation” from the toolbar.


## 2 Quick Start

### 2.2 Operation using FAULHABER Motion Manager

Move motor relatively by 10 000 increments:

Set Profile Position mode:

- Select the “Motion Control (DSP402) - modes\_of\_operation (6060h)” entry in the node explorer’s context menu or in the “CAN” menu.
- Enter value 1 for the “Profile Position Mode” in the dialogue box → the necessary command is entered directly in the command field of the Motion Manager.
- Press “Send” button next to the command field.



Set Target Position to value 10 000:

- Select the “Motion Control (DSP402) - target\_position (607Ah)” entry in the node explorer’s context menu or in the “CAN” menu.
- Enter value 10 000 for the target position in the dialogue box → the necessary command is entered directly in the command field of the Motion Manager.
- Press “Send” button next to the command field.

Move to target position: Set “New set-point” and “rel” in controlword.

- Select the “Motion Control (DSP402) - new\_setpoint\_rel” entry in the node explorer’s context menu or in the “CAN” menu.

## 2 Quick Start

### 2.3 Operation using own host application

#### 2.3.1 Activate CANopen nodes

The broadcast command “Start Remote Node” with CAN ID 0 is used to start either an individual node or the whole network and to set it to “Operational” status:

| 11 bit identifier | 2 bytes user data |    |
|-------------------|-------------------|----|
| ID 0x000          | 01                | 00 |

The first data byte contains the start command “Start Remote Node”, the second data byte contains the node address or 0 for the whole network.

All functions can be proceeded after the node has been started. The drive can now be activated and operated using the Device Control functions according to CiA DSP402 or using the FAULHABER commands on PDO2.

The identifiers of the individual objects are allocated according to the Predefined Connection Set and depend on the node number (see [Chapter 4.6 “NMT \(network management\)”](#)). Here are the most important objects:

| Command | CAN ID          | Description                             |
|---------|-----------------|---|
| TxPDO1  | 0x180 + Node ID | Receive the drive's statusword          |
| RxPDO1  | 0x200 + Node ID | Transfer controlword to the drives      |
| TxPDO2  | 0x280 + Node ID | Receive FAULHABER data from the drive   |
| RxPDO2  | 0x300 + Node ID | Transfer FAULHABER command to the drive |
| TxSDO1  | 0x580 + Node ID | Read entry of the object dictionary     |
| RxSDO1  | 0x600 + Node ID | Write entry of the object dictionary    |

In delivery status, after they are switched on, the drives are in operating mode Modes of operation = 1 (Profile Position Mode according to CiA 402). In this operating mode the drive is controlled using the Device Control state machine, which is operating using the controlword (Object 0x6040 or RxPDO1) and is queried using the statusword (Object 0x6041 or TxPDO1).

#### 2.3.2 Configuring the drives

The drive can be configured both by means of SDO transfer using the objects of the object dictionary, and using PDO2 with the commands of the FAULHABER channel.

#### NOTE



*Not all the configuration options are accessible using the object dictionary. Advanced operating modes are only available via the FAULHABER channel (see [Chapter 8 “Parameter description”](#)).*

*Use of the FAULHABER Motion Manager is recommended for the basic settings (see [Chapter 7.2 “Basic settings”](#)).*

#### 2.3.3 Operation using FAULHABER commands

All features of the drive can be operated even without in-depth CANopen knowledge, such as Device Control, SDO protocol and object dictionary. The FAULHABER channel on PDO2 provides an easy means of executing all supported commands.

##### RxPDO2: FAULHABER command

| 11 bit identifier      | 5 bytes user data |     |     |     |     |
|------------------------|-------------------|-----|-----|-----|-----|
| 0x300 (768d) + Node ID | Command           | LLB | LHB | HLB | HHB |

It is necessary to switch to operating mode Modes of operation = -1 first for drive control using the FAULHABER channel:

## 2 Quick Start

### 2.3 Operation using own host application

#### Example:

- Start node 3 using the CANopen Network Management (NMT):  
ID 000: 01 03 (Start Remote Node 3)
- Switch to FAULHABER mode using RxPDO2:  
ID 303: FD FF FF FF FF (OPMOD-1)
- Switch On using FAULHABER command on RxPDO2:  
ID 303: 0F 00 00 00 00 (EN)  
Start drive with 500 rpm using FAULHABER command on RxPDO2:  
ID 303: 93 F4 01 00 00 (V500)

#### NOTE



All available commands are listed in [Chapter 8.4 "FAULHABER commands"](#).

#### 2.3.4 Operation in one of the CANopen CiA 402 drive profiles

A CiA 402 drive must be activated according to a fixed sequence of steps (see [Chapter 6.1 "Device Control"](#)). Write access to the controlword is possible using the object dictionary at address 0x6040 or using the RxPDO1: .

##### 1. Shutdown:

Controlword = 0x00 06

##### 2. Switch on:

Controlword = 0x00 07

The drive is then in "Switched On" status. Operation must then be released to enable drive commands to be executed.

##### 3. Enable Operation:

Controlword = 0x00 0F

The drive is then in "Operation Enabled" state, in which it can be operated using the relevant objects of the set operating mode (see [Chapter 6.1 "Device Control"](#) and [Chapter 6.2 "Factor Group"](#)).

##### 4. Drive motor (examples):

###### Drive motor with 500 rpm velocity control:

Modes of operation (object 0x6060): Set 3 (profile velocity mode) by SDO access.

Target velocity (object 0x60FF): 500

###### Stop motor:

- Set Target Velocity to value 0 (Object 0x60FF) or
- Controlword = 0x00 07 (Disable Operation).

###### Move motor relatively by 10 000 increments:

Modes of Operation (Object 0x6060): Set 1 (Profile Position Mode) by means of SDO access.

Target Position (Object 0x607A): 10 000

Controlword = 0x00 7F (New set-point, Change set immediately, rel)



## 3 Operation in FAULHABER mode

### Guide

|                                |         |
|--------------------------------|---------|
| Position control               | Page 19 |
| Velocity control               | Page 27 |
| Homing and limit switches      | Page 35 |
| Extended operating modes       | Page 40 |
| Special fault output functions | Page 48 |
| Technical information          | Page 50 |

The Motion Controllers can be configured for different operating modes. As a default, the drive unit is delivered as a servo motor in "Profile Position Mode" according to CiA DSP402.

It is necessary to set Modes of operation or OPMODE to -1 for operation control using the FAULHABER channel.

The drive can be reconfigured by means of the corresponding FAULHABER commands. If the settings are to be permanently stored, the SAVE command must be executed following configuration; this saves the current settings in the Flash data memory, from where they are reloaded when the unit is next switched on. Alternatively, the EEPsAV command can also be run. Both commands are identical, therefore SAVE only is used in the following.

#### NOTE



*Operation of the drive in one of the operating modes listed here requires that the device is in NMT "Operational" state and that power stage is activated ("Switched On" or "EN" command). All commands and objects listed below are summarised and explained again in [Chapter 8.4 "FAULHABER commands"](#). The FAULHABER commands transmitted as CAN message frames on PDO2 are given for each operating mode.*

The FAULHABER Motion Manager enables simple setting of the configuration parameters and operating modes via corresponding dialogue windows. The specified commands can be entered in plain text or selected from the Commands menu. CANopen state machines can be conveniently operated by means of menu selection. The current states are automatically displayed in the status line.

The command tables given in this chapter contain the syntax for direct entry in the Motion Manager. The complete command telegrams are described in [Chapter 8 "Parameter description"](#).

#### NOTE



*Please note that FAULHABER commands can only be received in "Operational" state (Motion Manager "CAN" menu – "Network Management (NMT)" – "Start Remote Node").*

### 3 Operation in FAULHABER mode

#### Overview of the operating modes in FAULHABER mode and the FAULHABER commands for changing the operating mode

| Command   | Argument | Function                     | Description   |
|-----------|----------|------------------------------|---|
| SOR       | 0 – 4    | Source for Velocity          | Source for velocity presetting<br>0: CAN interface (default)<br>1: Voltage at analog input<br>2: PWM signal at analog input<br>3: Current target value via analog input<br>4: Current target value via analog input with presetting of the direction of rotation via input polarity |
| CONTMOD   | -        | Continuous Mode              | Switch back to normal mode from an enhanced mode  |
| STEPMOD   | -        | Stepper Motor Mode           | Change to stepper motor mode  |
| APCMOD    | -        | Analog Position Control Mode | Change to position control via analog voltage   |
| ENCMOD    | -        | Encoder Mode                 | Change to encoder mode An external encoder serves as position detector (the current position value is set to 0)   |
| HALLSPEED | -        | Hall sensor as speed sensor  | Speed via Hall sensors in encoder mode  |
| ENCSPPEED | -        | Encoder as speed sensor      | Speed via encoder signals in encoder mode   |
| GEARMOD   | -        | Gearing Mode                 | Change to gearing mode  |
| VOLTMOD   | -        | Set Voltage Mode             | Activate Voltage Regulator Mode   |

## 3 Operation in FAULHABER mode

### 3.1 Position control

#### Guide

##### Positioning mode with set value presetting via CAN

Set-point presetting via CAN/PDO2 Page 19

##### Positioning mode with set value presetting via the analog input


Analog positioning mode (APCMOD) Page 22

##### Positioning mode with external encoder as actual value

External encoder as actual position value (ENCMOD) - not for MCDC Page 24

#### 3.1.1 Set-point presetting via CAN/PDO2

##### Controller structure for set-point presetting via CAN/PDO2



In this operating mode, target positions can be preset using the FAULHABER commands via PDO2:

##### Basic settings

CONTMOD and SOR0 operating mode.

The positioning range limits can be set via the command LL and activated via APL.

The proportional amplification PP and a differential term PD can be set for the position controller.

## 3 Operation in FAULHABER mode

### 3.1 Position control

| Command | Argument | Function                            | Description   |
|---------|----------|-------------------------------------|---|
| PP      | Value    | Load Position Proportional Term     | Load position controller amplification.<br><b>Value: 1 ... 255</b>  |
| PD      | Value    | Load Position Differential Term     | Load position controller D-term.<br><b>Value: 1 ... 255</b>   |
| LL      | Value    | Load Position Range Limits          | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower.<br>The range limits are only active if APL1 is.<br><b>Value: <math>-1.8 \cdot 10^9</math> ... <math>+1.8 \cdot 10^9</math></b> |
| APL     | 0-1      | Activate/Deactivate Position Limits | Activate range limits (LL) (valid for all operating modes except VOLTMOD).<br>1: Position limits activated<br>0: Position limits deactivated  |

#### Additional settings

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Velocity controller / current limitation

The controller parameters POR and I of the velocity controller can be adjusted. In addition, the current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.2 "Velocity control"](#)).

#### Motion control commands

The positioning is executed via the FAULHABER Motion Control commands. An overview of all Motion Control commands is given in [Chapter 8 "Parameter description"](#).

| Command | Argument | Function               | Description  |
|---------|----------|------------------------|--|
| EN      | -        | Enable Drive           | Activate drive   |
| DI      | -        | Disable Drive          | Deactivate drive   |
| LA      | Value    | Load Absolute Position | Load new absolute target position<br><b>Value: <math>-1.8 \cdot 10^9</math> ... <math>1.8 \cdot 10^9</math></b>  |
| LR      | Value    | Load Relative Position | Load new relative target position, in relation to last started target position.<br>The resulting absolute target position must lie between the values given below.<br><b>Value: <math>-2.14 \cdot 10^9</math> and <math>2.14 \cdot 10^9</math></b> |
| M       | -        | Initiate Motion        | Activate position control and start positioning  |
| HO      | -/value  | Define Home Position   | Without argument:<br>Set actual position to 0.<br>With argument:<br>Set actual position to specified value.<br><b>Value: <math>-1.8 \cdot 10^9</math> ... <math>+1.8 \cdot 10^9</math></b>   |

#### Example:

- Load target position: **LA40000**
- Start positioning: **M**

Attainment of the target position is signalled by bit 10 "Target reached" in the statusword of the drive. If the transmission type for the TxPDO1 is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

#### Position resolution

If the linear Hall sensors of the brushless motors are used as position transducers, 3 000 pulses per revolution are supplied.

## 3 Operation in FAULHABER mode

---

### 3.1 Position control

#### **Complex motion profiles**

More complex motion profiles can be generated through appropriate presetting of new values (maximum speed, acceleration, end position) during positioning. After a value change, simply execute a new motion start command (M).

Further information on compiling motion profiles is given in [Chapter 3.6.1 "Ramp generator"](#).

#### **Positioning beyond the range limits**

In the case of APL0, relative positioning can also be executed beyond the range limits. If the upper (1 800 000 000) or lower (-1 800 000 000) limit is exceeded, counting is continued at 0 without loss of increments.

#### **Digital signal target position**

The entry into the target corridor can be displayed via the fault output as a digital output signal in the POSOUT function. The signal is not reset until a further Motion start command (M).


For notes on configuration, see [Chapter 3.5 "Special fault output functions"](#).

## 3 Operation in FAULHABER mode

### 3.1 Position control

#### 3.1.2 Analog positioning mode (APCMOD)

Controller structure for set-point presetting via an analog voltage



In this operating mode the target position can be preset using an analog voltage at the AnIn input.

#### Basic settings

APCMOD mode and SOR1 or SOR2.

The positioning range limits can be set via the command LL and activated via APL.

The proportional amplification PP and a differential term PD can be set for the position controller.

The maximum position to be approached with a voltage of 10 V can be preselected with the LL command. At -10 V the drive moves in the opposite direction up to the set negative range limit.

Irrespective of the preset LL value, the maximum position is limited to 3 000 000 in APCMOD.

Comment: The resolution of the analog input is limited to 12 bit (4 096 steps).

The direction of rotation can be predefined with the commands ADL and ADR.

| Command | Argument | Function                        | Description  |
|---------|----------|---------------------------------|--|
| PP      | Value    | Load Position Proportional Term | Load position controller amplification.<br><b>Value: 1 ... 255</b>   |
| PD      | Value    | Load Position Differential Term | Load position controller D-term.<br><b>Value: 1 ... 255</b>  |
| LL      | Value    | Load Position Range Limits      | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower.<br>The range limits are only active if APL1 is set.<br><b>Value: -3 000 000 ... 3 000 000 in the APCMOD</b> |
| ADL     | -        | Analog Direction Left           | If the set-point is positive the drive rotates to the left (anti-clockwise).   |
| ADR     | -        | Analog Direction Right          | If the set-point is positive the drive rotates to the right (clockwise).   |

## 3 Operation in FAULHABER mode

---

### 3.1 Position control

#### Additional settings

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Velocity controller / current limitation

The controller parameters POR and I of the velocity controller can be adjusted. In addition, the current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.2 "Velocity control"](#)).

#### Positioning via pulse width signal (PWM) at the analog input (SOR2)

If SOR2 is set in APCMOD, the pulse duty factor of a PWM signal can be used as position set-point.

On delivery:

- Pulse duty factor > 50% → positive target position
- Pulse duty factor = 50% → target position = 0
- Pulse duty factor < 50% → negative target position

#### Absolute positioning within one revolution (only for BL 2 pole):

In motion control systems with brushless 2-pole motors, the initial position is absolutely initialised within one revolution after the motor is switched on (0 - 3 000 corresponds to 0 - 360° of the rotor position). This means that even if the power supply is disconnected, the position determination supplies the correct position value after restarting (if the rotor has only been turned within one revolution).

The following commands enable the drive to be accurately positioned in the voltage range 0 V ... 10 V within one revolution and to return to the correct position even after the supply has been switched off, without homing.


- Switch over to analog positioning: **APCMOD**
- Hide negative range: **LL-1**
- Fix maximum position to 1 revolution: **LL3000**

## 3 Operation in FAULHABER mode

### 3.1 Position control

#### 3.1.3 External encoder as actual position value (ENCMOD) - not for MCDC

Controller structure for using an external encoder as the actual value encoder



For high-precision applications, the actual values of BL motors can be derived from an external encoder.

- Depending on the application, the velocity can be derived from the encoder or from the Hall sensors.
- The external encoder can be mounted directly on the motor shaft, but an encoder that is mounted to the application output (e.g. glass scale) is particularly advantageous. This allows the high precision to be set directly at the output.
- Commutation still occurs via the analog Hall sensors.

#### Basic settings

ENCMOD and SOR0 operating mode.

The positioning range limits can be set via the command LL and activated via APL.

The proportional amplification PP and a differential term PD can be set for the position controller.

| Command | Argument | Function                            | Description  |
|---------|----------|-------------------------------------|--|
| PP      | Value    | Load Position Proportional Term     | Load position controller amplification.<br>Value: 1 ... 255  |
| PD      | Value    | Load Position Differential Term     | Load position controller D-term.<br>Value: 1 ... 255   |
| LL      | Value    | Load Position Range Limits          | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower.<br>The range limits are only active if APL1 is.<br>Value: $-1.8 \cdot 10^9 \dots +1.8 \cdot 10^9$ |
| APL     | 0 - 1    | Activate/Deactivate Position Limits | Activate range limits (LL) (valid for all operating modes except VOLTMOD).<br>1: Position limits activated<br>0: Position limits deactivated   |



## 3 Operation in FAULHABER mode

### 3.1 Position control

#### Settings for external encoder

| Command   | Argument | Function                    | Description   |
|-----------|----------|-----------------------------|---|
| ENCMOD    | -        | Encoder Mode                | Change to encoder mode (not for MCDC) An external encoder serves as position transducer (the current position value is set to 0). |
| ENCSPPEED | -        | Encoder as speed sensor     | Speed via encoder signals in encoder mode   |
| HALLSPEED | -        | Hall sensor as speed sensor | Speed via hall sensors in encoder mode  |
| ENCRESP   | Value    | Load Encoder Resolution     | Load resolution of external encoder (4 times pulse/rev).<br>Value: 8 to 65 535  |

#### Additional settings

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Velocity controller / current limitation

The controller parameters POR and I of the velocity controller can be adjusted. In addition, the current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.2 "Velocity control"](#) and [Chapter 3.6.3 "Current controller and I<sup>2</sup>t current limitation"](#)).

#### Motion control commands

Positioning in the ENCMOD is executed in precisely the same way as in CONTMOD, using the FAULHABER Motion Control commands. An overview of all Motion Control commands is given in [Chapter 8 "Parameter description"](#).

| Command | Argument | Function               | Description   |
|---------|----------|------------------------|---|
| EN      | -        | Enable Drive           | Activate drive  |
| DI      | -        | Disable Drive          | Deactivate drive  |
| LA      | Value    | Load Absolute Position | Load new absolute target position<br>Value: $-1.8 \cdot 10^9$ ... $1.8 \cdot 10^9$  |
| LR      | Value    | Load Relative Position | Load new relative target position, in relation to last started target position.<br>The resulting absolute target position must lie between the values given below.<br>Value: $-2.14 \cdot 10^9$ and $2.14 \cdot 10^9$ |
| M       | -        | Initiate Motion        | Activate position control and start positioning   |
| HO      | -/value  | Define Home Position   | Without argument:<br>Set actual position to 0.<br>With argument:<br>Set actual position to specified value.<br>Value: $-1.8 \cdot 10^9$ ... $+1.8 \cdot 10^9$   |

## 3 Operation in FAULHABER mode

---

### 3.1 Position control

#### Example:

- Load target position: **LA40000**
- Start positioning: **M**

Attainment of the target position is signalled by bit 10 "Target reached" in the statusword of the drive. If the transmission type for the TxPDO1 is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

#### Position resolution

In ENCMOD the resolution of the position values depends on the resolution of the encoder.

#### Complex motion profiles

More complex motion profiles can be generated through appropriate presetting of new values (maximum speed, acceleration, end position) during positioning. After a value change, simply execute a new motion start command (M).

Further information on compiling motion profiles is given in [Chapter 3.6.1 "Ramp generator"](#).

#### Positioning beyond the range limits

In the case of APL0, relative positioning can also be executed beyond the range limits. If the upper (1 800 000 000) or lower limit (-1 800 000 000) is exceeded, counting is continued at 0 without loss of increments.

#### Digital signal target position

The entry into the target corridor can be displayed via the fault output as a digital output signal in the POSOUT function. The signal is not reset until a further Motion start command (M).

For notes on configuration, see [Chapter 3.5 "Special fault output functions"](#).

## 3 Operation in FAULHABER mode

---

### 3.2 Velocity control

#### Guide

**Velocity control mode with set value presetting via CAN**

Target velocity via CAN/PDO2 Page 28

**Velocity control mode with set value presetting via the analog input**

Velocity presetting via an analog voltage or a PWM signal Page 30

**Velocity control mode with external encoder as actual value**

External encoder as actual velocity value (ENCMOD) - not for MCDC Page 32

In velocity control mode the velocity of the drive is controlled by a PI controller. Provided the drive is not overloaded, the drive follows the presetting without deviation.

The current velocity of BL motors can be detected both from the Hall signals and via an additional encoder; an incremental encoder is always required for DC motors. One exception is the IxR control, as described in [Chapter 3.4.5 "IxR control for MCDC"](#).


The velocity can be preset via the CAN interface (PDO2), via an analog voltage preset or via a PWM signal.

## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### 3.2.1 Target velocity via CAN /PDO2

##### Controller structure for velocity control



In this operating mode, the drive velocity can be controlled with set-point presetting via FAULHABER commands on PDO2. The velocity of BL motors is registered by the analog hall sensors, incremental encoders are only supported for DC motors.

#### Basic settings

CONTMOD and SOR0 operating mode.

The controller parameters POR and I and the sampling rate can be adjusted for the velocity controller.

| Command | Argument | Function                        | Description  |
|---------|----------|---------------------------------|--|
| POR     | Value    | Load Velocity Proportional Term | Load velocity controller amplification.<br>Value: 1 ... 255  |
| I       | Value    | Load Velocity Integral Term     | Load velocity controller integral term.<br>Value: 1 ... 255  |
| SR      | Value    | Load Sampling Rate              | Load sampling rate of the velocity controller as a multiple of the basic sampling time.<br>Value: 1 ... 20 |

#### Velocity input

In BL motors the current velocity is determined in CONTMOD by evaluating the Hall sensor signals, which supply 3 000 pulses per revolution.

In DC motors the velocity is determined using an incremental encoder whose resolution has to be set using the ENCRE command. DC motors without an incremental encoder can also be operated with limited accuracy in IxR mode (see [Chapter 3.4.5 "IxR control for MDCD"](#)).

| Command | Argument | Function                | Description  |
|---------|----------|-------------------------|--|
| ENCRE   | Value    | Load Encoder Resolution | Load resolution of external encoder (4 times pulse/rev).<br>Value: 8 to 65 535 |

## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### Additional settings

##### Movement limits

The LL command can also be used to define a movement range limit for velocity mode. The APL1 command activates monitoring of these limits.

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Current limitation

The current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.6.3 "Current controller and I<sup>2</sup>t current limitation"](#)).

#### Motion control commands

An overview of all Motion Control commands is given in [Chapter 8 "Parameter description"](#).

| Command | Argument | Function             | Description   |
|---------|----------|----------------------|---|
| EN      | -        | Enable Drive         | Activate drive  |
| DI      | -        | Disable Drive        | Deactivate drive  |
| V       | Value    | Select Velocity Mode | Activate velocity mode and set specified value as target velocity (velocity control).<br>Unit: rpm<br>Value: -30 000 ... 30 000 |

##### Example:

- Drive motor at 100 rpm:  $v100$   
In order to change the direction of rotation, simply assign a negative velocity value (e.g.  $v-100$ ).
- Stop motor:  $v0$

#### NOTE



*Make sure that APL0 is set, if you do not want the drive to stop at the set range limits (LL)!*

*Also check that the maximum speed SP is not set below the desired target velocity.*

#### Complex motion profiles

Attainment of the target velocity is signalled by bit 10 "Target reached" in the statusword of the drive. If the transmission type for the TxPDO1 is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

| Command | Argument | Function                            | Description  |
|---------|----------|-------------------------------------|--|
| LL      | Value    | Load Position Range Limits          | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower.<br>The range limits are only active if APL1 is.<br>Value: $-1.8 \cdot 10^9 \dots +1.8 \cdot 10^9$ |
| APL     | 0 - 1    | Activate/Deactivate Position Limits | Activate range limits (LL) (valid for all operating modes except VOLTMOD).<br>1: Position limits activated<br>0: Position limits deactivated   |

## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### 3.2.2 Velocity presetting via an analog voltage or a PWM signal

In this operating mode, the drive velocity can be controlled with set value presetting via an analog voltage or a PWM signal.

##### Basic settings

CONTMOD mode and SOR1 (AnIn) or SOR2 (PWMIn).

The controller parameters POR, I and the sampling rate can be adjusted for the velocity controller. In addition, commands are available for configuring the analog velocity presetting.

| Command | Argument | Function                        | Description   |
|---------|----------|---------------------------------|---|
| SP      | Value    | Load Maximum Speed              | Load maximum speed (here: Target velocity at 10 V). Setting applies to all modes (except VOLTMOD).<br>Unit: rpm<br><b>Value: 0 ... 30 000</b>                                 |
| MV      | Value    | Minimum Velocity                | Specifies the lowest velocity.<br>Unit: rpm<br><b>Value: 0 ... 30 000</b>   |
| MAV     | Value    | Minimum Analog Voltage          | Specifies the minimum start voltage.<br>Unit: mV<br><b>Value: 0 ... 10 000</b>  |
| ADL     | -        | Analog Direction Left           | Positive voltages at the analog input result in counterclockwise rotation of the rotor  |
| ADR     | -        | Analog Direction Right          | Positive voltages at the analog input result in clockwise rotation of the rotor.  |
| DIRIN   | -        | Direction Input                 | Use fault pin as rotational direction input.<br>Low: ... anticlockwise rotation (corresponding to ADL command)<br>High: ... clockwise rotation (corresponding to ADR command) |
| POR     | Value    | Load Velocity Proportional Term | Load velocity controller amplification.<br><b>Value: 1 ... 255</b>  |
| I       | Value    | Load Velocity Integral Term     | Load velocity controller integral term.<br><b>Value: 1 ... 255</b>  |
| SR      | Value    | Load Sampling Rate              | Load sampling rate of the velocity controller as a multiple of the basic sampling time.<br><b>Value: 1 ... 20</b>   |

##### Velocity input

By default, in BL motors the current speed is determined by evaluating the Hall sensor signals. Additional incremental encoders cannot be connected to BL motors for analog velocity presetting

In DC motors the velocity is solely determined using the incremental encoder. DC motors without an incremental encoder can also be operated with limited accuracy in IxR mode (see [Chapter 3.4.5 "IxR control for MCDC"](#)).

## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### Target value input


##### Example:

The drive is only to start moving with voltages over 100 mV or below -100 mV at the analog input:

- MAV100

##### Advantage:

As 0 mV is usually difficult to set at the analog input, 0 rpm is also not easy to implement. The dead band produced by the minimum start voltage prevents the motor from starting as a result of small interference voltages.



#### Additional settings

##### Movement limits

The LL command can also be used to define a movement range limit for velocity mode. The APL1 command activates monitoring of these limits.

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Current limitation

The current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.6.3 "Current controller and I<sup>2</sup>t current limitation"](#)).

#### Velocity control using pulse width modulated (PWM) signal at the analog input (SOR2)

If SOR2 is set in CONTMOD, the pulse duty factor of a PWM signal can be used as velocity target.

On delivery:

- Pulse duty factor > 50% → clockwise rotation
- Pulse duty factor = 50% → stoppage  $n = 0$
- Pulse duty factor < 50% → anti-clockwise rotation

The commands SP, MV, MAV, ADL and ADR can also be used here.

#### NOTE



*Make sure that APL0 is set, if you do not want the drive to stop at the set range limits (LL)! Also check that the maximum speed SP is not set below the desired target velocity.*

#### Input circuit


The input circuit at the analog input is designed as a differential amplifier. If the analog input is open, an undefined velocity can be set. The input must be connected to AGND with low-impedance or set to the voltage level of the AGND, in order to generate 0 rpm. For a protective circuit example, see [Chapter 3.4 in the technical manual](#).

## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### 3.2.3 External encoder as actual velocity value (ENCMOD) - not for MCDC

##### Velocity control with external encoder as actual value



In this operating mode, the drive velocity can be controlled with set-point presetting via FAULHABER commands on PDO2. The velocity is evaluated via an additional encoder, external or built onto the motor. In particular, this enables a specific load speed to be controlled by an incremental encoder at the output.

ENCMOD mode is available for BL motors only. The analog Hall sensors of the motors are also evaluated in ENCMOD mode for the motor commutation.

#### Basic settings

ENCMOD and SOR0 operating mode.

The controller parameters POR and I and the sampling rate can be adjusted for the velocity controller.

| Command | Argument | Function                        | Description  |
|---------|----------|---------------------------------|--|
| POR     | Value    | Load Velocity Proportional Term | Load velocity controller amplification.<br>Value: 1 ... 255  |
| I       | Value    | Load Velocity Integral Term     | Load velocity controller integral term.<br>Value: 1 ... 255  |
| SR      | Value    | Load Sampling Rate              | Load sampling rate of the velocity controller as a multiple of the basic sampling time.<br>Value: 1 ... 20 |



## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### Velocity input

The external incremental encoder's resolution must be specified with 4 edge evaluation using the ENCRESP parameter.

In addition to ENCMOD mode, velocity evaluation on the basis of the encoder must be activated using the ENCSPEED command.

| Command   | Argument | Function                    | Description  |
|-----------|----------|-----------------------------|--|
| ENCRESP   | Value    | Load Encoder Resolution     | Load resolution of external encoder (4 times pulse/rev).<br><b>Value: 8 to 65 535</b>  |
| ENCMOD    | -        | Encoder Mode                | Change to encoder mode (not for MCDC) An external encoder serves as position detector (the current position value is set to 0) |
| ENCSPEED  | -        | Encoder as speed sensor     | Speed via encoder signals in encoder mode  |
| HALLSPEED | -        | Hall sensor as speed sensor | Speed via hall sensors in encoder mode   |

#### Additional settings

##### Movement limits

The LL command can also be used to define a movement range limit for velocity mode. The APL1 command activates monitoring of these limits.

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Current limitation

The current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.6.3 "Current controller and I<sub>t</sub> current limitation"](#)).

#### Motion control commands

An overview of all Motion Control commands is given in [Chapter 8 "Parameter description"](#).

| Command | Argument | Function             | Description  |
|---------|----------|----------------------|--|
| EN      | -        | Enable Drive         | Activate drive   |
| DI      | -        | Disable Drive        | Deactivate drive   |
| V       | Value    | Select Velocity Mode | Activate velocity mode and set specified value as target velocity (velocity control).<br>Unit: rpm<br><b>Value: -30 000 ... 30 000</b> |

#### Example:

- Drive motor at 100 rpm:  $v100$   
In order to change the direction of rotation, simply assign a negative velocity value (e.g.  $v-100$ ).
- Stop motor:  $v0$

#### NOTE



*Make sure that APL0 is set, if you do not want the drive to stop at the set range limits (LL)! Also check that the maximum speed SP is not set below the desired target velocity.*

## 3 Operation in FAULHABER mode

### 3.2 Velocity control

#### Complex motion profiles

Attainment of the target velocity is signalled by bit 10 "Target reached" in the statusword of the drive. If the transmission type for the TxPDO1 is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

| Command | Argument | Function                            | Description   |
|---------|----------|-------------------------------------|---|
| LL      | Value    | Load Position Range Limits          | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower.<br>The range limits are only active if APL is 1.<br><b>Value: <math>-1.8 \cdot 10^9 \dots +1.8 \cdot 10^9</math></b> |
| APL     | 0 - 1    | Activate/Deactivate Position Limits | Activate range limits (LL) (valid for all operating modes except VOLTMOD).<br>1: Position limits activated<br>0: Position limits deactivated  |

## 3 Operation in FAULHABER mode

---

### 3.3 Homing and limit switches

#### Guide

**Overview of the connections of the Faulhaber Motion Control systems available for limit switches and their configuration**

Limit switch connections and switching level Page 36

**Motion control commands (trigger homing sequence)**

Motion control commands Page 37

**Configuration of the behaviour at the limit switch and the homing sequence**

Configuration of homing and limit switches Page 38

Homing on limit switches can be used to re-initialise the absolute position of an application after switching on.

The GOHOSEQ command is used to perform previously defined homing up to the set limit switch and then perform the actions defined for it. The ramp generator settings for maximum acceleration and the movement limits are taken into account.

## 3 Operation in FAULHABER mode

### 3.3 Homing and limit switches

#### 3.3.1 Limit switch connections and switching level

The connections

- AnIn
- Fault
- 3<sup>rd</sup> input
- 4<sup>th</sup>, 5<sup>th</sup> input (MCDC only)

can be used as reference and limit switch inputs.

In addition, the zero crossing of the Hall sensor signals is also available as an index pulse in BL motors. Depending on the motor type (two-pole or four-pole), the index pulse occurs once or twice per revolution. The index pulse of an external encoder can also be connected to the fault pin, enabling the actual position to be exactly zeroed.

The AnIn and Fault connections are designed as interrupt inputs, which means that they are edge-triggered. All other inputs are not edge-triggered, so that the signal must be applied for at least 500 µs to enable it to be reliably detected. The maximum response time to level changes at all inputs is 500 µs.

#### Digital input configuration

| Command | Argument | Function        | Description  |
|---------|----------|-----------------|--|
| SETPLC  | -        | Set PLC inputs  | Digital inputs PLC-compatible (24 V level)<br>(For level definition, see technical manual) |
| SETTTL  | -        | Set TTL inputs  | Digital inputs TTL-compatible (5 V level)<br>(For level definition, see technical manual)  |
| REFIN   | -        | Reference Input | Fault pin as reference or limit switch input   |

The limit switch functions for the fault pin are only accepted if REFIN is activated (setting must be saved with SAVE)!

#### CAUTION!



#### **Configure before applying a voltage**

*The electronics can be damaged if a voltage is applied to the fault pin while it is not configured as input.*

- ▶ *Configure the fault pin as input first before applying external voltage!*

## 3 Operation in FAULHABER mode

### 3.3 Homing and limit switches

#### 3.3.2 Motion control commands

The function of the inputs and the homing behaviour are set using the FAULHABER commands described in [Chapter 3.3.3 "Configuration of homing and limit switches"](#). A previously configured homing is then started with the following FAULHABER commands. An overview of all motion control commands is given in [Chapter 7.4 "Motion control commands"](#).

| Command | Argument | Function           | Description  |
|---------|----------|--------------------|--|
| GOHOSEQ | -        | Go Homing Sequence | Execute FAULHABER homing sequence. A homing sequence is executed (if programmed) irrespective of the current mode. |
| FHIX    | -        | Find Hall Index    | The nearest index pulse in the preset direction of rotation is approached.<br>For BX4 drives only                  |
| GOHIX   | -        | Go Hall Index      | Move BL motor to Hall zero point (Hall index) and set actual position value to 0.<br>Not for BX4 and MCDC drives   |
| GOIX    | -        | Go Encoder Index   | Move to the encoder index at the Fault pin and set actual position value to 0 (DC motor or ext. encoder).          |


If the drive is already located in the limit switch when GOHOSEQ is invoked, first of all it moves out of the switch, in the opposite direction to that specified for HOSP.

## 3 Operation in FAULHABER mode

### 3.3 Homing and limit switches

#### 3.3.3 Configuration of homing and limit switches

The following commands use the following bit mask for configuration of the limit switch functions:



#### Polarity and limit switch function

Limit switches can respond to the rising or falling edge (or level).

In addition, the hard blocking function can be configured for the limit switches. The hard blocking function provides reliable protection against overshooting of the range limit switch. If the drive is located in an HB limit switch, then the direction of rotation set with HD will be blocked, i.e. the drive can only move further out of the limit switch.

The speed stays at 0 rpm if target velocity is preset in the wrong direction.

| Command | Argument | Function       | Description   |
|---------|----------|----------------|---|
| HP      | Bit mask | Hard Polarity  | Define valid edge and polarity of respective limit switches:<br>1: Rising edge and high level effective.<br>0: Falling edge and low level effective.              |
| HB      | Bit mask | Hard Blocking  | Activate Hard Blocking function for relevant limit switch.  |
| HD      | Bit mask | Hard Direction | Presetting of direction of rotation that is blocked with HB of respective limit switch.<br>1: Clockwise rotation blocked<br><br>0: Anticlockwise rotation blocked |

#### Example:

- Setting the hard blocking function for fault pin and 4<sup>th</sup> input:  $2^1 + 2^3 = 2 + 8 = 10 \rightarrow \text{HB10}$

#### Definition of homing behaviour

In order to be able to execute a homing sequence with the command GOHOSEQ, a homing sequence must be defined for a specific limit switch! To do this, at least one of the following actions must be defined for the limit switch. Definition of the hard blocking behaviour is an additional option.

| Command | Argument | Function                            | Description  |
|---------|----------|-------------------------------------|--|
| SHA     | Bit mask | Set Home Arming for Homing Sequence | Homing behaviour (GOHOSEQ): Set position value to 0 at edge of respective limit switch   |
| SHL     | Bit mask | Set Hard Limit for Homing Sequence  | Homing behaviour (GOHOSEQ): Stop motor at edge of respective limit switch.   |
| SHN     | Bit mask | Set Hard Notify for Homing Sequence | Homing behaviour (GOHOSEQ): If an edge is at the respective limit switch, the hard notify bit is set in the statusword of the drive. |

These settings must be saved with SAVE so that they are available immediately after switching on!

## 3 Operation in FAULHABER mode

### 3.3 Homing and limit switches

#### Example:

- Homing with 3<sup>rd</sup> input as reference input (rising edge):
  - **HP4** Low level or falling edge was evaluated at AnIn and at the fault pin, the rising edge is evaluated at the 3<sup>rd</sup> input.
  - **SHA4** Activate a homing sequence for 3<sup>rd</sup> input (all others are in bit mask = 0) Action: Set Pos = 0 on reaching the limit switch
  - **SHL4** Activate a homing sequence for 3<sup>rd</sup> input (all others are in bit mask = 0) Action: Stop motor
  - **SHN4** Activate a homing sequence for 3<sup>rd</sup> input (all others are in bit mask = 0) Action: Notify in statusword of the drive or via TxPD01

#### Homing Speed

| Command | Argument | Function          | Description   |
|---------|----------|-------------------|---|
| HOSP    | Value    | Load Homing Speed | Load speed and direction of rotation for homing (GO-HOSEQ, GOHIX).<br>Unit: rpm |

#### Example:

- Homing with 100 rpm and negative direction of rotation:  
HOSP-100

#### Direct programming via HA, HL and HN commands

These special commands can be used to define actions that are to be triggered at an edge of the relevant input, independently of a homing sequence. A programmed limit switch function will remain effective until the preselected edge occurs. The programming can be changed with a new command before an edge occurs.

| Command | Argument | Function    | Description   |
|---------|----------|-------------|---|
| HA      | Bit mask | Home Arming | Set position value to 0 and delete relevant HA bit at edge of respective limit switch.<br>Setting is not saved                    |
| HL      | Bit mask | Hard Limit  | Stop motor and delete relevant HL bit at edge of respective limit switch.<br>Setting is not saved.                                |
| HN      | Bit mask | Hard Notify | If an edge is at the respective limit switch, the hard notify bit is set in the statusword of the drive.<br>Setting is not saved. |

The settings are not saved with the SAVE command, therefore all configured limit switches are inactive again after power-on.

#### HL/SHL command:

##### ■ Positioning mode

When the edge occurs, the motor positions itself on the reference mark with maximum acceleration.

##### ■ Velocity controller mode

The motor is decelerated at the set acceleration value when the edge occurs, i.e. it goes beyond the reference mark. The reference mark can be precisely approached with a subsequent positioning command (command M).

**Advantage:** No abrupt motion changes.

## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes


#### Guide

|  |         |
|--|---------|
| Stepper motor mode                             | Page 40 |
| Gearing mode (electronic gear)                 | Page 42 |
| Voltage regulator mode                         | Page 44 |
| Current control with analog current presetting | Page 45 |
| IxR control for MDC                            | Page 47 |

Use the CONTMOD command to revert from an enhanced operating mode to normal mode.

#### 3.4.1 Stepper motor mode

##### Controller structure in stepper motor mode



In stepper motor mode the drive moves one programmable angle further for each pulse at the analog input, and thus simulates the function of a stepper motor.

There are a number of considerable advantages in comparison with a real stepper motor:

- The number of steps per revolution is freely programmable and of a very high resolution (encoder resolution)
- The individual step widths are freely programmable
- No detent torque
- The full dynamics of the motor can be used
- The motor is very quiet
- The motor monitors actual position so that no steps are "lost" (even with maximum dynamics)
- No motor current flows in settled state (actual position reached)
- High efficiency



## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### Basic settings

In stepper motor mode, the analog input acts as frequency input. The error output must be configured as rotational direction input if the direction of rotation is to be changed via a digital signal.

Alternatively, the direction of rotation can also be preset via the commands ADL and ADR.

| Command | Argument | Function               | Description   |
|---------|----------|------------------------|---|
| STEPMOD | -        | Stepper Motor Mode     | Change to stepper motor mode  |
| DIRIN   | -        | Direction Input        | Fault pin as rotational direction input   |
| ADL     | -        | Analog Direction Left  | Positive voltages at the analog input result in anticlockwise rotation of the rotor |
| ADR     | -        | Analog Direction Right | Positive voltages at the analog input result in clockwise rotation of the rotor     |

#### Input

Maximum input frequency: see technical manual.

Level: 5 V TTL or 24 V PLC-compatible, depending on configuration.

The number of steps of the emulated stepper motor can be set to virtually any required settings using the following formula:

$$\text{Revolutions} = \text{pulses} \cdot \frac{\text{STW}}{\text{STN}}$$

Motor revolutions      ... revolutions generated on the drive

Pulses                    ... number of pulses at the frequency input (= number of steps)

| Command | Argument | Function         | Description  |
|---------|----------|------------------|--|
| STW     | Value    | Load Step Width  | Load step width for step motor and gearing mode<br>Value: 1 ... 65 535                     |
| STN     | Value    | Load Step Number | Load number of steps per revolution for step motor and gearing mode<br>Value: 1 ... 65 535 |

#### Example:

The motor should move by 1/1 000th of a revolution per input signal:

- STW1
- STN1000

#### Additional settings

##### Movement limits

The LL command can be used to define a limit for the movement range for stepper motor mode also. The APL1 command activates monitoring of these limits.

##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Current limitation


The current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.6.3 "Current controller and I<sup>2</sup>t current limitation"](#)).

## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### 3.4.2 Gearing mode (electronic gear)

##### Controller structure in gearing mode



Gearing mode enables the use of an external encoder as set-point source for the position. This enables several drives to be synchronised. Several drives can be synchronised in this way. If the direction of rotation is to be changed by a digital signal, the function of the fault pin must be reconfigured as a rotational direction input.

Alternatively, the direction of rotation can also be preset via the commands ADL and ADR.

##### Basic settings

| Command | Argument | Function        | Description                             |
|---------|----------|-----------------|---|
| GEARMOD | -        | Gearing Mode    | Change to gearing mode                  |
| DIRIN   | -        | Direction Input | Fault pin as rotational direction input |

##### Input

The two channels of an external encoder are connected to connections AnIn and AGND, which may need to be connected to the 5 V encoder supply via a 2.7 kΩ pull-up resistor.

The gear ratio between the pulses per revolution (PPR) count of the external encoder and the resulting movement of the motor can be set using the following formula:

$$\text{Revolutions} = \text{pulses} \cdot \frac{\text{STW}}{\text{STN}}$$

Motor revolutions ... revolutions generated on the drive

Pulses ... actually counted pulses during four edge evaluation

| Command | Argument | Function         | Description  |
|---------|----------|------------------|--|
| STW     | Value    | Load Step Width  | Load step width for step motor and gearing mode<br>Value: 1 ... 65 535                     |
| STN     | Value    | Load Step Number | Load number of steps per revolution for step motor and gearing mode<br>Value: 1 ... 65 535 |

## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### Example:

Motor has to move one revolution at 1 000 pulses of the external encoder:

- STW1
- STN1000

#### Additional settings

##### Movement limits

The range limits set with LL are also active in gearing mode with APL1.


##### Ramp generator

The slopes of the acceleration and deceleration ramps, and the maximum speed can be defined using the AC, DEC and SP commands (see [Chapter 3.6.1 "Ramp generator"](#)).

##### Current limitation

The current limitation values LPC and LCC can be used to protect the drive against overload (see [Chapter 3.6.3 "Current controller and I<sup>2</sup>t current limitation"](#)).

#### Circuit example, gearing mode for MCBL 3003/06 C




## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### 3.4.3 Voltage regulator mode

##### Controller structure in voltage regulator mode



In voltage regulator mode a motor voltage is output proportional to the preset value. Current limitation remains active.

With this mode, it is possible to use a higher level controller. The controller then serves only as a power amplifier.

##### Basic settings

| Command | Argument | Function           | Description  |
|---------|----------|--------------------|--|
| VOLTMOD | -        | Set Voltage Mode   | Activate Voltage Regulator Mode  |
| U       | Value    | Set Output Voltage | Output motor voltage (corresponds to $-U_B \dots +U_B$ ) at SOR0 only<br>Value: -32 767 ... 32 767 |

##### Input

| SOR0 (CAN / PDO2) | SOR1 (AnIn) | SOR2 (PWMIn) | U <sub>MOT</sub> |
|-------------------|-------------|--------------|------------------|
| U-32767           | -10 V       | 0 %          | -U <sub>B</sub>  |
| U0                | 0 V         | 50 %         | 0                |
| U32767            | 10 V        | 100 %        | +U <sub>B</sub>  |

##### Additional settings

###### Current limitation

The current limitation values LPC and LCC can be used to protect the drive against overload.


## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### 3.4.4 Current control with analog current presetting

##### Fixed direction of rotation (SOR3)

##### Controller structure for analog current presetting with fixed preset direction of rotation



You can switch to analog target current presetting with the SOR3 command. In this way, both in velocity mode and in voltage regulator mode, current absolute value can be limited proportional to the voltage at the analog input. The set current is weighted with the maximum current LPC.

The motor is activated either in velocity mode by a previously fixed target velocity, or in voltage regulator mode via a voltage value. The error output must be configured as rotational direction input if the direction of rotation is to be changed via a digital signal.

#### Basic settings

| Command | Argument | Function                | Description                                    |
|---------|----------|-------------------------|--|
| SOR     | 3        | Source for Velocity     | 3: Current target value via analog input       |
| LPC     | Value    | Load Peak Current Limit | Load peak current (mA).<br>Value: 0 ... 12 000 |

#### Input

If 10 V are present at the analog input, the current is accordingly limited to the maximum current set with LPC.

Even if negative voltages are present at the analog input, the current is limited to the absolute value of the applied voltage. Negative target current presettings therefore have no effect on the direction of rotation!

| SOR3 (AnIn) | $I_{max}$ | $n_{max}$ |
|-------------|-----------|-----------|
| -10 V       | LPC       | SP        |
| 0 V         | 0         | SP        |
| 10 V        | LPC       | SP        |

#### Warning!



#### Risk of destruction


In current control mode with analog current presetting the internal  $I^2t$  current limitation is deactivated.

## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### Direction of rotation depending on current target value (SOR4)

##### Controller structure for analog current presetting with variable direction of rotation



You can switch to analog target current presetting with the SOR4 command. In this way, both in velocity mode and in voltage regulator mode, current absolute value can be limited proportional to the voltage at the analog input. The set current is weighted with the maximum current LPC.

The motor is activated either in velocity mode by a previously fixed target velocity, or in voltage regulator mode via a voltage value. The direction of rotation is determined from the sign of the current target value.

This mode corresponds to direct current control.

#### Basic settings

| Command | Argument | Function                | Description  |
|---------|----------|-------------------------|--|
| SOR     | 4        | Source for Velocity     | 4: Target current value via analog input with presetting of the direction of rotation via the sign of the set-point. |
| LPC     | Value    | Load Peak Current Limit | Load peak current (mA).<br>Value: 0 ... 12 000   |

#### Input

If 10 V are present at the analog input, the current is accordingly limited to the maximum current set with LPC.


| SOR4 (AnIn) | $I_{max}$ | $n_{max}$ |
|-------------|-----------|-----------|
| -10 V       | LPC       | -SP       |
| 0 V         | 0         | SP        |
| 10 V        | LPC       | SP        |

## 3 Operation in FAULHABER mode

### 3.4 Extended operating modes

#### 3.4.5 IxR control for MCDC

##### Controller structure in IxR mode



For speed-controlled applications with DC motors without an encoder, an IxR control is available on the MCDC. In this mode, the motor speed is determined via an internal motor model. Consequently, the encoder and the associated wiring can be omitted.

However, control quality and accuracy are considerably restricted. This mode is mainly suited for higher speeds and larger motors in the FAULHABER range.

##### Basic settings

| Command | Argument | Function              | Description  |
|---------|----------|-----------------------|--|
| IXRMOD  | -        | Set IxR Mode          | Activate IxR control (MCDC only)   |
| RM      | Value    | Load Motor Resistance | Load motor resistance $R_M$ according to specification in data sheet.<br>Unit: $m\Omega$   |
| KN      | Value    | Load Speed Constant   | Load speed constant $k_N$ in accordance with information in the data sheet.<br>Unit: rpm/V |

In stationary mode the following formula applies to the voltage at the DC motor:  $U_M = R_M \times I_A + k_N \times n$ .

As a result, at constant terminal voltage  $U_M$  the speed falls under load.

Vice versa, if  $R_M$  and  $k_N$  are known, the voltage applied to the motor can be increased depending on the target velocity and the measured motor current so that the voltage drop is approximately compensated at the winding resistor.

##### Setting rules

Synchronisation of the no-load speed via  $k_N$ .

Synchronisation of the velocity under load via  $R_M$ .

- Velocity increases under load:  $R_M$  is set too high
- Velocity drops too far under load:  $R_M$  is set too low

## 3 Operation in FAULHABER mode

### 3.5 Special fault output functions

The error connection (fault pin) can be configured as input or output for different tasks:

| Command | Function        | Description  |
|---------|-----------------|--|
| ERROUT  | Error Output    | Fault pin as error output (default)  |
| ENCOUT  | Encoder Output  | Fault pin as pulse output (not MCDC)   |
| DIGOUT  | Digital Output  | Fault pin as digital output. The output is set to low level.   |
| DIRIN   | Direction Input | Fault pin as rotational direction input <ul style="list-style-type: none"> <li>▶ Velocity control (see <a href="#">Chapter 3.2 "Velocity control"</a>),</li> <li>▶ Stepper motor mode (see <a href="#">Chapter 3.4.1 "Stepper motor mode"</a>),</li> <li>▶ Gearing mode (see <a href="#">Chapter 3.4.2 "Gearing mode (electronic gear)"</a>),</li> <li>▶ Voltage regulator mode (see <a href="#">Chapter 3.4.3 "Voltage regulator mode"</a>).</li> <li>▶ Current control with analog current presetting (see <a href="#">Chapter 3.4.4 "Current control with analog current presetting"</a>).</li> </ul> |
| REFIN   | Reference Input | Fault pin as reference or limit switch input <ul style="list-style-type: none"> <li>▶ Homing and limit switches (see <a href="#">Chapter 3.3 "Homing and limit switches"</a>)</li> </ul>   |
| POSOUT  | Position Output | Fault pin as output for display of the condition: "target position reached".   |

#### Fault pin as error output

In ERROUT mode the output is set as soon as one of the following errors occurs:

- One of the set current limitation values (LPC, LCC) is exceeded
- Set maximum permissible speed deviation (DEV) is exceeded
- Overvoltage detected
- Maximum coil or MOSFET temperature exceeded

#### Additional settings

##### Delayed signalling

In order to hide the transient occurrence of errors during the acceleration phase, for example, an error delay can be set which specifies how long an error must be present before it is displayed at the error output:

| Command | Argument | Function              | Description   |
|---------|----------|-----------------------|---|
| DCE     | Value    | Delayed Current Error | Delayed error output with ERROUT<br>Value in 1/100 sec. |

##### Example:

Wait 2 seconds before displaying error:

- DCE200

If one of the errors above occurs, a corresponding Emergency Object is sent to the CAN network, provided the Emergency mask in Object 0x2320 for the corresponding error is set to 1. See also [Chapter 8.2 "Manufacturer-specific objects"](#) under "FAULHABER Fault Register".



## 3 Operation in FAULHABER mode

### 3.5 Special fault output functions

#### Fault pin as pulse output (not for MCDC):

In the ENCOUT mode the fault pin is used as pulse output, which outputs an adjustable number of pulses per revolution. The pulses are derived from the Hall sensor signals of the BL motors and are limited to max. 4 000 pulses per second in 2 pole motors, and to max. 2 000 pulses per second in 4 pole motors.

In MCBL 300x CF AES the LPN value is limited to 32.

| Command | Argument | Function          | Description  |
|---------|----------|-------------------|--|
| LPN     | Value    | Load Pulse Number | Preset pulse number for ENCOUT.<br>Value: 1 to 255<br>Value: 1 bis 32 bei MCBL AES |

#### Example:

Output 16 pulses per revolution at the fault pin:

##### ■ LPN16

In the case of 5 000 rpm,  $5\,000/60 \cdot 16 = 1\,333$  pulses per second are output.

#### NOTE



*Bei Drehzahlen, die bei eingestelltem LPN-Wert mehr als die maximal mögliche Impulszahl erzeugen würden, wird die maximale Anzahl ausgegeben. The set pulses are precisely achieved, but the timing does not necessarily have to exactly agree (delays possible).*

*Position determination via pulse counting is therefore possible, provided that no change occurs in the direction of rotation and the maximum possible pulse number is not exceeded.*

#### Fault pin as digital output

In DIGOUT mode, the fault pin can be used as universal digital output. The digital output can be set or cleared using the following commands:

| Command | Argument | Function      | Description                             |
|---------|----------|---------------|---|
| CO      | -        | Clear Output  | Set digital output DIGOUT to low level  |
| SO      | -        | Set Output    | Set digital output DIGOUT to high level |
| TO      | -        | Toggle Output | Toggle digital output DIGOUT            |


## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### 3.6.1 Ramp generator

In all modes, apart from voltage regulator mode and current control, the set-point is controlled by the ramp generator.

##### Basic ramp generator function



This can be used to separately set the parameters for maximum acceleration (AC), maximum delay (DEC) and maximum speed (SP) for specific applications.

#### CAUTION!



#### **Overshoot at maximum acceleration / delay**

*If the acceleration (AC) or delay (DEC) is set to the maximum value of 30 000 mm/s<sup>2</sup> or higher the effect of the ramp generator is switched off. With this setting, the maximum possible dynamic of the drive system is achieved. At this setting, at times the drive swings clearly beyond the target position.*

► Please note and take into account this fact during use.

Basic settings


| Command | Argument | Function                  | Description   |
|---------|----------|---------------------------|---|
| AC      | Value    | Load Command Acceleration | Load acceleration value (1/s <sup>2</sup> ).<br>Value: 0 ... 30 000 |
| DEC     | Value    | Load Command Acceleration | Load deceleration value (1/s <sup>2</sup> ).<br>Value: 0 ... 30 000 |
| SP      | Value    | Load Maximum Speed        | Load maximum speed (rpm).<br>Value: 0 ... 30 000                    |

## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### Ramp generator in velocity mode

##### Intervention of the ramp generator in velocity mode



In velocity mode the ramp generator acts like a filter on the target velocity. The target value is limited to the maximum speed value (SP) and target value changes are limited according to the deceleration and acceleration ramps (AC and DEC).

#### Notification of the higher level control


Attainment of the target velocity is signalled by bit 10 "Target reached" in the statusword of the drive. If the transmission type for the TxPDO1 is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### Ramp generator in positioning mode

##### Intervention of the ramp generator in positioning mode



In positioning mode a preset speed is determined by the position controller from the difference between the target position and actual position.

In the ramp generator, the preset speed output by the position controller is limited to the maximum speed value (SP) and accelerations are limited according to the acceleration ramp (AC).

In positioning mode the deceleration process is not extended as, before reaching the limit position, the speed has to be reduced so that the target position can be reached without overshooting.

According to the equation of motion:

$$2a s = v^2 \rightarrow v_{\max} = \sqrt{2a s}$$

a: Acceleration [m/s<sup>2</sup>]

v: Velocity [m/s]

s: remaining distance [m]

the maximum speed  $v_{\max}$  must be limited proportional to the remaining distance.

The allowable delay, or rather the technically possible delay depending on the motor and inertia of the load, is set here using the parameter DEC.

## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### Notification of the higher level control

Attainment of the target position is signalled by bit 10 "Target reached" in the statusword of the drive. If the transmission type for the TxPDO1 is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

#### Complex motion profiles

More complex motion profiles can be generated through appropriate presetting of new values (maximum speed, acceleration, end position) during positioning.

After a value change, simply execute a new motion start command (M).

The positioning range can be set using the command LL and activated using APL.

| Command | Argument | Function                            | Description   |
|---------|----------|-------------------------------------|---|
| LL      | Value    | Load Position Range Limits          | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower.<br>The range limits are only active if APL is 1.<br><b>Value: <math>-1.8 \cdot 10^9 \dots +1.8 \cdot 10^9</math></b> |
| APL     | 0 - 1    | Activate/Deactivate Position Limits | Activate range limits (LL) (valid for all operating modes except VOLTMOD).<br>1: Position limits activated<br>0: Position limits deactivated  |

## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### 3.6.2 Sinus commutation

The outstanding feature of FAULHABER motion controllers for brushless motors is their so-called sinus commutation. This means that the specified rotating field is always ideally positioned relative to the rotor. As a result, torque fluctuations can be reduced to a minimum, even at very low speeds. In addition, the motor runs particularly quietly.


The sinus commutation is further enhanced by so-called flat-top modulation, which enables more modulation. As a result, higher no-load speeds are possible.

The SIN0 command can even be used to set the system so that the sinus commutation switches to block commutation in the upper speed range. This full modulation enables the complete speed range of the motor to be utilised.

| Command | Function          | Description   |
|---------|-------------------|---|
| SIN     | Sinus commutation | 0: Full control (block mode with full control)<br>1: Limited to sinusoidal form (basic setting) |

#### 3.6.3 Current controller and I<sup>2</sup>t current limitation

##### Intervention of the current limiting controller



The FAULHABER Motion Controllers are equipped with an integral current controller, which enables torque limitation.

The current controller operates as a limitation controller. Depending on the previous loading, the I<sup>2</sup>t current limitation limits to the allowable peak current or continuous current. As soon as the motor current exceeds the currently allowed maximum value the current controller limits the voltage.

Due to its design as a current limiting controller, current control in the thermally relaxed state has no effect on the dynamic of the velocity control. The time response of this limitation can be adjusted using the parameter CI.

The default values for CI limit the current to the allowable value after around 5ms.

## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### Basic settings

| Command | Argument | Function                      | Description   |
|---------|----------|-------------------------------|---|
| LPC     | Value    | Load Peak Current Limit       | Load peak current<br>Value: 0 to 12 000 mA                  |
| LCC     | Value    | Load Continuous Current Limit | Load continuous current<br>Value: 0 to 12 000 mA            |
| CI      | Value    | Load Current Integral Term    | Load integral term for current controller<br>Value: 1...255 |


#### Mode of operation of the current controller

When the motor starts, the peak current is preset as the set-point for the current controller. As the load increases, the current in the motor constantly increases until it finally reaches the peak current. The current controller then comes into operation and limits the current to this set-point.

A thermal current model operating in parallel calculates a model temperature from the actually flowing current. If this model temperature exceeds a critical value, continuous current is switched to and the motor current is regulated to this. Only when the load becomes so small that the temperature falls below the critical model temperature is peak current permitted again.

The aim of this so-called  $I^2t$  current limiting is not to heat the motor above the thermally allowable temperature by selecting a suitable continuous current. On the other hand, a high load should be temporarily possible in order to enable very dynamic movements.

#### Function of the $I^2t$ current limitation



## 3 Operation in FAULHABER mode

### 3.6 Technical information

#### 3.6.4 Overtemperature protection

If the MOSFET temperature of the external controllers or the coil temperature of the drives with integrated controller exceeds a preset limit value, the motor is switched off. The following conditions must be fulfilled in order to reactivate the motor:

- Temperature below a preset limit value
- Target velocity set to 0 rpm
- Actual motor speed less than 50 rpm

#### NOTE



#### **Determining the coil temperature**

*The housing temperature is measured and the power loss concluded from the current measurement. The MOSFET or coil temperature is calculated from these values via a thermal model. In most applications, this method represents a thermal motor protection device.*

#### 3.6.5 Under-voltage monitoring

If the supply voltage falls below the lower voltage threshold, the power stage is switched off. The Motion Controller remains active. When the voltage returns within the permissible range, the power stage is switched on again immediately.

#### 3.6.6 Overvoltage regulation

If the motor is operated as a generator, it produces energy. Usually power supply units are not able to feed this energy back into the power line. For this reason, the supply voltage at the motor increases, and depending on the speed, the allowable maximum voltage may be exceeded.

In order to avoid irreparable damage to components, FAULHABER motion controllers for brushless motors contain a controller which adjusts the rotor displacement angle if a limit voltage (32 V) is exceeded. Motion controllers for DC motors contain a ballast circuit which is activated if a limit voltage (32 V) is exceeded. As a result, the energy generated in the motor is converted, and the voltage of the electronics remains limited to 32 V. This method protects the drive during generating operation and rapid braking.

#### 3.6.7 Adjustment of the controller parameters

The preset controller parameters must be optimised in order to optimally adjust the controller to the respective application.

#### NOTE



#### **Controller sampling rate**

*The digital controller operates at a sampling rate of 100  $\mu$ s. If necessary the sampling rate can be increased to up to 2 ms via the Sampling Rate Parameter.*



## 3 Operation in FAULHABER mode

### 3.6 Technical information

Default behaviour:

Without further settings, the gain set in the parameter POR is effective for the velocity controller.

In Positioning Mode the gain set via the parameter POR is increased within the target corridor by the value of the parameter PD. This enables faster adjustment to the stoppage in the target position without having to over-stimulate the controller during the transient phenomena. To this end, the parameter PD must be set carefully and should typically be a maximum of 50% of the base value POR; otherwise there is a risk of instability.

The following controller parameters are available:

| Command | Function                        | Description  |
|---------|---------------------------------|--|
| POR     | Load Velocity Proportional Term | Load velocity controller amplification.<br>Value: 1 – 255. |
| I       | Load Velocity Integral Term     | Load velocity controller integral term<br>Value: 1 – 255.  |
| PP      | Load Position Proportional Term | Load position controller amplification.<br>Value: 1 – 255. |
| PD      | Load Position D-Term            | Load position controller D-term.<br>Value: 1 – 255.        |
| SR      | Load Sampling Rate              | Sampling rate setting.<br>Value: 1 ... 20 ms/10            |

In the case of integrated units these values are already preset, however, they can be adjusted to the driving load using the Motion Manager's Motor Wizard. These values are suitably preassigned for external controls by selecting a motor type in the Motion Manager's Motor Wizard.

The controller tuning Wizard in Motion Manager can be used to further adjust several controller parameters, in order to optimally adjust the controller to the respective application.

#### Possible procedure

It is recommended that you begin with the default settings of the Motor Wizard and then further optimise the velocity controller first and then the position controller.

##### 1.) Optimise velocity controller:

Use, for example, the controller tuning Wizard to make velocity jumps between 1/3 and 2/3 of the maximum velocity and at the same time increase the controller gain POR gradually, until the controller becomes unstable. The controller gain must then be reduced again until reliable stability exists. Under certain circumstances it may be necessary to optimise the integral term I accordingly.

##### 2.) Optimise position controller:

Specify appropriate motion profiles for the application, e.g. using the controller tuning Wizard. If the system does not function stably with these settings, stability can be achieved by reducing the I term of the velocity controller or reducing the P term of the position controller. Then increase the P term of the position controller gradually up to the system's stability limit. The stability can then be restored, either by increasing the D term of the position controller or by reducing the I term of the velocity controller.

## 3 Operation in FAULHABER mode

---

### 3.6 Technical information

#### Special mode for position control

The SR command can be used to activate a special position control mode (Gain Scheduling). To this end, the value 100 must be added to the required SR setting.

**Example:**

Required setting SR10 with special mode: **SR110**.

If this mode is activated, the parameter POR is successively reduced in a position-controlled application as soon as the drive is within the target corridor (can be set using the CORRIDOR command). This enables much "gentler" stoppage to be achieved in the target position. As soon as the drive leaves the target corridor, POR is immediately increased back to the set value.

**NOTE**



*The "Gain Scheduling" function only becomes active at sampling rates with a factor larger than 3 (sampling rate > 3).*

## 4 CANopen protocol description

---

### Guide

|                                  |         |
|----------------------------------|---------|
| Introduction                     | Page 59 |
| PDOs (process data objects)      | Page 61 |
| SDO (service data object)        | Page 63 |
| Emergency Object (error message) | Page 65 |
| SYNC object                      | Page 66 |
| NMT (network management)         | Page 67 |
| Entries in the object dictionary | Page 70 |

### 4.1 Introduction

- CANopen is a standardised software protocol based on the CAN hardware (Controller Area Network).
- The international CAN Organisation CAN in Automation e.V. (CiA) defines the communication profile in DS301 (Description of the communication structure and methods for parameter access, control and monitoring functions).
- Device profiles are specified for the different devices, such as DSP402 for drives and DS401 for I/O devices (general device description from the view of the user).
- Public data is managed using the object dictionary (Parameter table, access to entries via Index and Subindex).
- There are two data communication objects:
  - PDOs (Process data objects for control and monitoring)
  - SDOs (Service data objects for access to the object dictionary)
- Further objects are available for network management, node monitoring and synchronisation.
- CANopen supports up to 127 nodes per network segment with transmission rates up to 1 MBit/s.
- The communication is message based, each communication object is assigned its own 11 bit identifier.

## 4 CANopen protocol description

---

### 4.1 Introduction

FAULHABER Motion Controllers support the CANopen communication profile in accordance with CiA DS301 V4; the following communication objects are supported:

- 3 transmit PDOs
- 3 receive PDOs
- 1 server SDO
- 1 emergency object
- NMT with Node Guarding
- 1 SYNC object

The identifier configuration of the CANopen objects is defined according to the “Predefined Connection Set” (see [Chapter 4.6 “NMT \(network management\)”](#)). Data assignment of the PDOs is permanently preset (static PDO mapping).

Many manufacturers offer CANopen libraries for PC and PCS systems, via which the individual objects can be conveniently accessed, without having to worry about the internal structure.

The FAULHABER Motion Manager also enables easy access to the individual objects via a graphic user interface.

## 4 CANopen protocol description

### 4.2 PDOs (process data objects)

PDOs correspond to a CAN message frame with up to 8 bytes and are used to transmit process data, i.e. to control and monitor the device's behaviour. The PDOs are designated from the point of view of the field device. Receive PDOs (RxPDOs) are received by the field device and contain, e.g. control data, send PDOs (TxPDOs) are sent by the field device and contain, e.g. monitoring data.

PDOs can only be transmitted if the device is in "Operational" state (see [Chapter 4.6 "NMT \(network management\)"](#)).

PDO communication types:

- Event controlled: Data are automatically sent following a change to the device.
- Remote Request (RTR): Data are sent following a request message frame.
- Synchronised: Data are sent following receipt of a SYNC object, see [Chapter 4.5 "SYNC object"](#).

FAULHABER Motion Controllers provide the following PDOs:

- Receive PDO1: Controlword according to DSP402
- Send PDO1: Statusword according to DSP402
- Receive PDO2: FAULHABER command
- Send PDO2: FAULHABER query data (RTR)
- Receive PDO3: FAULHABER trace configuration
- Send PDO3: FAULHABER trace data (RTR)

#### RxPDO1: *Controlword*

| 11 bit identifier      | 2 bytes user data |    |
|------------------------|-------------------|----|
| 0x200 (512d) + Node ID | LB                | HB |

Contains the 16 bit controlword according to CiA DSP402, which controls the state machine of the drive unit. The PDO refers to object index 0x6040 in the object dictionary. The bit allocation is described in [Chapter 6.1 "Device Control"](#).

#### TxPDO1: *Statusword*

| 11 bit identifier      | 2 bytes user data |    |
|------------------------|-------------------|----|
| 0x180 (384d) + node ID | LB                | HB |

Contains the 16 bit controlword according to CiA DSP402, which displays the state machine of the drive unit. The PDO refers to object index 0x6041 in the object dictionary. The bit allocation is described in [Chapter 6.1 "Device Control"](#).

#### RxPDO2: FAULHABER Command

| 11 bit identifier      | 5 bytes user data |     |     |     |     |
|------------------------|-------------------|-----|-----|-----|-----|
| 0x300 (768d) + Node-ID | Cmd               | LLB | LHB | HLB | HHB |

Is made available by the FAULHABER channel for transmission of manufacturer-specific commands. All the parameters and control commands of the drive unit can be transmitted with the help of this PDO. Transmissions are always 5 bytes long, whereby the first byte gives the command and the following 4 bytes give the argument as a long integer value. A description of the commands is given in [Chapter 8.4 "FAULHABER commands"](#).

## 4 CANopen protocol description

### 4.2 PDOs (process data objects)

#### TxPDO2: FAULHABER Data

| 11 bit identifier      | 6 bytes user data |     |     |     |     |       |
|------------------------|-------------------|-----|-----|-----|-----|-------|
| 0x280 (640d) + Node-ID | Cmd               | LLB | LHB | HLB | HHB | Error |

FAULHABER Channel for query commands. A request (RTR) on this PDO returns the data requested with the previously sent command. Transmissions are always 6 bytes long, whereby the first byte gives the command and the following 4 bytes give the required value as a long integer followed by an error code. The error byte can also be used to check whether a send command was successfully executed or not (1 = command successfully executed, for further error codes see [Chapter 8.4 "FAULHABER commands"](#)).

#### RxPDO3: Trace Configuration

| 11 bit identifier       | 5 bytes user data |        |    |         |        |
|-------------------------|-------------------|--------|----|---------|--------|
| 0x400 (1024d) + node ID | Mode 1            | Mode 2 | TC | Packets | Period |

This PDO is used to set the trace mode, via which the internal parameters can be quickly read out.

The data configuration looks like this:

Byte 0: Mode for Parameter 1

Byte 1: Mode for Parameter 2

Byte 2: Transfer with time code [1/0]

Byte 3: Number of packets to be transmitted per request (Default: 1)

Byte 4: Time interval between packets (Default: 1 ms)

The possible operating modes for Parameters 1 and 2 are described in [Chapter 5.2 "Trace"](#).

#### TxPDO3: Trace Data

| 11 bit identifier      | 3 to 8 byte user data |       |       |       |       |       |       |       |
|------------------------|-----------------------|-------|-------|-------|-------|-------|-------|-------|
| 0x380 (896d) + Node-ID | Data0                 | Data1 | Data2 | Data3 | Data4 | Data5 | Data6 | Data7 |

A request (RTR) on this PDO returns the trace data according to the setting made via RxPDO3 (see [Chapter 5.2 "Trace"](#)).

## 4 CANopen protocol description

### 4.3 SDO (service data object)

The service data object can be used to read and describe parameters in the object dictionary (OD). They are accessed via the 16 bit index and the 8 bit subindex. The Motion Controller functions as a server, i.e. it makes data available (upload) at the request of the client (PC, PCS) (Upload) or receives data from the client (download).

| Byte0             | Byte1-2      | Byte3          | Byte4                   |
|-------------------|--------------|----------------|-------------------------|
| Command Specifier | 16 bit index | 8 bit subindex | 1-4 byte parameter data |

→ Entry in the object dictionary

A differentiation is made between 2 SDO transfer types:

- Expedited transfer: Transfer of 4 bytes maximum
- Segmented transfer: Transfer of more than 4 bytes

As, apart from for query of the version and the device name, only 4 bytes maximum are transferred by the FAULHABER Motion Controllers, only the expedited transfer is described in the following.

The size of the message frames is always 8 bytes and their structure is as follows:

Read OD entries: Client → Server, Upload Request

| 11 bit identifier       | 8 bytes user data |          |          |          |   |   |   |   |
|-------------------------|-------------------|----------|----------|----------|---|---|---|---|
| 0x600 (1536d) + Node-ID | 0x40              | Index LB | Index HB | Subindex | 0 | 0 | 0 | 0 |

Server → Client, Upload Response

| 11 bit identifier       | 8 bytes user data |          |          |          |          |          |          |          |
|-------------------------|-------------------|----------|----------|----------|----------|----------|----------|----------|
| 0x580 (1408d) + Node-ID | 0x4x              | Index LB | Index HB | Subindex | LLB (D0) | LHB (D1) | HLB (D2) | HHB (D3) |

Byte0 (0x4x) gives the number of valid data bytes in D0-D3 and the transfer type and is coded for expedited transfer ( $\leq 4$  data bytes) as follows:

- 1 data byte in D0: Byte0 = 0x4F
- 2 data bytes in D0-D1: Byte0 = 0x4B
- 3 data bytes in D0-D2: Byte0 = 0x47
- 4 data bytes in D0-D3: Byte0 = 0x43

Write OD entries: Client → Server, Download Request

| 11 bit identifier       | 8 bytes user data |          |          |          |          |          |          |          |
|-------------------------|-------------------|----------|----------|----------|----------|----------|----------|----------|
| 0x600 (1536d) + Node-ID | 0x2x              | Index LB | Index HB | Subindex | LLB (D0) | LHB (D1) | HLB (D2) | HHB (D3) |

Byte0 (0x2x) gives the number of valid data bytes in D0-D3 and the transfer type and is coded for expedited transfer ( $\leq 4$  data bytes) as follows:

- 1 data byte in D0: Byte0 = 0x2F
- 2 data bytes in D0-D1: Byte0 = 0x2B
- 3 data bytes in D0-D2: Byte0 = 0x27
- 4 data bytes in D0-D3: Byte0 = 0x23

If it is not necessary to specify the number of data bytes: Byte0 = 0x22

Server → Client, Download Response

| 11 bit identifier       | 8 bytes user data |          |          |          |   |   |   |   |
|-------------------------|-------------------|----------|----------|----------|---|---|---|---|
| 0x580 (1407d) + node ID | 0x60              | Index LB | Index HB | Subindex | 0 | 0 | 0 | 0 |

## 4 CANopen protocol description

### 4.3 SDO (service data object)

Termination of the SDO protocols in the event of an error:

Client → Server

| 11 bit identifier       | 8 bytes user data |          |          |          |        |        |        |        |
|-------------------------|-------------------|----------|----------|----------|--------|--------|--------|--------|
| 0x600 (1536d) + Node-ID | 0x80              | Index LB | Index HB | Subindex | Error0 | Error1 | Error2 | Error3 |

Server → Client

| 11 bit identifier       | 8 bytes user data |          |          |          |        |        |        |        |
|-------------------------|-------------------|----------|----------|----------|--------|--------|--------|--------|
| 0x580 (1408d) + Node-ID | 0x80              | Index LB | Index HB | Subindex | Error0 | Error1 | Error2 | Error3 |

Error3 Error class

Error2: Error code

Error1: Additional error code HB

Error0: Additional error code LB

| Error class | Error code | Additional code | Description  |
|-------------|------------|-----------------|--|
| 0x05        | 0x03       | 0x0000          | Toggle bit unchanged   |
| 0x05        | 0x04       | 0x0001          | SDO Command Specifier invalid or unknown                           |
| 0x06        | 0x01       | 0x0000          | Access to this object is not supported                             |
| 0x06        | 0x01       | 0x0002          | Attempt to write on a Read_Only parameter                          |
| 0x06        | 0x02       | 0x0000          | Object does not exist in the object dictionary                     |
| 0x06        | 0x04       | 0x0041          | Object cannot be mapped in PDO                                     |
| 0x06        | 0x04       | 0x0042          | Number and/or length of the mapped objects would exceed PDO length |
| 0x06        | 0x04       | 0x0043          | General parameter incompatibility                                  |
| 0x06        | 0x04       | 0x0047          | General internal error in the device                               |
| 0x06        | 0x06       | 0x0000          | Access cancelled due to hardware fault                             |
| 0x06        | 0x07       | 0x0010          | Data type or parameter length do not match or are unknown          |
| 0x06        | 0x07       | 0x0012          | Data type does not match, parameter length is too large            |
| 0x06        | 0x07       | 0x0013          | Data type does not match, parameter length is too short            |
| 0x06        | 0x09       | 0x0011          | Subindex not available   |
| 0x06        | 0x09       | 0x0030          | General value range error  |
| 0x06        | 0x09       | 0x0031          | Value range error: Parameter value too large                       |
| 0x06        | 0x09       | 0x0032          | Value range error: Parameter value too small                       |
| 0x06        | 0x0A       | 0x0023          | Resource not available   |
| 0x08        | 0x00       | 0x0021          | Access not possible due to local application                       |
| 0x08        | 0x00       | 0x0022          | Access not possible due to current device status                   |



## 4 CANopen protocol description

### 4.4 Emergency Object (error message)

The emergency object informs other bus devices of errors that have occurred.

The size of the Emergency Object is always 8 bytes and its structure is as follows:

| 11 bit identifier     | 8 bytes user data |             |            |   |   |   |   |   |
|-----------------------|-------------------|-------------|------------|---|---|---|---|---|
| 0x80 (128d) + Node-ID | Error0 (LB)       | Error1 (HB) | Error reg. | 0 | 0 | 0 | 0 | 0 |

The first two bytes contain the 16 bit error code, the third byte contains the error register (content of object 0x1001), bytes 4 and 5 contain the 16 bit FAULHABER error register (content of object 0x2320), the remaining bytes are unused (always 0).

The error register identifies the error type. The individual error types are bit coded and are assigned the respective error codes in the following table. The object 0x1001 can be used to query the last value of the error register.

The following error code table lists all errors reported by emergency message frames, provided the corresponding error is set in the emergency mask for the FAULHABER error register. Only those errors for which an emergency mask is given in this table are reported.

#### Emergency error codes

| Error code | Meaning                               | Emergency mask | Error register bit |
|------------|---------------------------------------|----------------|--------------------|
| 0x0000     | no error                              |                |                    |
| 0x1000     | generic error                         |                | 0                  |
| 0x2000     | current                               |                |                    |
| 0x2300     | current, device output side           |                |                    |
| 0x2310     | continuous over current               | 0x0001         | 1                  |
| 0x3000     | voltage                               |                |                    |
| 0x3200     | voltage inside the device             |                |                    |
| 0x3210     | over voltage                          | 0x0004         | 2                  |
| 0x4000     | temperature                           |                |                    |
| 0x4300     | drive temperature                     |                |                    |
| 0x4310     | over temperature                      | 0x0008         | 3                  |
| 0x5000     | device hardware                       |                |                    |
| 0x5500     | data storage                          |                |                    |
| 0x5530     | flash memory error                    | 0x0010         | 5                  |
| 0x6000     | device software                       |                |                    |
| 0x6100     | internal software                     | 0x1000         | 5                  |
| 0x8000     | monitoring                            |                |                    |
| 0x8100     | communication                         |                |                    |
| 0x8130     | life guard error                      | 0x0100         | 4                  |
| 0x8140     | recovered from bus off                | 0x0200         | 4                  |
| 0x8400     | velocity speed controller (deviation) | 0x0002         | 5                  |
| 0x8600     | positioning controller                |                |                    |
| 0x8611     | following error (deviation)           | 0x0002         | 5                  |

Example:

If 0x2320 is set in the FAULHABER error register under Subindex 2 Bit 1, an emergency message frame with 8 data bytes 0x10 0x23 0x01 0x00 0x00 0x00 0x00 0x00 is sent if the current limitation value set using LCC was exceeded for longer than the error delay time set with DCE.

#### Error Register

| Bit | Meaning                                    |
|-----|--|
| 0   | Generic error                              |
| 1   | Current                                    |
| 2   | Voltage                                    |
| 3   | Temperature                                |
| 4   | Communication error (overrun, error state) |
| 5   | Device profile specific                    |
| 6   | Reserved (always 0)                        |

## 4 CANopen protocol description

### 4.5 SYNC object

The SYNC object is a short message frame without data content, which is used to trigger synchronous PDOs and therefore enables quasi simultaneous starting of processes on different devices.

The identifier of the SYNC object can be set in the object dictionary under Index 0x1005 (Default: 0x80).

|                          |                     |
|--------------------------|---------------------|
| <b>11 bit identifier</b> | <b>No user data</b> |
| 0x80                     |                     |

Whether a PDO is to be triggered by a SYNC object or not can be set using the transmission type in the Communication Parameter objects of the corresponding PDO (see [Chapter 8.1 "Communication objects according to CiA 301"](#)).

A differentiation is made between the following PDO transmission types:

| Transmission type | Meaning   |
|-------------------|---|
| 255               | asynchronous (event controlled)   |
| 253               | asynchronous, only on request (RTR)   |
| 252               | synchronous, only on request (RTR)<br>PDO is only sent on request following a SYNC object   |
| 1 – 240           | synchronous, cyclical<br>PDO is repeatedly sent following a SYNC object The given value simultaneously represents the number of SYNC objects which have to have been received before the PDO is sent again (1 = PDO is sent with each SYNC object). |
| 0                 | synchronous, acyclic<br>PDO is sent or executed once following a SYNC object, if it has changed its content (new parameter query or status change)  |

#### Synchronous receive PDO:

The command transmitted with the PDO is not executed until the SYNC objects is received. In this way, e.g. several axles can be synchronised with each other.


#### NOTE

*In the case of RxPDOs, the transmission types 1-240 are identical to transmission type 0.*



#### Synchronous transmit PDO:

After receiving a SYNC object, the PDO is sent as quickly as possible with the current data (Synchronous Window Length = 0):



#### NOTE

*Transmission types 1-240 can also be used to group nodes.*



## 4 CANopen protocol description

### 4.6 NMT (network management)

After switching on and initialisation has been successfully performed, the FAULHABER Motion Controllers are automatically in the “Pre-Operational” state. Apart from via NMT messages, in this state it is only possible to communicate with the device via service data objects (SDOs), to make or query parameter settings. FAULHABER Motion Controllers are delivered complete with useful default settings for all objects; therefore, in general it is not necessary to assign parameters with the system start. Necessary parameter settings are usually performed once, e.g. with the help of the FAULHABER Motion Manager and are then permanently stored in the data flash. These settings are then immediately available following the system start.

A single CAN message is sufficient to start a CANopen device:

Start Remote Node:

| 11 bit identifier | 2 bytes user data |         |
|-------------------|-------------------|---------|
| 0x000             | 0x01              | Node-ID |


Or, to start the whole network:

Start All Remote Nodes:

| 11 bit identifier | 2 bytes user data |      |
|-------------------|-------------------|------|
| 0x000             | 0x01              | 0x00 |

The devices are then in “Operational” state. The device is now fully functional and can be operated via PDOs.

The state diagram is given in the following:



- (1) At Power on the initialisation state is entered autonomously
- (2) Initialisation finished – enter PRE-OPERATIONAL automatically
- (3), (6) Start\_Remote\_Node indication
- (4), (7) Enter PRE-OPERATIONAL\_State indication
- (5), (8) Stop\_Remote\_Node indication
- (9), (10), (11) Reset\_Node indication
- (12), (13), (14) Reset\_Communication indication

In the “Stopped” (“Prepared”) state, the device is in the error state and can no longer be operated using SDO and PDOs. Only NMT messages are received, to cause a state change. State changes can be performed with the help of the NMT services:

An NMT message frame always consists of 2 bytes on the identifier 0x000:

| 11 bit identifier | 2 bytes user data |         |
|-------------------|-------------------|---------|
| 0x000             | CS                | Node-ID |

CS: Command Specifier

Node-ID: Node address (0 = all nodes)

## 4 CANopen protocol description

### 4.6 NMT (network management)

The possible values for the Command Specifier CS are listed in the following table:

| State transition | Command Specifier CS | Explanation   |
|------------------|----------------------|---|
| (1)              | –                    | The initialisation status is reached autonomously on switching on.  |
| (2)              | –                    | Following initialisation the pre-operational status is reached automatically, at the same time the boot-up message is sent. |
| (3), (6)         | CS = 0x01 (1d)       | Start_Remote_Node. Starts the device and releases the transmission of PDOs.   |
| (4), (7)         | CS = 0x80 (128d)     | Enter_Pre-Operational. Stops the PDO transmission, SDO continues to be active.  |
| (5), (8)         | CS = 0x02 (2d)       | Stop_Remote_Node. Device changes to error state, SDO and PDO are switched off.  |
| (9), (10), (11)  | CS = 0x81 (129d)     | Reset_Node. Performs a reset. All objects are reset to power-on defaults.   |
| (12), (13), (14) | CS = 0x82 (130d)     | Reset_Communication. Resets the communication functions.  |

#### Boot-Up Message:

Following the initialisation phase, the FAULHABER Motion Controller sends the Boot-Up Message, a CAN message with one data byte (Byte0 = 0x00) on the identifier of the node guarding message (0x700 + Node ID):j


| 11 bit identifier       | 1 bytes user data |
|-------------------------|-------------------|
| 0x700 (1792d) + Node ID | 0x00              |

The boot-up message signals the end of the initialisation phase of a newly activated module, which can then be configured or started.

#### Node guarding / life guarding:

The node guarding object can be used to query the momentary state of the device. To do this, by setting a remote frame, the master sends a request (request message frame) on the guarding identifier of the node to be monitored. This then replies with the guarding message, which contains the current status of the node and a toggle bit.

The following diagram describes the node guarding protocol:



t: Toggle bit. Initially 0, changes its value in each guarding message frame.

s: Status:

s = 0x04 (4d): Stopped

s = 0x05 (5d): Operational

s = 0x7F (127d): Pre-operational

If a node life time > 0 is set (objects 0x100C and 0x100D), a life-guarding-error is set, if no more node guarding queries of the master arrive within the given life time (life-guarding).


The response to a Life Guarding error can be set via the FAULHABER error register (Object 0x2320). Otherwise, by default, no action is performed.

## 4 CANopen protocol description

### 4.6 NMT (network management)

Identifier distribution:

CANopen provides default identifiers in the "Predefined Connection Set" for the most important objects. These are made up of a 7 bit node address (Node-ID) and a 4 bit function code in accordance with the following schema:



FAULHABER Motion Controller only operate with these default identifiers:

| Object | Function code (binary) | Resulting COB-ID | Communication Parameters at Index |
|--------|------------------------|------------------|-----------------------------------|
| NMT    | 0000                   | 0                | -                                 |
| SYNC   | 0001                   | 128 (80h)        | 1005h                             |

| Object            | Function code (binary) | Resulting COB-ID          | Communication Parameters at Index |
|-------------------|------------------------|---------------------------|-----------------------------------|
| EMERGENCY         | 0001                   | 129 (81h) – 255 (FFh)     | 1014h                             |
| PDO1 (tx)         | 0011                   | 385 (181h) – 511 (1FFh)   | 1800h                             |
| PDO1 (rx)         | 0100                   | 513 (201h) – 639 (27Fh)   | 1400h                             |
| PDO2 (tx)         | 0101                   | 641 (281h) – 767 (2FFh)   | 1801h                             |
| PDO2 (rx)         | 0110                   | 769 (301h) – 895 (37Fh)   | 1401h                             |
| PDO3 (tx)         | 0111                   | 897 (381h) – 1023 (3FFh)  | 1802h                             |
| PDO3 (rx)         | 1000                   | 1025 (401h) – 1151 (47Fh) | 1402h                             |
| SDO (tx)          | 1011                   | 1409 (581h) – 1535 (5FFh) | 1200h                             |
| SDO (rx)          | 1100                   | 1537 (601h) – 1663 (67Fh) | 1200h                             |
| NMT Error Control | 1110                   | 1793 (701h) – 1919 (77Fh) |                                   |

## 4 CANopen protocol description

### 4.7 Entries in the object dictionary

The configuration parameters are managed in the CANopen object dictionary. The object dictionary is divided into three areas:

1. Communication parameters (Index 0x1000 – 0x1FFF)
2. Manufacturer specific area (Index 0x2000 – 0x5FFF)
3. Standardised device profiles (0x6000 – 0x9FFF)

The 1<sup>st</sup> area contains the objects according to DS301, the 2<sup>nd</sup> area is reserved for manufacturer-specific objects and the 3<sup>rd</sup> area contains the objects according to DSP402 supported by the FAULHABER Motion Controllers.

Each object can be referenced via its index and subindex (SDO protocol).

#### Overview of the available objects:

a.) Communication objects according to DS301:

| Index                                       | Object | Name                                       | Type           | Attribute |
|---|--------|--|----------------|-----------|
| 0x1000                                      | VAR    | device type                                | UNSIGNED32     | ro        |
| 0x1001                                      | VAR    | error register                             | UNSIGNED8      | ro        |
| 0x1003                                      | ARRAY  | pre-defined error field                    | UNSIGNED32     | rw        |
| 0x1005                                      | VAR    | COB-ID SYNC                                | Unsigned32     | rw        |
| 0x1008                                      | VAR    | manufacturer device name                   | Vis-String     | const     |
| 0x1009                                      | VAR    | manufacturer hardware version              | Vis-String     | const     |
| 0x100A                                      | VAR    | manufacturer software version              | Vis-String     | const     |
| 0x100C                                      | VAR    | guard time                                 | UNSIGNED16     | rw        |
| 0x100D                                      | VAR    | life time factor                           | UNSIGNED8      | rw        |
| 0x1010                                      | ARRAY  | store parameters                           | UNSIGNED32     | rw        |
| 0x1011                                      | ARRAY  | restore default parameters                 | UNSIGNED32     | rw        |
| 0x1014                                      | VAR    | COB-ID EMCY                                | UNSIGNED32     | ro        |
| 0x1018                                      | RECORD | identity object                            | Identity (23h) | ro        |
| <b>Server SDO Parameter</b>                 |        |  |                |           |
| 0x1200                                      | RECORD | 1 <sup>st</sup> server SDO parameter SDO   | SDOParameter   | ro        |
| <b>Receive PDO Communication Parameter</b>  |        |  |                |           |
| 0x1400                                      | RECORD | 1 <sup>st</sup> receive PDO parameter PDO  | PDOCommPar     | rw        |
| 0x1401                                      | RECORD | 2 <sup>nd</sup> receive PDO parameter PDO  | PDOCommPar     | rw        |
| 0x1402                                      | RECORD | 3 <sup>rd</sup> receive PDO Parameter PDO  | PDOCommPar     | rw        |
| <b>Receive PDO Mapping Parameter</b>        |        |  |                |           |
| 0x1600                                      | RECORD | 1 <sup>st</sup> receive PDO mapping PDO    | PDOMapping     | ro        |
| 0x1601                                      | RECORD | 2 <sup>nd</sup> receive PDO mapping PDO    | PDOMapping     | ro        |
| 0x1602                                      | RECORD | 3 <sup>rd</sup> receive PDO mapping PDO    | PDOMapping     | ro        |
| <b>Transmit PDO Communication Parameter</b> |        |  |                |           |
| 0x1800                                      | RECORD | 1 <sup>st</sup> transmit PDO parameter PDO | PDOCommPar     | rw        |
| 0x1801                                      | RECORD | 2 <sup>nd</sup> transmit PDO parameter PDO | PDOCommPar     | rw        |
| 0x1802                                      | RECORD | 3 <sup>rd</sup> transmit PDO parameter PDO | PDOCommPar     | rw        |
| <b>Transmit PDO Mapping Parameter</b>       |        |  |                |           |
| 0x1A00                                      | RECORD | 1 <sup>st</sup> transmit PDO mapping PDO   | PDOMapping     | ro        |
| 0x1A01                                      | RECORD | 2 <sup>nd</sup> transmit PDO mapping PDO   | PDOMapping     | ro        |
| 0x1A02                                      | RECORD | 3 <sup>rd</sup> transmit PDO mapping PDO   | PDOMapping     | ro        |

## 4 CANopen protocol description

### 4.7 Entries in the object dictionary

b.) Drive profile objects according to DSP402:

| Index  | Name                           | Type             | Attribute | Meaning                            |
|--------|--------------------------------|------------------|-----------|------------------------------------|
| 0x6040 | controlword                    | Unsigned16       | rw        | Drive control                      |
| 0x6041 | statusword                     | Unsigned16       | ro        | Status display                     |
| 0x6060 | modes of operation             | Integer8         | wo        | Operating mode changeover          |
| 0x6061 | modes of operation display     | Integer8         | ro        | Set operating mode                 |
| 0x6062 | position demand value          | Integer32        | ro        | Last target position scaled        |
| 0x6063 | position actual value          | Integer32        | ro        | Actual position in increments      |
| 0x6064 | position actual value          | Integer32        | ro        | Actual position scaled             |
| 0x6067 | position window                | Unsigned32       | rw        | Target position window             |
| 0x6068 | position window time           | Unsigned16       | rw        | Time in target position window     |
| 0x6069 | velocity actual sensor value   | Integer32        | ro        | Current speed value                |
| 0x606B | velocity demand value          | Integer32        | ro        | Target velocity                    |
| 0x606C | velocity actual value          | Integer32        | ro        | Current speed value                |
| 0x606D | velocity window                | Unsigned16       | rw        | End speed window                   |
| 0x606E | velocity window time           | Unsigned16       | rw        | Time in end speed window           |
| 0x606F | velocity threshold             | Unsigned16       | rw        | Speed threshold value              |
| 0x6070 | velocity threshold time        | Unsigned16       | rw        | Time below speed threshold value   |
| 0x607A | target position                | Integer32        | rw        | Target position                    |
| 0x607C | homing offset                  | Integer32        | rw        | Reference point offset             |
| 0x607D | software position limit        | ARRAY Integer32  | rw        | Area limits                        |
| 0x607E | polarity                       | Unsigned8        | rw        | Polarity (direction of rotation)   |
| 0x607F | max profile velocity           | Unsigned32       | rw        | Maximum speed                      |
| 0x6081 | profile velocity               | unsigned32       | rw        | Maximum speed                      |
| 0x6083 | profile acceleration           | Unsigned32       | rw        | Acceleration value                 |
| 0x6084 | profile deceleration           | Unsigned32       | rw        | Braking ramp value                 |
| 0x6085 | quick stop deceleration        | Unsigned32       | rw        | Quick stop braking ramp value      |
| 0x6086 | motion profile type            | Integer16        | ro        | Motion profile                     |
| 0x608F | position encoder resolution    | ARRAY Unsigned32 | rw        | Resolution of the external encoder |
| 0x6093 | position factor                | ARRAY Unsigned32 | rw        | Position factor                    |
| 0x6096 | velocity factor                | ARRAY Unsigned32 | rw        | Speed factor                       |
| 0x6097 | acceleration factor            | ARRAY Unsigned32 | rw        | Acceleration factor                |
| 0x6098 | homing method                  | Integer8         | rw        | Homing method                      |
| 0x6099 | homing speed                   | ARRAY Unsigned32 | rw        | Homing speed                       |
| 0x609A | homing acceleration            | Unsigned32       | rw        | Homing acceleration                |
| 0x60F9 | velocity control parameter set | ARRAY Unsigned16 | rw        | Parameters for speed controller    |
| 0x60FA | control effort                 | Integer32        | ro        | Controller output                  |
| 0x60FB | position control parameter set | ARRAY Unsigned16 | rw        | Parameters for position controller |
| 0x60FC | position demand value          | Integer32        | ro        | Last target position in increments |
| 0x60FF | target velocity                | Integer32        | rw        | Target velocity                    |
| 0x6510 | drive data                     | RECORD           | rw        | Drive information                  |

A detailed description of the individual objects is given in [Chapter 8 "Parameter description"](#).

## 5 Extended CAN functions

### 5.1 The FAULHABER channel

A special FAULHABER channel is available on, which can be used to execute all the Motion Controller's commands in a simple way.

A corresponding CAN message frame is available for each FAULHABER command, with which the CAN unit can be operated analogous to the serial version. All the functions and parameters of the drive unit can be activated using this channel.

[Chapter 8.4 "FAULHABER commands"](#) contains the complete description of the FAULHABER commands.

### 5.2 Trace

PDO3 can be used to trace operating data, i.e. to read it out online with a resolution of up to 1 ms. After the required trace type has been set using RxPDO3, the values can be requested consecutively by requests on TxPDO3 (see [Chapter 4.2 "PDOs \(process data objects\)"](#)).

#### Trace configurations:

RxPDO3:

| Byte | Function   |
|------|--|
| 0    | Mode for Parameter 1   |
| 1    | Mode for Parameter 2<br>255 = No second parameter                          |
| 2    | Transmission with time code<br>1 = with time code<br>0 = without time code |
| 3    | Number of data packets to be transmitted per request<br>Default: 1         |
| 4    | Time interval between packets [ms]<br>Default: 1                           |

The following values are available for Parameter 1 and 2:

- 0: Actual velocity [Integer16, rpm]
- 1: Target velocity [Integer16, rpm]
- 2: Controller output [Integer16]
- 4: Motor current [Integer16, mA]
- 44: Housing temperature [Unsigned16, °C]
- 46: Coil temperature [Unsigned16, °C]
- 200: Current position [Integer32, Inc]
- 201: Target position [Integer32, Inc]

#### Data request:

Depending on the mode set for Parameter 1 and 2, following a request (RTR) on TxPDO3, 3 to 8 bytes are returned on TxPDO3:

- 1.) Mode 1 between 0 and 15,  
Mode 2 at 255 (inactive)
- 3 byte ... 1<sup>st</sup> byte: Low byte data  
2<sup>nd</sup> byte: High byte data  
3<sup>rd</sup> byte: Timer code

The data are in Integer16 format.



## 5 Extended CAN functions

### 5.2 Trace

2.) Mode 1 between 16 and 199,  
Mode 2 at 255 (inactive)

→ 3 bytes ... Coding as for 1.)

The data are in Unsigned16 format.

3.) Mode 1 between 200 and 255,  
Mode 2 at 255 (inactive)

→ 5 byte ... 1<sup>st</sup> byte: Lowest byte data  
2<sup>nd</sup> byte: Second byte data  
3<sup>rd</sup> byte: Third byte data  
4<sup>th</sup> byte: Highest byte data  
5<sup>th</sup> byte: Time code

The data are in Integer32 format.

4.) Mode1 corresponding to 1.), 2.) or 3.) and  
Mode 2 less than 255:

|                    |                          |                     |
|--------------------|--------------------------|---------------------|
| → 5 to 8 bytes ... | Byte 1 to 2 (4):         | Data bytes of Mode1 |
|                    | Byte 3 (5) to 4 (6) (8): | Data bytes of Mode2 |
|                    | Byte 5 (7):              | Time code           |

The data bytes of Mode2 are coded as for Mode1.

The time code corresponds to a multiple of the time basis of 1 ms and defines the time interval to the last transmission. If two Integer32 parameters are requested, there is no more space for the time code in the CAN message frame; configuration parameter 2 must therefore be set to 0 (transmission without time code). The time must then be measured in the master.

#### NOTE



*The trace data can also be read out using a SYNC object instead of via RTR. To do this, the transmission type of TxPDO3 in object 0x1802 must be set to a synchronous transmission type (see [Chapter 4.5 "SYNC object"](#)). In this way, data can be simultaneously read out from several nodes.*

#### Example:

Record the actual position and motor current of node 1.

a.) Set trace configuration

Transmit ID 401: C8 04 01 01 01

b.) Data request

Request ID 381

c.) Answer

Receive ID 381: 10 27 00 00 32 00 03

→ Byte 1 to 4: Position 10 000  
Byte 5 to 6: Motor current 50 mA  
Byte 7: Timecode 3 ms

Further data can be requested by means of renewed requests on ID 381.

## 6 Functional description of the CANopen CiA 402

---

### Guide

|   |         |
|---|---------|
| Device Control                                      | Page 75 |
| Factor Group  | Page 80 |
| Profile Position Mode and Position Control Function | Page 82 |
| Homing Mode   | Page 87 |
| Profile Velocity Mode                               | Page 91 |
| Drive parameters/Common entries                     | Page 94 |
| Inputs/Outputs                                      | Page 95 |
| Error handling                                      | Page 97 |

The CANopen device profile for drives and Motion Control applications (CiA 402) of the CANopen user organisation CAN in Automation (CiA) is based on the general CANopen protocol description CiA 301 as described in Chapter 4.


Communication with the drive takes place via the mechanisms described there. Before the drive can be addressed the baud rate must be set and a node number assigned to the CAN node. In addition, the underlying CANopen node must be activated using the network management (NMT) (see [Chapter 4.6 "NMT \(network management\)"](#)).

## 6 Functional description of the CANopen CiA 402


### 6.1 Device Control

FAULHABER Motion Control systems support “Device Control” from the CiA 402 profile and the “Profile Position Mode”, “Profile Velocity Mode” and “Homing Mode” operating modes.

#### 6.1.1 State machine of the drive



The drive behaviour is mapped in CANopen via a state machine. The states can be controlled with the controlword and displayed with the status-word:



After switching on and the initialisation has been successfully performed, the FAULHABER drive is immediately in “Switch On Disabled” state. At the same time, transitions 0 and 1 are run through autonomously.

A change in state within the state machine of the drive according to CiA 402 cannot be made until the underlying CANopen node is in the “Operational” state (see [Chapter 4.6 “NMT \(network management\)”](#)).

The “Shutdown” command places the drive in “Ready to Switch On” state (transition 2).

The “Switch On” command then switches on the power stage. The drive is now enabled and is in “Switched On” state (transition 3).

The “Enable Operation” command places the drive in “Operation Enabled” state, the drive’s normal operating mode (transition 4). The “Disable Operation” command places the drive back in “Switched On” state and is used, e.g. to terminate a running operation (transition 5).

## 6 Functional description of the CANopen CiA 402

### 6.1 Device Control

The state changes shown in the diagram are executed by the following commands:

| Command           | Transitions  |
|-------------------|--------------|
| Shutdown          | 2, 6, 8      |
| Switch on         | 3            |
| Disable Voltage   | 7, 9, 10, 12 |
| Quick Stop        | 7, 10, 11    |
| Disable Operation | 5            |
| Enable Operation  | 4, 16        |
| Fault Reset       | 15           |

#### Controlword (0x6040)

The commands for executing state changes are executed by a combining bits 0 – 3 in the controlword. The controlword is located in the object dictionary under Index 0x6040 and is usually transmitted with PDO1.

| Index  | Subindex | Name        | Type       | Attrb. | Default value | Meaning       |
|--------|----------|-------------|------------|--------|---------------|---------------|
| 0x6040 | 0        | controlword | Unsigned16 | rw     | 0             | Drive control |

The bits in the controlword have the following meaning:

| Bit | Function                             | Commands for Device Control State Machine |           |                 |            |                   |                  |             |  |
|-----|--------------------------------------|---|-----------|-----------------|------------|-------------------|------------------|-------------|--|
|     |                                      | shut-down                                 | Switch on | Disable Voltage | Quick Stop | Disable Operation | Enable Operation | Fault Reset |  |
| 0   | Switch on                            | 0   | 1         | X               | X          | 1                 | 1                | X           |  |
| 1   | Enable Voltage                       | 1   | 1         | 0               | 1          | 1                 | 1                | X           |  |
| 2   | Quick Stop                           | 1   | 1         | X               | 0          | 1                 | 1                | X           |  |
| 3   | Enable Operation                     | X   | 0         | X               | X          | 0                 | 1                | X           |  |
| 4   | New set-point/Homing operation start |   |           |                 |            |                   |                  |             |  |
| 5   | Change set immediately               |   |           |                 |            |                   |                  |             |  |
| 6   | abs/rel                              |   |           |                 |            |                   |                  |             |  |
| 7   | Fault reset                          |   |           |                 |            |                   |                  | 0->1        |  |
| 8   | Halt                                 |   |           |                 |            |                   |                  |             |  |
| 9   | 0                                    |   |           |                 |            |                   |                  |             |  |
| 10  | 0                                    |   |           |                 |            |                   |                  |             |  |
| 11  | 0                                    |   |           |                 |            |                   |                  |             |  |
| 12  | 0                                    |   |           |                 |            |                   |                  |             |  |
| 13  | 0                                    |   |           |                 |            |                   |                  |             |  |
| 14  | 0                                    |   |           |                 |            |                   |                  |             |  |
| 15  | 0                                    |   |           |                 |            |                   |                  |             |  |

Meaning of the other bits in the controlword:

| Function               | Description   |
|------------------------|---|
| New set-point          | 0: No new target position specified<br>1: New target position specified   |
| Change set immediately | 0: Start new positioning when current positioning has finished.<br>1: Interrupt current positioning and start a new one |
| abs/rel                | 0: Target position is an absolute value<br>1: Target position is a relative value                                       |
| Fault reset            | 0->1: Reset fault   |
| Halt                   | 0: Movement can be made<br>1: Stop drive  |

The command sequences for starting a positioning, a speed control operation or a homing sequence are explained in the following sections.

## 6 Functional description of the CANopen CiA 402

---

### 6.1 Device Control

#### Example

Step sequence of the transitions in order to set a drive in Enable Operation state:

**1. Shutdown:**

Controlword = 0x00 06

**2. Switch on:**

Controlword = 0x00 07

The drive is then in "Switched On" status. Operation must then be released to enable drive commands to be executed:

**3. Enable Operation:**

Controlword = 0x00 0F

The drive is then in "Operation Enabled" state, in which it can be operated using the relevant objects of the set operating mode.

#### Example

Step sequence of the transitions to get a drive from the error state:

**1. Fault reset:**

Controlword = 0x00 80

**2. Shutdown:**

Controlword = 0x00 06

**3. Switch on:**

Controlword = 0x00 07

The drive is then in "Switched On" status. Operation must then be released to enable drive commands to be executed:

**4. Enable Operation:**

Controlword = 0x00 0F

The drive is then in "Operation Enabled" state, in which it can be operated using the relevant objects of the set operating mode.

## 6 Functional description of the CANopen CiA 402

### 6.1 Device Control

#### Statusword (0x6041)

The current state of the drive is displayed in bits 0 – 6 of the statusword. In the event of state changes, the FAULHABER Motion Controller in its default setting automatically sends the current statusword on PDO1. The current state can also be queried at any time using a remote request on PDO1. The statusword is located in the object dictionary under Index 0x6041.

| Index  | Sub-index | Name       | Type       | Attrb. | Default value | Meaning        |
|--------|-----------|------------|------------|--------|---------------|----------------|
| 0x6041 | 0         | statusword | Unsigned16 | ro     | 0             | Status display |

The bits of the statusword have the following meaning:

| Bit | Function                                    | State of the Device Control State Machine |                    |                    |             |                   |                   |                       |       |
|-----|---|---|--------------------|--------------------|-------------|-------------------|-------------------|-----------------------|-------|
|     |   | Not Ready to Switch On                    | Switch On Disabled | Ready to Switch On | Switched On | Operation Enabled | Quick stop active | Fault reaction active | Fault |
| 0   | Ready to Switch On                          | 0   | 0                  | 1                  | 1           | 1                 | 1                 | 1                     | 0     |
| 1   | Switched On                                 | 0   | 0                  | 0                  | 1           | 1                 | 1                 | 1                     | 0     |
| 2   | Operation Enabled                           | 0   | 0                  | 0                  | 0           | 1                 | 1                 | 1                     | 0     |
| 3   | Fault                                       | 0   | 0                  | 0                  | 0           | 0                 | 0                 | 1                     | 1     |
| 4   | Voltage Enabled                             | X   | X                  | X                  | X           | X                 | X                 | X                     | X     |
| 5   | Quick Stop                                  | X   | X                  | 1                  | 1           | 1                 | 0                 | X                     | X     |
| 6   | Switch On Disabled                          | 0   | 1                  | 0                  | 0           | 0                 | 0                 | 0                     | 0     |
| 7   | Warning                                     |   |                    |                    |             |                   |                   |                       |       |
| 8   | 0   |   |                    |                    |             |                   |                   |                       |       |
| 9   | Remote                                      |   |                    |                    |             |                   |                   |                       |       |
| 10  | Target Reached                              |   |                    |                    |             |                   |                   |                       |       |
| 11  | Internal limit active                       |   |                    |                    |             |                   |                   |                       |       |
| 12  | Set-point acknowledge/Speed/Homing attained |   |                    |                    |             |                   |                   |                       |       |
| 13  | Homing Error                                |   |                    |                    |             |                   |                   |                       |       |
| 14  | Hard Notify                                 |   |                    |                    |             |                   |                   |                       |       |
| 15  | 0   |   |                    |                    |             |                   |                   |                       |       |

Meaning of the other bits in the statusword:

| Function              | Description  |
|-----------------------|--|
| Warning               | not used   |
| Remote                | not used   |
| Target Reached        | 0: Target position or target velocity not yet reached<br>1: Target position or target velocity reached.<br>(Halt = 1: Drive has reached speed 0) |
| Set-point acknowledge | 0: New target position not yet adopted (Profile Position Mode)<br>1: New target position adopted   |
| Homing attained       | 0: Homing sequence not yet completed<br>1: Homing sequence successfully completed  |
| Speed                 | 0: Speed not equal to 0 (Profile Velocity Mode)<br>1: Speed 0  |
| Homing Error          | 0: No error<br>1: Error  |
| Hard Notify           | 0: No limit switch has switched<br>1: A notify switch has switched<br>(see Object 0x2311 for which input has switched)                           |

Bit 10 (Target Reached) is set if the drive has reached its target position in Profile Position Mode or has reached its target velocity in Profile Velocity Mode. Specification of a new target value deletes the bit.

Bit 11 (Internal Limit active) indicates that a internal range limit has been reached.

Bit 12 (Setpoint acknowledge/Speed) is set after receiving a new positioning command (control word with new setpoint) and is reset when the target position is reached or the new setpoint has been reset in the control word (handshake for positioning command). In Profile Velocity Mode the bit is set at velocity 0.

## 6 Functional description of the CANopen CiA 402

### 6.1 Device Control

#### 6.1.2 Selection of the operating mode

The Modes of Operation parameter is used to select the active drive profile, the Modes of Operation Display entry can be used to read back the current mode of operation.

##### Modes of Operation (0x6060)

| Index  | Sub-index | Name               | Type     | Attrb. | Default value | Meaning                   |
|--------|-----------|--------------------|----------|--------|---------------|---------------------------|
| 0x6060 | 0         | modes of operation | Integer8 | wo     | 1             | Operating mode changeover |

FAULHABER Motion Control systems support the following operating modes:

- 1 CiA 402 Profile Position Mode (position control)
- 3 CiA 402 Profile Velocity Mode (velocity control)
- 6 CiA 402 Homing Mode (homing)
- 1 FAULHABER specific operating mode

The operating modes according to CiA 402 are described in the following sections. The operating modes of the FAULHABER-specific mode of operation are described in [Chapter 3 "Operation in FAULHABER mode"](#).

##### Modes of Operation Display (0x6061)


| Index  | Sub-index | Name                       | Type     | Attrb. | Default value | Meaning                           |
|--------|-----------|----------------------------|----------|--------|---------------|-----------------------------------|
| 0x6061 | 0         | modes of operation display | Integer8 | ro     | 1             | Display of the set operating mode |

The set operating mode can be queried here, the meaning of the return values corresponds to the values of the object 0x6060.

## 6 Functional description of the CANopen CiA 402

### 6.2 Factor Group

Effects of the factor group on the set-point and actual values of the controller



The objects of this area are used to convert between internal variables and user-defined physical variables. The effective factors are each determined via a quotient:

$$\text{Factor} = \frac{\text{Numerator}}{\text{Denominator (divisor)}}$$

FAULHABER Motion Control systems support the conversion of the position, the velocity and acceleration at the interface in user-defined variables.



## 6 Functional description of the CANopen CiA 402

### 6.2 Factor Group

#### Position Factor (0x6093)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                                      |
|--------|-----------|-------------------|------------|--------|---------------|--|
| 0x6093 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                     |
|        | 1         | numerator         | Unsigned32 | rw     | 1             | Numerator of the position factor             |
|        | 2         | feed_constant     | Unsigned32 | rw     | 1             | Denominator (divisor) of the position factor |

The position factor can be used to set the required position unit for the profile position mode. Internally, the encoder resolution or the resolution of the analog hall signals of BL motors without encoder are used.

#### Velocity Factor (0x6096)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                                      |
|--------|-----------|-------------------|------------|--------|---------------|--|
| 0x6096 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                     |
|        | 1         | numerator         | Unsigned32 | rw     | 1             | Numerator of the velocity factor             |
|        | 2         | divisor           | Unsigned32 | rw     | 1             | Denominator (divisor) of the velocity factor |

The required velocity unit can be set using the velocity factor. Internally, the velocity is used in 1/min (rpm).

#### Acceleration Factor (0x6097)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|-------------------|------------|--------|---------------|--|
| 0x6097 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                         |
|        | 1         | numerator         | Unsigned32 | rw     | 1             | Numerator of the acceleration factor             |
|        | 2         | divisor           | Unsigned32 | rw     | 1             | Denominator (Divisor) of the acceleration factor |

The required acceleration unit can be set using the acceleration factor. Internally, accelerations are displayed in 1/s<sup>2</sup>.

#### Polarity (0x607E)

| Index  | Sub-index | Name     | Type      | Attrb. | Default value | Meaning               |
|--------|-----------|----------|-----------|--------|---------------|-----------------------|
| 0x607E | 0         | polarity | Unsigned8 | rw     | 0             | Direction of rotation |

The entries in this object can be used to change the direction of rotation of the connected encoder for the supported operating modes:


Bit 7 = 1 → negative direction of rotation in positioning mode

Bit 6 = 1 → negative direction of rotation in velocity mode

## 6 Functional description of the CANopen CiA 402

### 6.3 Profile Position Mode and Position Control Function

#### Controller structure for position control in Profile Position Mode



In this operating mode the target position and the controller settings are specified by the entries in the object dictionary.

#### Operating mode overview

In profile position mode the drive is positioned in the transferred target position.

In order for the drive to be operated in profile position mode, this operating mode must be set in the modes of operation parameter (0x6060). In addition, the drive must be in operation enabled state via its state machine.

In general, after switching on a homing sequence must be performed via homing mode in order to reset the position value to zero at the homing limit switch (see [Chapter 6.4 "Homing Mode"](#)).

A position setpoint value is specified via the target position object (0x607A). The positioning process is started by a change from 0 to 1 of bit 4 (New setpoint in the controlword). Bit 6 in the controlword can be used to additionally specify whether the setpoint value is to be interpreted in absolute or relative terms.

Operation in profile position mode requires correctly set velocity and position controllers.

In addition to the setpoint value, the software position limit object (0x607D) can be used to specify range limits for the movement range.

The set maximum values for acceleration, deceleration ramp and speed are additionally taken into account.

#### Notification of the higher level control

Attainment of the target position is signalled by bit 10 "target reached" in the statusword of the drive. If the transmission type for the particular PDO is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

#### Basic settings

The position control parameter set object (0x2332) can be used to set the proportional amplification and a differential term for the position controller.

Positioning range limits can be defined relative to the reference position using the software position limit object (0x607D).

The position window object (0x6067) can be used to define a window around the target position. The target position is signalled as being reached using bit 10 (target reached) in the statusword, if the actual position stays within the position window for at least the time set in the position window time object (0x6068).

## 6 Functional description of the CANopen CiA 402

### 6.3 Profile Position Mode and Position Control Function

#### Software Position Limit (0x607D)

| Index  | Sub-index | Name               | Type      | Attrb. | Default value     | Meaning                       |
|--------|-----------|--------------------|-----------|--------|-------------------|-------------------------------|
| 0x607D | 0         | number of entries  | Unsigned8 | ro     | 2                 | Number of object entries      |
|        | 1         | min position limit | Integer32 | rw     | $-1.8 \cdot 10^9$ | Lower positioning range limit |
|        | 2         | max position limit | Integer32 | rw     | $+1.8 \cdot 10^9$ | Upper positioning range limit |

The positioning range limits are specified in the units defined by the user and are converted in the internal display using the position factor.

#### Position Control ParameterSet (0x60FB)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                    |
|--------|-----------|-------------------|------------|--------|---------------|----------------------------|
| 0x60FB | 0         | number of entries | Unsigned16 | ro     | 2             | Number of object entries   |
|        | 1         | gain              | Unsigned16 | rw     | <sup>*)</sup> | Position controller P term |
|        | 2         | D constant        | Unsigned16 | rw     | <sup>*)</sup> | Position controller D term |

<sup>\*)</sup>Dependent on the factory configuration of the motion controller

#### Position Window (0x6067)

| Index  | Sub-index | Name            | Type       | Attrb. | Default value | Meaning                |
|--------|-----------|-----------------|------------|--------|---------------|------------------------|
| 0x6067 | 0         | position window | Unsigned32 | rw     | 40            | Target position window |

Symmetrical area around the target position, which is used for the "Target Reached" message. It is specified in user-defined units, according to the given Position Factor.

#### Position Window Time (0x6068)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning                        |
|--------|-----------|----------------------|------------|--------|---------------|--------------------------------|
| 0x6068 | 0         | position window time | Unsigned32 | rw     | 200           | Time in target position window |

If the drive stays within the range of the Position Window for at least the time set here in milliseconds, bit 10 is set in the statusword (Target Reached).

#### Query current values / Position Control Function

The last target position can be read back in internal units using the Position Demand Value object on Index 0x60FC and in user-defined units using the entry on Index 0x6062.

The current position can be read back in internal units using the Position Actual Value object on Index 0x6063 and in user-defined units using Index 0x6064. The description of the objects is given in [Chapter 8.3 "Drive profile objects according to CiA 402"](#).

## 6 Functional description of the CANopen CiA 402

### 6.3 Profile Position Mode and Position Control Function

#### Additional settings

##### Incremental encoder as position sensor

By default, the position for BL motors is evaluated using the analog hall sensors with a resolution of 3 000 increments per revolution. Alternatively, an incremental encoder can also be used as the position encoder for BL motors in Profile Position mode. To do this, the drive must be configured in ENCMOD. This can be done in FAULHABER mode using the FAULHABER commands on PDO2 or using the Motion Manager. Following the initial configuration, the Profile Position Mode can be selected.

##### Ramp generator

The output of the position controller is additionally limited by a ramp generator to the permissible acceleration and deceleration values and the maximum speed.

A trapezoidal profile with linear speed ramps only is supported. This setting can be read out in the Motion Profile Type object (0x6086).

#### Profile Velocity (0x6081) and Max Profile Velocity (0x607F)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning       |
|--------|-----------|----------------------|------------|--------|---------------|---------------|
| 0x6081 | 0         | profile velocity     | Unsigned32 | rw     | *)            | Maximum speed |
| 0x607F | 0         | max profile velocity | Unsigned32 | rw     | *)            | Maximum speed |

\*) Dependent on the factory configuration of the motion controller

Maximum velocity during positioning. It is specified in user-defined units, according to the given velocity factor. Both objects describe the same internal parameter.

#### Profile Acceleration (0x6083)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning              |
|--------|-----------|----------------------|------------|--------|---------------|----------------------|
| 0x6083 | 0         | profile acceleration | Unsigned32 | rw     | 30 000.       | Maximum acceleration |

It is specified in user-defined units, according to the given acceleration factor.

#### Profile Deceleration (0x6084)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning       |
|--------|-----------|----------------------|------------|--------|---------------|---------------|
| 0x6084 | 0         | profile deceleration | Unsigned32 | rw     | 30 000.       | Maximum delay |

#### Quick Stop Deceleration (0x6085)

| Index  | Sub-index | Name                    | Type       | Attrb. | Default value | Meaning                           |
|--------|-----------|-------------------------|------------|--------|---------------|-----------------------------------|
| 0x6085 | 0         | quick stop deceleration | Unsigned32 | rw     | 30 000        | Braking ramp value for Quick Stop |

The acceleration values are specified in user-defined units, according to the value of the given acceleration factor.

#### Velocity controller / current limitation

The controller parameters of the secondary velocity controller can also be adjusted. In addition, the current limitation values LPC and LCC made available by the FAULHABER channel (PDO2) or the Motion Manager can be used to protect the drive against overload (see [Chapter 6.5 "Profile Velocity Mode"](#)).

## 6 Functional description of the CANopen CiA 402

### 6.3 Profile Position Mode and Position Control Function

#### Motion control commands

A position set-point is specified using the Target Position object (0x607A). The positioning process is started using bit 4 in the controlword. Bit 6 in the controlword can also be used to additionally specify whether the set-point should be interpreted as being absolute or relative.

#### Target Position (0x607A)

| Index  | Sub-index | Name            | Type      | Attrb. | Default value | Meaning         |
|--------|-----------|-----------------|-----------|--------|---------------|-----------------|
| 0x607A | 0         | target position | Integer32 | rw     | 0             | Target position |

The target position is specified in the units defined by the user and is converted in the internal display using the position factor.


Adoption of a new target position is acknowledged by the drive via the statusword with set bit 12 (acknowledge setpoint). The drive signals that the target position has been reached via the statusvalue with set bit 10 (target reached). "Target Reached" remains set until new positioning is started or the output stage is switched off.

If a new setpoint value is specified during positioning (new setpoint), this is accepted immediately and the drive moves to the new target position. In this way, motion profiles can be run through continuously without having to decelerate the drive to velocity 0 in between times.

#### Individual positioning sequence:

Prerequisite: NMT state "Operational", drive state "Operation Enabled" and modes of operation (0x6060) set to Profile Position Mode (1).

1. Set Target Position (0x607A) to the required value.
2. In the Controlword, set Bit 4 (New Setpoint) to "1" and set Bit 6 (abs / rel) depending on whether absolute or relative positioning is required.
3. The drive responds with Bit 12 (Setpoint Acknowledge) set in the Statusword and starts the positioning.
4. The drive signals that the target position has been reached via the status value with set bit 10 (target reached). A new positioning job can now be started (New Setpoint).




## 6 Functional description of the CANopen CiA 402

### 6.3 Profile Position Mode and Position Control Function

#### Procedure for a sequence of set-points:

Prerequisite: NMT state "Operational", drive state "Operation Enabled" and modes of operation (0x6060) set to Profile Position Mode (1).

1. Set Target Position (0x607A) to the required value.
2. In the Controlword, set Bit 4 (New Setpoint) to "1" and set Bit 6 (abs / rel) depending on whether absolute or relative positioning is required.
3. The drive responds with Bit 12 (Setpoint Acknowledge) set in the Statusword and starts the positioning.
4. A new positioning job can already be started now (New Setpoint), with relative positioning the new target position is added to the last target position. The drive then moves immediately to the new target position.
5. The end of the movement sequence is signalled by the Statusword with set Bit 10 (Target reached).



## 6 Functional description of the CANopen CiA 402

### 6.4 Homing Mode

The objects within this range are available for homing mode. In general, after switching on a homing sequence must be performed to reset the position value at the homing limit switch. Object 0x2310 can be used to set which inputs are to be used as homing limit switches (see [Chapter 8.2 “Manufacturer-specific objects”](#)).

#### Homing Offset

| Index  | Sub-index | Name          | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|---------------|-----------|--------|---------------|---|
| 0x607C | 0         | homing offset | Integer32 | rw     | 0             | Zero point displacement from the reference position |

#### Homing Method

| Index  | Sub-index | Name          | Type     | Attrb. | Default value | Meaning       |
|--------|-----------|---------------|----------|--------|---------------|---------------|
| 0x6098 | 0         | homing method | Integer8 | rw     | 0             | Homing method |

All homing methods defined in DSP402 V2 are supported:

- 1 to 14: Homing with index pulse (if available)
- 17 to 30: Homing without index pulse
- 33, 34: Homing at index pulse (if available)
- 35: Homing at the current position

#### NOTE



*Limit switches limit the movement range (negative/positive limit switch), but at the same time can also be used as reference switches for the zero position. A homing switch is a separate reference switch for the zero position.*

#### Method 1 and 17

Homing at the lower limit switch (Negative Limit Switch)

If the limit switch is inactive, the drive moves in the direction of the lower limit switch first, until its positive edge has been detected. If the limit switch is active, the drive moves upward out of the limit switch until the negative edge has been detected. With Method 1, the drive then continues moving on the next index pulse at which the home position is set.

#### Method 2 and 18

Homing at the upper limit switch (Positive Limit Switch)

If the limit switch is inactive, the drive moves in the direction of the upper limit switch first, until its positive edge has been detected. If the limit switch is active, the drive moves downward out of the limit switch until the negative edge has been detected. With Method 2, the drive then continues moving on the next index pulse at which the home position is set.


## 6 Functional description of the CANopen CiA 402

### 6.4 Homing Mode

#### Method 3, 4 and 19, 20

Homing at a positive Homing switch (Positive Home Switch)

Depending on the state of the homing switch, the drive moves in one direction or the other up to the falling (3, 19) or rising (4, 20) edge. There is only one rising edge of the homing switch in the direction of the upper limit switch. The FAULHABER HP parameter for the limit switch used is simultaneously set to 1 here (rising edge).



#### Method 5, 6 and 21, 22

Homing at a negative Homing switch (Negative Home Switch)

Depending on the state of the homing switch, the drive moves in one direction or the other up to the falling (5, 21) or rising (6, 22) edge. There is only one falling edge of the homing switch in the direction of the upper limit switch. The FAULHABER HP parameter for the limit switch used is simultaneously set to 0 here (falling edge).


#### Method 7 to 14 and 23 to 30

Homing at Homing switch (Home Switch)

These methods use a limit switch which is only active within a defined path range. A differentiation is made between the response to the two edges.

With Methods 7 to 14, after the edge has been detected, the drive continues moving up to the index pulse at which the homing position is then set.

**Method 7 and 23** Homing at bottom of falling edge.  
Start in positive direction, if switch inactive



**Method 8 and 24** Homing at bottom of rising edge.  
Start in positive direction, if switch inactive.



## 6 Functional description of the CANopen CiA 402

---

### 6.4 Homing Mode

|                         |   |
|-------------------------|---|
| <b>Method 9 and 25</b>  | Homing at top of rising edge.<br>Always start in positive direction.  |
| <b>Method 10 and 26</b> | Homing at top of falling edge.<br>Always start in positive direction.                                       |
| <b>Method 11 and 27</b> | Homing at top of falling edge.<br>Start in negative direction, if switch inactive.                          |
| <b>Method 12 and 28</b> | Homing at top of rising edge.<br>Start in negative direction, if switch inactive.                           |
| <b>Method 13 and 29</b> | Homing at bottom of rising edge.<br>Always start in negative direction.                                     |
| <b>Method 14 and 30</b> | Homing at bottom of falling edge.<br>Always start in negative direction.                                    |
| <b>Method 33 and 34</b> | Homing at the index pulse<br>Drive moves in negative (33) or positive (34) direction up to the index pulse. |
| <b>Method 35</b>        | The position counter is reset at the current position.  |

#### **NOTE**



*Limit switches and homing switches are approached in velocity mode, an index pulse in positioning mode. At the same time the set range limits (0x607D) are taken into account.*

## 6 Functional description of the CANopen CiA 402

### 6.4 Homing Mode

#### Homing Speed

| Index  | Sub-index | Name                           | Type       | Attrb. | Default value | Meaning                        |
|--------|-----------|--------------------------------|------------|--------|---------------|--------------------------------|
| 0x6099 | 0         | number of entries              | Unsigned8  | ro     | 2             | Number of object entries       |
|        | 1         | speed during search for switch | Unsigned32 | rw     | 400           | Speed during search for switch |
|        | 2         | speed during search for home   | Unsigned32 | rw     | 100           | Speed during search for zero   |

The specifications are given in user-defined units, according to the given velocity factor.

#### Homing Acceleration

| Index  | Sub-index | Name                | Type       | Attrb. | Default value | Meaning                    |
|--------|-----------|---------------------|------------|--------|---------------|----------------------------|
| 0x609A | 0         | homing acceleration | Unsigned32 | rw     | 50            | Acceleration during homing |

It is specified in user-defined units, according to the given acceleration factor.

#### Procedure for a homing sequence:

Prerequisite: NMT state "Operational", drive state "Operation Enabled" and modes of operation (0x6060) set to Homing Mode (6).


1. Set Homing Limit Switch (0x2310), Homing Method (0x6098), Homing Speed (0x6099) and Homing Acceleration (0x609A) to the required value.
2. In the controlword, set Bit 4 (Homing operation start) to "1", to start the homing sequence.
3. The drive responds with Bit 12 (Homing attained) set in the statusword when the homing sequence is finished. If an error occurs during the homing sequence, Bit 13 (Homing Error) is set in the statusword.

An on-going homing sequence can be interrupted by writing a "0" on Bit 4 in the controlword.

## 6 Functional description of the CANopen CiA 402

### 6.5 Profile Velocity Mode

#### Controller structure in Profile Velocity Mode



#### Operating mode overview

In the profile velocity mode the speed of the drive is controlled by a PI controller. This ensures that the drive is operated without deviation from the specified values, provided it is not overloaded.

In order for the drive to be operated in profile velocity mode, this operating mode must be set in the modes of operation parameter (0x6060). In addition, the drive must be in operation enabled state via its state machine.

The target velocity is set via the target velocity object (0x60FF) in the object dictionary. In profile velocity mode the drive directly follows each new transferred setpoint value. At the same time, the set maximum values for acceleration, deceleration ramp and speed are also taken into account.

#### Notification of the higher level control

Attainment of the target velocity is signalled by bit 10 "target reached" in the statusword of the drive. A stopped drive is signalled via bit 12 "Speed = 0". If the transmission type for the particular PDO is set to 255, the PDO is transmitted asynchronously, triggered by the change in state.

Operation in profile velocity mode requires a velocity controller correctly adjusted to the application.

## 6 Functional description of the CANopen CiA 402

### 6.5 Profile Velocity Mode

#### Basic settings

The Velocity Control Parameter Set object (0x60F9) can be used to set the proportional amplification and the I term for the position controller.

#### Velocity Control Parameter Set (0x60F9)

| Index  | Sub-index | Name                      | Type       | Attrb. | Default value | Meaning                  |
|--------|-----------|---------------------------|------------|--------|---------------|--------------------------|
| 0x60F9 | 0         | number of entries         | Unsigned8  | ro     | 2             | Number of object entries |
|        | 1         | gain                      | Unsigned16 | rw     | *)            | P term                   |
|        | 2         | integration time constant | Unsigned16 | rw     | *)            | I term                   |

\*) Dependent on the factory configuration of the motion controller

The sampling rate can be set between 1 and 20 as a multiple of the internal sampling rate using the SR command. The internal sampling rate is 0.2 ms.

#### Actual velocity value

In BL motors the current velocity is determined by evaluating the analog hall sensor signals. The ECN-MOD can also be configured for BL motors using the Motion Manager or the ENCMOD command via the FAULHABER channel on PDO2.

In DC motors, the velocity is determined using the incremental encoder.

The resolution of the encoder is configured using the Position Encoder Resolution object (0x608F) (see [Chapter 6.2 "Factor Group"](#)).

## 6 Functional description of the CANopen CiA 402

### 6.5 Profile Velocity Mode

#### Additional settings

##### Ramp generator

After specifying a new target speed using the Target Velocity object (0x60FF), the drive is accelerated or braked to the new speed in the Profile Velocity Mode using the acceleration deposited in the Profile Acceleration object (0x6083). The parameter is valid in both directions!

##### Current limitation

The parameter LPC (allowable peak current) and LCC (allowable continuous current) can be used to protect the drive against overload. The parameters can be set using the configuration dialogue of the Motion Manager or the FAULHABER commands LPC and LCC via PDO2.

#### Motion control commands

A velocity set-point is specified using the Target Velocity object (0x60FF). Provided the drive is in Operation Enable state (see [Chapter 6.1 "Device Control"](#)), the drive is accelerated directly to the new target velocity.

The Parameter Velocity Window (0x606D) is used to define a window around the target velocity, within which the target velocity is signalled as being reached, if the velocity remains within the target window for at least the time in using the parameter Velocity Window Time (0x606E).

The attained target velocity is signalled in the statusword by bit 10 "Target Reached".

The Parameter Velocity Threshold (0x606F) is used to define a threshold value for the velocity, below which the drive is signalled as being at a standstill, if the velocity remains below the threshold value for at least the time defined using the parameter and Velocity Threshold Time (0x6070).

Stoppage is signalled in the statusword by bit 12 "Speed=0".

#### Target Velocity (0x60FF)

| Index  | Sub-index | Name            | Type      | Attrb. | Default value | Meaning         |
|--------|-----------|-----------------|-----------|--------|---------------|-----------------|
| 0x60FF | 0         | target velocity | Integer32 | rw     | 20            | Target velocity |

The target velocity is specified in the units defined by the user and is converted in the internal display (1/min) using the velocity factor.

The last set target velocity can be queried in user-defined units using the Velocity Demand Value object (0x606B).

The current velocity value can be queried using the Velocity sensor actual value (0x6069) or Velocity actual value (0x606C) objects, each in user-defined units.

The description of the objects is given in [Chapter 8.3 "Drive profile objects according to CiA 402"](#).

#### Complex motion profiles

Evaluation of bits 10 "Target Reached" and 12 "Speed = 0" in the statusword can be used to deliberately shut down specific velocity profiles. The acceleration is defined using the Profile Acceleration object.

## 6 Functional description of the CANopen CiA 402

### 6.6 Drive parameters / Common entries

Basic properties of the drive system are stored in the encoder and motor type objects.

#### Drive Data (0x6510)

The velocity constant and the motor resistance are required as parameters for the motor monitoring models. These values are already set for integrated units. These values are suitably preassigned for external controls by selecting a motor type in the Motion Manager's Motor Wizard.

| Index  | Sub-index | Name                | Type       | Attrb. | Default value | Meaning                                       |
|--------|-----------|---------------------|------------|--------|---------------|---|
| 0x6510 | 0         | number of entries   | Unsigned8  | ro     | 3             | Number of object entries                      |
|        | 1         | motor type          | Signed32   | ro     | *)            | Set motor type<br>0 BL motor<br>-1 DC motor   |
|        | 2         | speed constant KN   | Unsigned16 | rw     | *)            | Speed constant Kn of the motor<br>Unit: rpm/V |
|        | 3         | motor resistance RM | Unsigned32 | rw     | *)            | Motor resistance RM<br>Unit: mΩ               |

\*) Dependent on the factory configuration of the motion controller

#### Position Encoder Resolution (0x608F)

If the linear Hall sensors of the brushless motors are used as position transducers, 3 000 pulses per revolution are supplied. If using an incremental sensor as position sensor, its resolution must be set using the Position Encoder Resolution object.

| Index  | Sub-index | Name               | Type       | Attrb. | Default value | Meaning   |
|--------|-----------|--------------------|------------|--------|---------------|---|
| 0x608F | 0         | number of entries  | Unsigned8  | ro     | 2             | Number of entries   |
|        | 1         | encoder increments | Unsigned32 | rw     | 2 048         | Resolution of the external encoder for 4 edge evaluation              |
|        | 2         | motor revolution   | Unsigned32 | rw     | 1             | Number of motor revolutions with the pulse number named in subindex 1 |

## 6 Functional description of the CANopen CiA 402

### 6.7 Inputs/Outputs

The connections described in [Chapter 3.3 "Homing and limit switches"](#) are available. [Chapter 3.3.1 "Limit switch connections and switching level"](#) describes configuration of the switching level. [Chapter 3.5 "Special fault output functions"](#) describes the special function of the fault pin.

#### Limit switch and homing switch setting

The available digital inputs can each be configured as limit switches or homing switches for use within a DSP402 homing method. The upper and lower limit switches are additionally used as range limit switches, beyond which the drive cannot move (hard blocking).

If lower and upper limit switches are not used for a DSP402 homing method, their switch polarity can be defined using the switch polarity parameter (rising or falling edge valid). By default, homing methods 1, 2, 17 and 18 assume a positively switching limit switch. If, on the other hand, a negative switching limit switch is to be used the required polarity must be set here accordingly and in addition the polarity parameter for the homing limit must be set to 1.

#### NOTE




*The input configuration cannot be changed in homing mode. For this you must switch to profile position or profile velocity mode!*

#### Limit switch setting

| Index  | Sub-index | Name                      | Type      | Attrb. | Default value           | Meaning  |
|--------|-----------|---------------------------|-----------|--------|-------------------------|--|
| 0x2310 | 0         | Number of entries         | Unsigned8 | ro     | 6                       | Number of object entries   |
|        | 1         | Negative limit switch     | Unsigned8 | rw     | 0                       | Lower limit switch   |
|        | 2         | Positive limit switch     | Unsigned8 | rw     | 0                       | Upper limit switch   |
|        | 3         | Homing switch             | Unsigned8 | rw     | 0x07/0x1F <sup>*)</sup> | Homing switch  |
|        | 4         | Notify switch             | Unsigned8 | rw     | 0                       | Notify switch  |
|        | 5         | Switch polarity           | Unsigned8 | rw     | 0x07/0x1F <sup>*)</sup> | Polarity of the switches<br>1: Pos. edge valid<br>0: Neg. Edge valid |
|        | 6         | Polarity for homing limit | Unsigned8 | rw     | 0                       | Use the polarity of the switches in DSP402 Homing Mode too           |

<sup>\*)</sup> BL-Controller/MCDC

The function of the digital inputs can be set here in accordance with the following bit mask:



## 6 Functional description of the CANopen CiA 402

### 6.7 Inputs/Outputs

#### Explanation

- Subindex 1 (negative limit):

Here the input is given, at which the lower limit switch for homing methods 1 and 17 or for a hard blocking function is connected.

If the limit switch is activated the drive is stopped and can now only be moved back out of the limit switch in the opposite direction (Hard Blocking).

- Subindex 2 (positive limit):

Here the input is given, at which the upper limit switch for homing methods 2 and 18 or for a hard blocking function is connected.

If the limit switch is activated the drive is stopped and can now only be moved back out of the limit switch in the opposite direction (Hard Blocking).

- Subindex 3 (homing):

Here the input is given, at which the homing switch for homing methods 3 to 14 and 19 to 30 is connected. Polarity and notify (subindex 5 and 4) cannot be used here.

- Subindex 4 (notify):

Here the input is given, at which a notify switch is connected, which reports with the status word and set bit 14, if it has been activated. Object index 0x2311 can then be used to query which switch has switched. This function cannot be used simultaneously with a homing method. The object's setting is not saved, as soon as a switch has been activated the value is reset.

- Subindex 5 (polarity):

The polarity of the notify switch and the hard blocking limit switch can be set here. If the polarity is to be changed with homing methods 1, 2, 17 and 18 too, subindex 6 must be set to 1 beforehand.

- Subindex 6 (DSP402 polarity):

Here it is possible to give whether the polarity settings under subindex 5 are to be used for the homing methods 1, 2, 17 and 18. In general, the setting can only be set for all inputs (no bitmask coding).

For a description of the homing methods, see [Chapter 6.4 "Homing Mode"](#).

The settings of this object simultaneously change the settings of the FAULHABER parameters HB, HD, HA, HN and HP!

#### Notify switch

| Index  | Sub-index | Name             | Type      | Attrb. | Default value | Meaning           |
|--------|-----------|------------------|-----------|--------|---------------|-------------------|
| 0x2311 | 0         | triggered switch | Unsigned8 | ro     | 0             | Switched switches |

This object can be used to query which switch switched according to the above bit mask if a status-word message with set bit 14 has arrived. Reading the object resets bit 14 in the statusword.



## 6 Functional description of the CANopen CiA 402

### 6.8 Error handling

#### FAULHABER Fault Register

| Index  | Sub-index | Name                    | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|-------------------------|------------|--------|---------------|--|
| 0x2320 | 0         | number of entries       | Unsigned8  | ro     | 4             | Number of object entries   |
|        | 1         | internal fault register | Unsigned16 | ro     | 0             | Current internal fault<br>0 = No fault   |
|        | 2         | emergency mask          | Unsigned16 | rw     | 0x00FF        | Faults which trigger an emergency message frame                                      |
|        | 3         | fault mask              | Unsigned16 | rw     | 0             | Faults which are treated as DSP402 faults and affect the state machine (fault state) |
|        | 4         | errout mask             | Unsigned16 | rw     | 0x00FF        | Faults which set the error output  |

This object describes how internal faults are treated.

The errors are coded as follows and can be masked by adding the required error types:

| Error-Bit | Error                         | Beschreibung                                      |
|-----------|-------------------------------|---|
| 0x0001    | Continuous over current       | Set continuous current limiting exceeded          |
| 0x0002    | Deviation                     | Set maximum allowable velocity deviation exceeded |
| 0x0004    | Over voltage                  | Overvoltage detected                              |
| 0x0008    | Over temperature              | Maximum coil or MOSFET temperature exceeded       |
| 0x0010    | Flash memory error            | Memory error                                      |
| 0x0100    | Life guard or heartbeat error | CAN monitoring error                              |
| 0x0200    | Recovered from bus off        | Exit CAN bus error "Bus off"                      |
| 0x1000    | Internal software             | Internal software error                           |

#### NOTE



Set SubIndex 3 of Object 0x2320 to 1, to switch off the drive in the event of overcurrent and place it in error status. A value of 0x0101 switches the drive off even if a CAN error exists.

#### NOTE



Set SubIndex 4 of Object 0x2320 to 0, if the error output (Fault Pin) is not to display errors or to 0xFFFF, if all errors (including CAN errors) are to be displayed.

See also [Chapter 3.5 "Special fault output functions"](#) for further information on the error types and [Chapter 4.4 "Emergency Object \(error message\)"](#) for the coding of the emergency error codes.

#### Set Baud Rate

| Index  | Sub-index | Name      | Type      | Attrb. | Default value | Meaning       |
|--------|-----------|-----------|-----------|--------|---------------|---------------|
| 0x2400 | 0         | Baud rate | Unsigned8 | ro     | 0xFF          | Set baud rate |

This object can be used to query which baud rate is set. The index of the set baud rate is returned or 0xFF, if AutoBaud is set.

| Baud rate  | Index | Baud rate | Index |
|------------|-------|-----------|-------|
| 1 000 kBit | 0     | 125 kBit  | 4     |
| 800 kBit   | 1     | 50 kBit   | 6     |
| 500 kBit   | 2     | 20 kBit   | 7     |
| 250 kBit   | 3     | 10 kBit   | 8     |
|            |       | AutoBaud  | 0xFF  |

## 7 Commissioning

### Guide

|   |          |
|---|----------|
| Node number and baud rate                             | Page 98  |
| Basic settings  | Page 100 |
| Configuration using the Motion Manager                | Page 101 |
| Configuration in FAULHABER mode                       | Page 105 |
| Configuration in a drive profile according to CIA 402 | Page 113 |
| Data set management                                   | Page 120 |
| Status display  | Page 121 |

The drive unit must be connected to a PC via a CAN adapter or a host control with CANopen interface in order to make the basic settings for commissioning.

#### NOTE



Connection of the CAN interface is described in the technical manual. For the communication setup, ensure that the same transfer rate is set for all nodes (see [Chapter 2.1 "Set node number and baud rate"](#)) and the terminating resistances are used!

FAULHABER Motion Manager provides a convenient device configuration option using graphic dialogues.

The configuration can also be carried out using your own programming or other CANopen configuration tools.

### 7.1 Node number and baud rate

The node address and transfer rate are set using the network in accordance with the LSS protocol according to CiA DSP305 V1.1 (Layer Setting Services and Protocol).

A configuration tool which supports the LSS protocol is therefore required for the setting, e.g. FAULHABER Motion Manager.

The configuration tool is the LSS Master, and the drives act as LSS Slaves.

LSS Slaves can be configured in two ways:

1. "Switch Mode Global" switches all connected LSS Slaves to configuration mode. However, only one LSS Slave may be connected to set the baud rate and Node-ID.
2. "Switch Mode Selective" switches precisely one LSS Slave in the network to configuration mode. For this, the Vendor ID, Product code, Revision number and Serial number of the node to be addressed must be known.

## 7 Commissioning

### 7.1 Node number and baud rate

The following baud rates (Bit Timing Parameters) can be set:

| Baud rate    | Index |
|--------------|-------|
| 1 000 kBit/s | 0     |
| 800 kBit/s   | 1     |
| 500 kBit/s   | 2     |
| 250 kBit/s   | 3     |
| 125 kBit/s   | 4     |
| 50 kBit/s    | 6     |
| 20 kBit/s    | 7     |
| 10 kBit/s    | 8     |

In addition, Index 0xFF can be used to activate automatic baud rate detection.

The following node numbers can be set:

1 – 127.

Node-ID 255 (0xFF) indicates that the node has not yet been configured, which causes the node to retain in LSS-Init status after it is switched on until a valid node number is transferred to it. Only then is the NMT initialisation continued.

The LSS protocol also supports the reading of LSS addresses, consisting of the Vendor ID, Product code, Revision Number and Serial number of connected units and reading out of the set Node-ID.

Identifiers 0x7E5 (from the Master) and 0x7E4 (from the Slave), on which the protocol is worked through, are used for LSS communication.

Following configuration, the set parameters are backed up in the Flash memory, so that they are available again after switching off and on.

FAULHABER controllers use Vendor ID, Product code and Serial number only to activate the "Switch Mode Selective". 0.0 can always be transferred for the revision number, as this value is ignored in the protocol.

Vendor ID: 327

Product code: 3 150

Please refer to the CiA document DSP 305 for a detailed description of the LSS protocol.

If automatic baud rate detection is activated, the drive can be used in a network with any transmission rate in accordance with the table above and after 3 message frames on the bus line at the latests, the baud rate of the network is detected and the drive has adjusted itself to it. Here it must be noted that the initial message frames cannot be processed and booting takes a little longer.

## 7 Commissioning

### 7.2 Basic settings

In the case of external motion controllers, several basic settings have to be made during the initial start-up to adjust the controller to the connected motor.

If drive units are integrated, these basic settings are made in the factory so it is only necessary to adjust to the respective application.

#### **CAUTION!**



#### **Risk of destruction!**

*Failure to observe these basic settings can result in destruction of components!*

- ▶ *The basic settings described in the following must be noted and observed*

The following basic settings must be made for external motion controllers:

- Motor type or motor data (KN, RM) of the connected motor
- Resolution of an external encoder (ENCRES), if used
- Current limitation values (LCC, LPC), adjusted to the motor type and application
- Controller parameters (POR, I, PP, PD), adjusted to the motor type and application

In addition, FAULHABER Motion Manager can be used to synchronise the Hall sensor signals for smooth start-up and optimisation of the phase angle for the best efficiency.

The configuration must then be adjusted to the respective application for all motion controllers (integrated and external). In particular, the following basic settings are important:

- Operating Mode
- Current limiting values
- Controller parameters
- Function of the digital inputs/outputs

#### **Warning!**



#### **Risk of destruction**

*If using the Fault Pin as input (REFIN, DIRIN), the desired function must be programmed before applying external voltage!*


Configuration of these parameters with the help of the FAULHABER Motion Manager is explained in greater detail in the following chapter.

## 7 Commissioning

### 7.3 Configuration using the Motion Manager

“FAULHABER Motion Manager” PC software provides a simple option for configuring the drive unit and for performing initial tests and optimisation.

The software is available for Microsoft Windows and can be downloaded free of charge from the FAULHABER internet site: [www.faulhaber.com](http://www.faulhaber.com).



Motion control systems with electronics built onto the motor are already pre-parameterised in the factory.

Motion controllers with an externally connected motor must be equipped with current limitation values suitable for the motor and suitable controller parameters before being started up.

The motor selection Wizard is available for selecting the motor and the suitable basic parameters.

Other settings, e.g. for the function of the fault pin, can be made under the “configuration – drive functions” menu item, where a convenient dialog is provided ([Chapter 7.3.3 “Drive configuration”](#)). The configuration dialog is also available for direct access in the wizard bar of the Motion Manager.

A tuning wizard, with which the controller parameters of the speed and positioning controller can be adjusted to the application, is also provided.


## 7 Commissioning

### 7.3 Configuration using the Motion Manager

#### 7.3.1 Connection setting

If no drive nodes are found when the Motion Manager is started, a connection wizard appears. In the first step, the “Motion Controller with CAN-interface” product group must be selected. The connection wizard can also be started at any time via the wizard bar.


##### Connection wizard (Step 1: Selection of the controller)



In the second step, the CAN interface used and, if applicable, the baud rate can be set. Information on the supported CAN interfaces is given in the instruction manual of the Motion Manager or you can contact FAULHABER for information.

The interface found by the driver must then be explicitly adopted again as a once-off action.

##### Connection wizard (Step 2: Selection of Interface)



Devices which are already set to a baud rate are then found by the Motion Manager and are displayed in the Node Explorer.

Devices which have not yet been configured can be assigned a node number and baud rate in a further step.

## 7 Commissioning

---

### 7.3 Configuration using the Motion Manager

#### 7.3.2 Motor selection

External motion controllers must be adjusted to the connected motor.

The Motor Wizard is provided for this purpose; it can be opened via the Wizard bar of the Motion Manager.

After selecting the required FAULHABER motor from a list and setting the sensor type used, as well as entering an inertia factor for the load to be operated, in addition to the motor and current limiting values, suitable controller parameters are also determined and transferred to the drive.

Refer to the Motion Manager instruction manual for details of how to use the Motor Wizard.

#### 7.3.3 Drive configuration

The Motor Wizard has already set sensible default settings for the motor/sensor combination selected.

A configuration dialog with several pages for further drive configuration and adjustment to the required application is available in the Motion Manager's Wizard bar or under the menu item: "Configuration – Drive functions...".

#### **NOTE**



*The CAN node must be in OPERATIONAL state (see [Chapter 4 "CANopen protocol description"](#)) in order to configure the drives.*

*The node can be started using the context menu in the NodeExplorer: "CANopen Network Management-Start Remote Node".*

No settings are transferred to the drive until the "Send" button is pressed. The current state of the drive is also read back and the dialog is updated accordingly. Invalid combinations of settings are corrected at the same time, as they are not accepted by the drive.


The settings are permanently saved in the drive using the "EEPSAV" button.

## 7 Commissioning

### 7.3 Configuration using the Motion Manager

#### 7.3.4 Selection of the operating mode

##### Configuration of the Modes of Operation



The basic operating mode must be selected using the “Modes of Operation” or OPMOD on the first page of the configuration dialogue. FAULHABER Mode with the scope of functions described in [Chapter 3 “Operation in FAULHABER mode”](#) and the drive profiles described in the [Chapter 6 “Functional description of the CANopen CiA 402”](#) are available.



## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### 7.4.1 Basic settings

Within the scope of the commissioning,


- the operating mode
  - and the type of set-point presetting (command source)
- are set in the Basic Settings tab:

**NOTE**



*The "Basic settings" dialog page is only shown in FAULHABER mode.*

#### Basic settings for the motor and encoder type



## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### Encoder type and optimisation

If an incremental encoder attached to the motor is to be evaluated its effective resolution must be given for 4 edge evaluation. If using the internal encoder, no further inputs are necessary.

A button, with which the Optimisation Wizard can be started, is available for adjusting Hall sensor signals and phase angles to the connected motor for externally connected BL motors with analog Hall sensors.

#### **NOTE**



*Ensure that the motor can freely rotate before starting the encoder optimisation.*

#### Controller mode

FAULHABER motion controllers support both main types of operation

- Position control as servo drive.
- Velocity control

The controller mode is partly automatically selected depending on the chosen operating mode.

#### Operating mode

In addition to the controller mode, variations of the operation can also be selected.

The following options are available:

#### CONTMOD

Default setting for the selected controller mode.

For BL motors the actual velocity and actual position in CONTMOD are determined by the motor's Hall sensors.

For DC motors the actual velocity and actual position are determined by the motor's incremental encoder (corresponds to ENCMOD)

CONTMOD for position control: see [Chapter 3.1.1 "Set-point presetting via CAN/PDO2"](#)

CONTMOD for velocity control: see [Chapter 3.2.1 "Target velocity via CAN/PDO2"](#)

#### STEPMOD

Position control

The target position is derived from the number of steps at the AnIn input.

STEPMOD see [Chapter 3.4.1 "Stepper motor mode"](#)

#### APCMOD

Position control

The target position is preset by an analog voltage at the AnIn input.

APCMOD see [Chapter 3.1.2 "Analog positioning mode \(APCMOD\)"](#)

#### ENCMOD with ENCSPEED

Position control with evaluation of an external encoder in BL motors, including for the actual speed.

ENCMOD for position control: see [Chapter 3.1.3 "External encoder as actual position value \(ENCMOD\) - not for MDCD"](#)

## 7 Commissioning

---

### 7.4 Configuration in FAULHABER mode

#### **ENCMOD with HALLSPEED**

Position control with evaluation of an external encoder and the Hall signals for the actual speed of BL motors

ENCMOD for position control: see [Chapter 3.1.3 “External encoder as actual position value \(ENC-MOD\) - not for MCDC”](#)

#### **GEARMOD**

Position control

The target position is determined using the number of steps of an external encoder

GEARMOD see [Chapter 3.4.2 “Gearing mode \(electronic gear\)”](#)

#### **VOLTMOD**

Direct presetting of a voltage amplitude at the motor

VOLTMOD see [Chapter 3.4.3 “Voltage regulator mode”](#)

#### **IxRMOD**

Velocity control without sensors for DC motors

IxRMOD see [Chapter 3.4.5 “IxR control for MCDC”](#)

#### **Set-point presetting**

The set-value presetting must be chosen to match the selected type of operation and controller mode.

The following are supported:

- Set-point presetting via CAN
- Set-point presetting for position or velocity via an analog voltage
- Set-point presetting for position or velocity via a PWM voltage
- Set-point presetting for the limit current via an analog voltage

#### **Power-on state**

In the default state the drive's power stage is initially inactive after power-on.

The power stage can be activated by selecting the “Drive enabled (EN)” checkbox.


## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### 7.4.2 Drive parameters

The Drive Parameters tab is used to make additional settings for the encoder and chosen type of operation.

##### Additional settings for the chosen type of operation



##### Encoder resolution

If an incremental encoder attached to the motor is to be evaluated its effective resolution for 4 edge evaluation must be given.

##### Set-point presetting in stepper or gearing mode

For set-point presetting in stepper mode and in gearing mode the conversion from step count of the external presetting to number of motor revolutions must be given.

##### Example:

Motor has to perform one revolution at 1 000 pulses of the external encoder or at 1 000 steps:

- STW1
- STN1000

Detailed notes on using these parameters are given in the chapters with the functional description of stepper and gearing mode ([Chapter 3.4.1 "Stepper motor mode"](#) and [Chapter 3.4.2 "Gearing mode \(electronic gear\)"](#)).

##### Velocity presetting via an analog voltage

For presetting a velocity via an analog voltage, a threshold value (MAV) can be preset, from which the target value is evaluated starting with the minimum velocity (MV).

Detailed notes on using these parameters are given in the [Chapter 3.2.2 "Velocity presetting via an analog voltage or a PWM signal"](#).

## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### Positioning range limits

In various types of operation the movement range can be monitored and limited. The limits of this movement range can be given in increments of the actual position using the parameter LL

Range monitoring is activated by the APL1 command.

#### Maximum allowable velocity deviation and target corridor

The parameter CORRIDOR defines a range around the target position within which the "Target position reached" flag is set. If required, the target position is signalled asynchronously by a notify.

Within this corridor the D term of the position controller is active and the ramp generator is inactive.


The parameter DEV can be used to preset a maximum allowable controller deviation for the velocity controller. If this barrier is exceeded for longer than set using the parameter DCE in the Inputs and Outputs tab, an error is signalled via the fault pin or via a CANopen Emergency Message.

#### 7.4.3 Controller settings

The changes to the default set controller and current limitation parameters can be made in the "Controller Parameters" tab of the drive configuration dialog.

In addition, under the "Configuration – Digital Filter Settings..." menu item, there is another dialog in which the parameters can be changed online and the result can be observed directly or can be recorded using the trace function in Motion Manager.

#### Digital Filter Settings



The screenshot shows the "Drive Configuration" dialog box with the "Digital Filter Settings" tab selected. The dialog has a title bar with a close button (X) and a menu bar with "Mode", "Basic Settings", "Drive Parameters", "Digital Filter Settings", and "Inputs/Outputs". The main area contains several parameters with spinners and checkboxes:

- Proportional term (POR): 9
- Integral term (I): 16
- Peak current limit (LPC): 7500 mA
- Cont. current limit (LCC): 2500 mA
- Acceleration (AC): 30000 1/s<sup>2</sup>
- Maximum speed (SP): 12000 rpm
- Gain of position controller (PP): 64
- D-term of position cont. (PD): 4
- I-term of current controller (CI): 14
- Deceleration (DEC): 30000 1/s<sup>2</sup>
- Pure sinus commutation, no block commutation in upper velocity range (SIN)
- Sampling rate (SR): 1 1/10 ms

At the bottom of the dialog are four buttons: "Send", "Close", "EEPSAV", and "Help".

## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### Voltage output

By default the Motion Controller for BL motors uses pure sinus commutation. This means the motor runs with the lowest possible losses and noise.

Alternatively, at higher velocities it is possible to also allow overriding of the output signals similar to block commutation. As a result, the whole velocity range of the drive can be used.

#### NOTE



*On changing between pure sinus commutation and operation with block commutation in the upper velocity range the controller amplification is also increased accordingly.*

#### Current controller (LCC, LPC, CI)

The parameter LCC can be used to give the thermally allowable continuous current for the application.

Motors and the motion controller can be overloaded within certain limits. Therefore, higher currents can also be allowed for dynamic processes. The maximum current value is given using the parameter LPC.

Depending on the drive's load, the internal current monitoring limits the output current to the peak current (LPC) or the allowable continuous current (LCC).

#### CAUTION!



#### **Risk of destruction!**

*The thermally allowable continuous current (LCC) should never be given above the thermally allowable continuous current of the motor according to the data sheet.*

*The maximum peak current (LPC) may never be given above the maximum peak output current of the installed electronics.*

The current controller of the motion controller operates as a current limiting controller and therefore in an unlimited case has no effect on the dynamics of the velocity control. The speed of the limitation can be set using the parameter CI. If using the default values for your motor, the current is limited to the allowable value after around 5 ms.

If a FAULHABER motor was selected via the Motor Wizard, parameters are already set here with which the motor can be operated safely.

Further details are given in the [Chapter 3.6.3 "Current controller and I<sub>pt</sub> current limitation"](#).

#### Velocity controller (I, POR, SR)

The velocity controller is implemented as a PI controller. The sampling time SR can be set as multiples of the basic sampling rate, the proportional gain POR and the integral component I can be set.

If a FAULHABER motor was selected via the Motor Wizard, parameters are already set here with which the motor can be operated safely.

If the motor is exposed to additional loads, the inertia of the load must be compensated for by a higher proportional term and if necessary slower sampling; in most applications the integral term can remain unchanged.

Further information on setting and adjustment is given in [Chapter 3.6.7 "Adjustment of the controller parameters"](#).

## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### Ramp generator (AC, DEC, SP)

The ramp generator limits the velocity change at the input of the velocity controller using the parameters AC and DEC and the maximum preset speed using the parameter SP.

The parameters AC and SP can be freely selected depending on the application; the parameter DEC is used to specify the deceleration behaviour in positioning mode. For large loads, the deceleration ramp must be limited using the parameter DEC to achieve dead beat (overshoot-free) run-in in the target position.

Further information on setting and adjustment is given in [Chapter 3.6.1 "Ramp generator"](#).

#### Position controller (PP, PD)

The position controller is implemented as a proportional controller. An additional D term also acts within the target corridor only (see Drive Parameters tab).

The proportional term uses the position deviation in increments to calculate the maximum preset velocity for the underlying velocity controller. The ramp generator is used to additionally limit the acceleration and maximum velocity.


Dead beat run-in in the target position can be preferentially achieved by adjusting the deceleration ramp to the load. For a well-attenuated transient condition in the limit position, the parameter PP must be reduced proportionally to the load inertia.

Further information on setting and adjustment is given in [Chapter 3.6.7 "Adjustment of the controller parameters"](#).

#### 7.4.4 I/O connection and use

The functions of the digital inputs and outputs and homing can be defined in the "Inputs/Outputs" tab of the drive configuration dialog.

#### Configuration of the inputs and outputs



## 7 Commissioning

### 7.4 Configuration in FAULHABER mode

#### Input level and edge

The switching thresholds of the digital inputs are either directly 5V TTL compatible or are adjusted to the switching level of 24 V PLC outputs.

In addition, it is also possible to select which level is to be used as the active level for each input and if the input is to be used as a limit switch (HB/HD).

#### Function of the fault pin

The fault pin can be used both as an input and as an output.

#### CAUTION!



*Do not connect 24V to the fault pin, if the fault pin is configured as a digital output (ERROUT / DIG-OUT / ENCOU)!*

The other settings for the 2<sup>nd</sup> input can only be made if the fault pin is configured as a reference input.

For the default function as a fault output, the parameter DCE can be used to specify a delay time to suppress the response to individual short overcurrent pulses.

For the function as pulse output, the number of pulses per revolution of the motor can be set using the parameter LPN.

In the POSOUT function the output displays the entry into the target corridor as a digital signal (low means target position is reached).

#### Homing

Use as a reference switch can be set for each of the available inputs.

To this end, either the actual position can be set to 0 by an edge at the selected input (SHA), the motor can be stopped (SHL) or a message can be set to the higher level control (SHN). Notification is given by sending the statusword with bit14 = 1 (Hard Notify) on PDO1. The actions can be combined. Homing defined in this way can be executed using the GOHOSEQ command.



## 7 Commissioning

---

### 7.5 Configuration in a drive profile according to CIA 402

#### 7.5.1 Basic settings

**NOTE**

*The "Basic settings" dialog page is only shown in FAULHABER mode.*



#### **Encoder type and optimisation**

If an incremental encoder attached to the motor is to be evaluated its effective resolution must be given for 4 edge evaluation. If using the internal encoder, no further inputs are necessary.

A button, with which the Optimisation Wizard can be started, is available for adjusting Hall sensor signals and phase angles to the connected motor for externally connected BL motors with analog Hall sensors.

**NOTE**

*Ensure that the motor can freely rotate before starting the encoder optimisation.*



## 7 Commissioning

### 7.5 Configuration in a drive profile according to CIA 402

#### Profile selection

In the “Mode” tab of the drive configuration you can select one of the CiA 402 drive profiles under “Modes of Operation”.


If the drive is to be operated with an incremental encoder as position sensor, you can activate this in the selected profile by entering the ENCMOD command in the command line of the Motion Manager.

#### NOTE



Save the selected setting via *EEPSAV* to permanently configure the drive.

#### Selection of the drive profile



#### Controller mode

Operation is supported as a positioning drive, as a speed-controlled drive as well as the homing methods.


## 7 Commissioning

### 7.5 Configuration in a drive profile according to CIA 402

#### 7.5.2 Drive parameters

The “Drive Parameters” tab is used to make additional settings for the encoder and chosen type of operation.

##### Additional settings for the chosen type of operation



The screenshot shows the 'Drive Configuration' window with the 'Drive Parameters' tab selected. The interface includes the following settings:

- Position range limits (LL):** from: -1800000000 to: 1800000000 Inc.  Activate Position Limits (APL)
- Allowed Deviation (DEV):** 30000 rpm Target win. (CORRIDOR): 20
- Analog Velocity Control:**
  - Start voltage (MAV): 25 mV
  - Minimum velocity (MV): 0 rpm
  - Direction of Rotation:**
    - right-hand (ADR)
    - left-hand (ADL)
- Stepper Motor and Gearing Mode:**
  - Step width (STW): 1
  - Step number (STN): 1000 Steps per revolution
- D.C. motor and BL motor in Encoder Mode:**
  - Resolution of external encoder (ENCRES): 2048 Inc. / Rev. (quad pulse number)

Buttons at the bottom: Send, Close, EEPsAV, Help.

##### Encoder resolution

If an incremental encoder attached to the motor is to be evaluated its effective resolution for 4 edge evaluation must be given.

##### Positioning range limits

In various types of operation the movement range can be monitored and limited. The limits of this movement range can be given in increments of the actual position using the parameter LL.

##### Maximum allowable velocity deviation and target corridor

The parameter CORRIDOR defines a range around the target position within which the “Target reached” flag is set in the statusword. If transmission type 255 is configured for the TxPDO1 (default setting), the target position is signalled by an asynchronously set PDO. Within this corridor the D term of the position controller is active and the ramp generator is inactive.

The parameter DEV can be used to preset a maximum allowable controller deviation for the velocity controller. If this barrier is exceeded for longer than set using the parameter DCE in the Inputs and Outputs tab, an error is signalled via the fault pin or via a CANopen Emergency Message.

## 7 Commissioning


### 7.5 Configuration in a drive profile according to CIA 402

#### 7.5.3 Controller setting

The changes to the default set controller and current limitation parameters can be made in the “Digital Filter Settings” tab of the drive configuration dialog.

In addition, under the “Configuration – Digital Filter Settings...” menu item, there is another dialog in which the parameters can be changed online and the result can be observed directly or can be recorded using the trace function in Motion Manager.

#### Digital Filter Settings



| Parameter                          | Value | Unit             |
|------------------------------------|-------|------------------|
| Proportional term (POR):           | 6     |                  |
| Integral term (I):                 | 50    |                  |
| Peak current limit (LPC):          | 10000 | mA               |
| Cont. current limit (LCC):         | 5000  | mA               |
| Acceleration (AC):                 | 30000 | 1/s <sup>2</sup> |
| Maximum speed (SP):                | 15000 | rpm              |
| Gain of position controller (PP):  | 10    |                  |
| D-term of position cont. (PD):     | 5     |                  |
| I-term of current controller (CI): | 40    |                  |
| Deceleration (DEC):                | 30000 | 1/s <sup>2</sup> |

Pure sinus commutation, no block commutation in upper velocity range (SIN)

Sampling rate (SR): 1 x internal sampling rate

Buttons: Send, Close, EEPsAV, Help

#### Voltage output

By default the motion controller uses pure sinus commutation. This means the motor runs with the lowest possible losses and noise.

Alternatively, at higher velocities it is possible to also allow overriding of the output signals similar to block commutation. As a result, the whole velocity range of the drive can be used.

#### NOTE



*On changing between pure sinus commutation and operation with block commutation in the upper velocity range the controller amplification is also increased accordingly.*

## 7 Commissioning

### 7.5 Configuration in a drive profile according to CIA 402

#### Current controller (LCC, LPC, CI)

The parameter LCC can be used to give the thermally allowable continuous current for the application.

Motors and the motion controller can be overloaded within certain limits. Therefore, higher currents can also be allowed for dynamic processes. The maximum current value is given using the parameter LPC.

Depending on the drive's load, the internal current monitoring limits the output current to the peak current (LPC) or the allowable continuous current (LCC).

#### **CAUTION!**



#### **Risk of destruction!**

*The thermally allowable continuous current (LCC) should never be given above the thermally allowable continuous current of the motor according to the data sheet.*

*The maximum peak current (LPC) may never be given above the maximum peak output current of the installed electronics.*

The current controller of the motion controller operates as a current limiting controller and therefore in an unlimited case has no effect on the dynamics of the velocity control. The speed of the limitation can be set using the parameter CI. If using the default values for your motor, the current is limited to the allowable value after around 5ms.

If a FAULHABER motor was selected on the basic settings page, parameters are already set here with which the motor can be safely operated.

Further details are given in the [Chapter 3.6.3 "Current controller and I<sup>2</sup>t current limitation"](#).

#### Velocity controller (I, POR, SR)

The velocity controller is implemented as a PI controller. The sampling time SR can be set as multiples of the drive's basic sampling rate, the proportional amplification POR and the integral term I.

If a FAULHABER motor was selected on the basic settings page, parameters are already set here with which the motor can be safely operated.

If the motor is exposed to additional loads, the inertia of the load must be compensated for by a higher proportional term and if necessary slower sampling; in most applications the integral term can remain unchanged.

Further information on setting and adjustment is given in [Chapter 3.6.7 "Adjustment of the controller parameters"](#).

#### Ramp generator (AC, DEC, SP)

The ramp generator limits the velocity change at the input of the velocity controller using the parameters AC and DEC and the maximum preset speed using the parameter SP.

The parameters AC and SP can be freely selected depending on the application; the parameter DEC is used to specify the deceleration behaviour in positioning mode. For large loads, the deceleration ramp must be limited using the parameter DEC to achieve dead beat (overshoot-free) run-in in the target position.

Further information on setting and adjustment is given in [Chapter 3.6.1 "Ramp generator"](#).

## 7 Commissioning

### 7.5 Configuration in a drive profile according to CIA 402

#### Position controller (PP, PD)

The position controller is implemented as a proportional controller. An additional D term also acts within the target corridor only (see Drive Parameters tab).

The proportional term uses the position deviation in increments to calculate the maximum preset velocity for the underlying velocity controller. The ramp generator is used to additionally limit the acceleration and maximum velocity.


Dead beat run-in in the target position can be preferentially achieved by adjusting the deceleration ramp to the load. For a well-attenuated transient condition in the limit position, the parameter PP must be reduced proportionally to the load inertia.

Further information on setting and adjustment is given in [Chapter 3.6.7 "Adjustment of the controller parameters"](#).

#### 7.5.4 I/O connection and use

The function of the digital inputs and outputs can be defined in the "Inputs/Outputs" tab of the drive configuration dialogue.

#### Configuration of the inputs and outputs



#### Input level and edge

The switching thresholds of the digital inputs are either directly 5V TTL compatible or are adjusted to the switching level of 24 V PLC outputs.

Precise information on the thresholds is given in the drive's data sheet.

## 7 Commissioning

---

### 7.5 Configuration in a drive profile according to CIA 402

#### Function of the fault pin

The fault pin can be used both as an input and as an output. The basic function can be selected using the radiobuttons.

The other settings for the 2<sup>nd</sup> input can only be made if the fault pin is configured as a reference input.

For the default function as a fault output, the parameter DCE can be used to specify a delay time to suppress the response to individual short overcurrent pulses.

For the function as pulse output, the number of pulses per revolution can be set using the parameter LPN.

## 7 Commissioning

---

### 7.6 Data set management

#### Save parameters

The settings of a drive can be saved as a backup or as a file for configuration of other drives.

The Motion Manager offers the option of reading out the current drive configuration and saving it as a parameter file.

#### Transfer parameters to the drive

Previously saved parameter files can be opened in Motion Manager, edited if necessary and transferred to the drive.

#### **NOTE**

*Execute the SAVE or EEPSAV command to permanently save a transferred parameter set in the drive.*





## 7 Commissioning


### 7.7 Status display

The status display is used for continuous checking of the main operating states.

Internal states, error flags and the state of the digital inputs are signalled. In addition, the internally measured housing temperature is also displayed here.

The display is updated by Motion Manager by means of cyclical querying of the internal states.

#### Display of the operating state



#### Internal states

Partially autonomous states of the motion controller are displayed. This is the course of homing.

Other internal states are on the one hand the error flag and the housing temperature.

The current limitation flag is set if the maximum current has been set to the continuous current (LCC) by the i<sup>2</sup>t monitoring.

#### States of digital inputs

The state of the digital inputs is displayed as On or Off depending on the level setting

#### Status of the limit switches

The display indicates whether one of the limit switches has switched, even if the assigned input is already back in the idle state.

#### 7.7.1 Trace function

Motion Manager provides a trace function as an additional diagnosis tool with which the internal parameters can be graphically recorded. This enables the dynamic behaviour of the drive to be monitored, which is useful, e.g. for optimisation of the controller parameters.

## 8 Parameter description

### 8.1 Communication objects according to CiA 301

#### Device Type

| Index  | Sub-index | Name        | Type       | Attrb. | Default value | Meaning                          |
|--------|-----------|-------------|------------|--------|---------------|----------------------------------|
| 0x1000 | 0         | device type | Unsigned32 | ro     | 0x00020192    | Specification of the device type |

Contains information on the device type, divided into two 16-bit fields:

|                        |                       |
|------------------------|-----------------------|
| byte: MSB              | LSB                   |
| Additional information | Device Profile Number |

Device Profile Number = 0x192 (402d)

#### Error Register

| Index  | Sub-index | Name           | Type      | Attrb. | Default value | Meaning        |
|--------|-----------|----------------|-----------|--------|---------------|----------------|
| 0x1001 | 0         | error register | Unsigned8 | ro     |               | Error register |

The error register contains, bit coded, the types of errors that have most recently occurred. For a description of the error register, see [Chapter 4.4 "Emergency Object \(error message\)"](#).

#### Pre-defined Error Field (error memory)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning                 |
|--------|-----------|----------------------|------------|--------|---------------|-------------------------|
| 0x1003 | 0         | number of errors     | Unsigned8  | rw     |               | Number of stored errors |
|        | 1         | standard error field | Unsigned32 | ro     |               | Last error              |
|        | 2         | standard error field | Unsigned32 | ro     |               | Further errors...       |

The error memory contains the coding of the last error to occur. The standard error field is divided into two 16-bit fields:

|                        |            |
|------------------------|------------|
| byte: MSB              | LSB        |
| Additional information | Error code |

The meaning of the individual error codes is described in [Chapter 4.4 "Emergency Object \(error message\)"](#).

The error memory is deleted by writing "0" on subindex 0.

#### COB-ID SYNC

| Index  | Sub-index | Name        | Type       | Attrb. | Default value | Meaning                                  |
|--------|-----------|-------------|------------|--------|---------------|--|
| 0x1005 | 0         | COB-ID SYNC | Unsigned32 | rw     | 0x80          | CAN object identifier of the SYNC object |

## 8 Parameter description

### 8.1 Communication objects according to CiA 301

#### Manufacturer Device Name

| Index  | Sub-index | Name                     | Type       | Attrb. | Default value | Meaning     |
|--------|-----------|--------------------------|------------|--------|---------------|-------------|
| 0x1008 | 0         | manufacturer device name | Vis-String | const  |               | Device name |

Use the segmented SDO protocol to read out the device name, as it can be larger than 4 bytes.

#### Manufacturer Hardware Version

| Index  | Sub-index | Name                          | Type       | Attrb. | Default value | Meaning          |
|--------|-----------|-------------------------------|------------|--------|---------------|------------------|
| 0x1009 | 0         | manufacturer hardware version | Vis-String | const  |               | Hardware Version |

Use the segmented SDO protocol to read out the hardware version, as it can be larger than 4 bytes.

#### Manufacturer Software Version

| Index  | Sub-index | Name                          | Type       | Attrb. | Default value | Meaning          |
|--------|-----------|-------------------------------|------------|--------|---------------|------------------|
| 0x100A | 0         | manufacturer software version | Vis-String | const  |               | Software Version |

Use the segmented SDO protocol to read out the software version, as it can be larger than 4 bytes.

#### Guard Time

| Index  | Sub-index | Name       | Type       | Attrb. | Default value | Meaning                           |
|--------|-----------|------------|------------|--------|---------------|-----------------------------------|
| 0x100C | 0         | guard time | Unsigned16 | rw     | 0             | Monitoring time for Node Guarding |

Specification of the Guard Time in milliseconds, 0 switches off the monitoring.

#### Life Time Factor

| Index  | Sub-index | Name             | Type      | Attrb. | Default value | Meaning                      |
|--------|-----------|------------------|-----------|--------|---------------|------------------------------|
| 0x100D | 0         | life time factor | Unsigned8 | rw     | 0             | Time factor for lifeguarding |

The Life Time Factor multiplied by the Guard Time gives the Life Time for the Node Guarding Protocol (see [Chapter 5.6 "NMT \(Network Management\)"](#)). 0 switches off lifeguarding.

#### Store Parameters

| Index  | Sub-index | Name                          | Type       | Attrb. | Default value | Meaning                            |
|--------|-----------|-------------------------------|------------|--------|---------------|------------------------------------|
| 0x1010 | 0         | number of entries             | Unsigned8  | ro     | 3             | Number of object entries           |
|        | 1         | save all parameters           | Unsigned32 | rw     | 1             | Saves all parameters               |
|        | 2         | save communication parameters | Unsigned32 | rw     | 1             | Save communication parameters only |
|        | 3         | save application parameters   | Unsigned32 | rw     | 1             | Save application parameters only   |

This object saves configuration parameters in the non-volatile Flash memory. Read access provides information about the storage options.

## 8 Parameter description

### 8.1 Communication objects according to CiA 301

The storage process is triggered by writing the “save” signature on the relevant subindex:

| Signature             | MSB |     | LSB |     |
|-----------------------|-----|-----|-----|-----|
| ISO 8859<br>("ASCII") | e   | v   | a   | s   |
| hex                   | 65h | 76h | 61h | 73h |

The object corresponds to the FAULHABER SAVE command.

#### CAUTION!



#### Flash memory

The Flash memory is designed for 10 000 write cycles. If this command is executed more than 10 000 times, the function of the Flash memory can no longer be guaranteed.

- ▶ Do not execute command more than 10 000 times.

#### Restore Default Parameters

| Index  | Sub-index | Name                                     | Type       | Attrb. | Default value | Meaning                                    |
|--------|-----------|--|------------|--------|---------------|--|
| 0x1011 | 0         | number of entries                        | Unsigned8  | ro     | 3             | Number of object entries                   |
|        | 1         | restore all default parameters           | Unsigned32 | rw     | 1             | Loads all default parameters               |
|        | 2         | restore default communication parameters | Unsigned32 | rw     | 1             | Load default communication parameters only |
|        | 3         | restore default application parameters   | Unsigned32 | rw     | 1             | Load default application parameters only   |

This object loads the default configuration parameters (status on delivery).

Read access provides information about the restore options.

The restore process is triggered by writing the “load” signature on the relevant subindex:

| Signature | MSB |     | LSB |     |
|-----------|-----|-----|-----|-----|
| ASCII     | d   | a   | o   | l   |
| hex       | 64h | 61h | 6Fh | 6Ch |

The parameters are not set to the default values until the next boot process (reset).

If the default parameters are to be finally saved, a Save command must be executed after the reset.

#### COB-ID Emergency Message

| Index  | Sub-index | Name        | Type       | Attrb. | Default value  | Meaning                                       |
|--------|-----------|-------------|------------|--------|----------------|---|
| 0x1014 | 0         | COB-ID EMCY | Unsigned32 | ro     | 0x80 + Node ID | CAN object identifier of the Emergency Object |

## 8 Parameter description

### 8.1 Communication objects according to CiA 301

#### Identity Object

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                                 |
|--------|-----------|-------------------|------------|--------|---------------|---|
| 0x1018 | 0         | Number of entries | Unsigned8  | ro     | 4             | Number of object entries                |
|        | 1         | Vendor ID         | Unsigned32 | ro     | 327           | Manufacturer ID number (FAULHABER: 327) |
|        | 2         | Product code      | Unsigned32 | ro     | 3 150         | Product ID number                       |
|        | 3         | Revision number   | Unsigned32 | ro     |               | Version number                          |
|        | 4         | Serial number     | Unsigned32 | ro     |               | Serial No.                              |

#### Server SDO Parameter

| Index  | Sub-index | Name                        | Type       | Attrb. | Default value   | Meaning                                   |
|--------|-----------|-----------------------------|------------|--------|-----------------|---|
| 0x1200 | 0         | number of entries           | Unsigned8  | ro     | 2               | Number of object entries                  |
|        | 1         | COB-ID Client → server (rx) | Unsigned32 | ro     | 0x600 + Node ID | CAN object identifier of the server RxSDO |
|        | 2         | COB-ID Server → client (tx) | Unsigned32 | ro     | 0x580 + Node ID | CAN object identifier of the server TxSDO |

#### Receive PDO1 Communication Parameter

| Index  | Sub-index | Name              | Type       | Attrb. | Default value   | Meaning                                    |
|--------|-----------|-------------------|------------|--------|-----------------|--|
| 0x1400 | 0         | number of entries | Unsigned8  | ro     | 2               | Number of object entries                   |
|        | 1         | COB-ID            | Unsigned32 | ro     | 0x200 + Node ID | CAN object identifier of the server RxPDO1 |
|        | 2         | transmission type | Unsigned8  | rw     | 255             | PDO transmission type                      |

#### Receive PDO2 Communication Parameter

| Index  | Sub-index | Name              | Type       | Attrb. | Default value   | Meaning                                    |
|--------|-----------|-------------------|------------|--------|-----------------|--|
| 0x1401 | 0         | number of entries | Unsigned8  | ro     | 2               | Number of object entries                   |
|        | 1         | COB-ID            | Unsigned32 | ro     | 0x300 + Node ID | CAN object identifier of the server RxPDO2 |
|        | 2         | transmission type | Unsigned8  | rw     | 255             | PDO transmission type                      |

#### Receive PDO3 Communication Parameter

| Index  | Sub-index | Name              | Type       | Attrb. | Default value   | Meaning                                    |
|--------|-----------|-------------------|------------|--------|-----------------|--|
| 0x1402 | 0         | number of entries | Unsigned8  | ro     | 2               | Number of object entries                   |
|        | 1         | COB-ID            | Unsigned32 | ro     | 0x400 + Node ID | CAN object identifier of the server RxPDO3 |
|        | 2         | transmission type | Unsigned8  | rw     | 255             | PDO transmission type                      |

#### Receive PDO1 Mapping Parameter

| Index  | Sub-index | Name                                | Type       | Attrb. | Default value | Meaning                                  |
|--------|-----------|-------------------------------------|------------|--------|---------------|--|
| 0x1600 | 0         | number of entries                   | Unsigned8  | ro     | 1             | Number of object entries                 |
|        | 1         | 1 <sup>st</sup> object to be mapped | Unsigned32 | ro     | 0x60400010    | Reference to 16 bit controlword (0x6040) |

## 8 Parameter description

### 8.1 Communication objects according to CiA 301

#### Receive PDO2 Mapping Parameter

| Index  | Sub-index | Name                                | Type       | Attrb. | Default value | Meaning                              |
|--------|-----------|-------------------------------------|------------|--------|---------------|--------------------------------------|
| 0x1601 | 0         | number of entries                   | Unsigned8  | ro     | 2             | Number of object entries             |
|        | 1         | 1 <sup>st</sup> object to be mapped | Unsigned32 | ro     | 0x23010108    | Reference to 8 bit FAULHABER command |
|        | 2         | 2 <sup>nd</sup> object to be mapped | Unsigned32 | ro     | 0x23010220    | Reference to 32 bit command argument |

#### Receive PDO3 Mapping Parameter

| Index  | Sub-index | Name                                | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|-------------------------------------|------------|--------|---------------|--|
| 0x1602 | 0         | number of entries                   | Unsigned8  | ro     | 5             | Number of object entries                           |
|        | 1         | 1 <sup>st</sup> object to be mapped | Unsigned32 | ro     | 0x23030108    | Reference to 8 bit trace mode for Parameter 1      |
|        | 2         | 2 <sup>nd</sup> object to be mapped | Unsigned32 | ro     | 0x23030208    | Reference to 8 bit trace mode for Parameter 2      |
|        | 3         | 3 <sup>rd</sup> object to be mapped | Unsigned32 | ro     | 0x23030308    | Reference to 8 bit trace time code setting         |
|        | 4         | 4 <sup>th</sup> object to be mapped | Unsigned32 | ro     | 0x23030408    | Reference to 8 bit trace value "number of packets" |
|        | 5         | 5 <sup>th</sup> object to be mapped | Unsigned32 | ro     | 0x23030508    | Reference to 8 bit trace value "time interval"     |

#### Transmit PDO1 Communication Parameter

| Index  | Sub-index | Name              | Type       | Attrb. | Default value   | Meaning  |
|--------|-----------|-------------------|------------|--------|-----------------|--|
| 0x1800 | 0         | number of entries | Unsigned8  | ro     | 2               | Number of object entries                       |
|        | 1         | COB-ID            | Unsigned32 | ro     | 0x180 + Node ID | CAN object identifier of the TxPDO1            |
|        | 2         | transmission type | Unsigned8  | rw     | 255             | PDO transmission type<br>Default: asynchronous |

#### Transmit PDO2 Communication Parameter

| Index  | Sub-index | Name              | Type       | Attrb. | Default value   | Meaning   |
|--------|-----------|-------------------|------------|--------|-----------------|---|
| 0x1801 | 0         | number of entries | Unsigned8  | ro     | 2               | Number of object entries  |
|        | 1         | COB-ID            | Unsigned32 | ro     | 0x280 + Node ID | CAN object identifier of the TxPDO2                             |
|        | 2         | transmission type | Unsigned8  | rw     | 253             | PDO transmission type<br>Default: asynchronous on request (RTR) |

#### Transmit PDO3 Communication Parameter

| Index  | Sub-index | Name              | Type       | Attrb. | Default value   | Meaning  |
|--------|-----------|-------------------|------------|--------|-----------------|--|
| 0x1802 | 0         | number of entries | Unsigned8  | ro     | 2               | Number of object entries   |
|        | 1         | COB-ID            | Unsigned32 | ro     | 0x380 + Node ID | CAN object identifier of the TxPDO3                                      |
|        | 2         | transmission type | Unsigned8  | rw     | 253             | PDO transmission type<br>asynchronous on request (RTR)<br>or synchronous |

## 8 Parameter description

### 8.1 Communication objects according to CiA 301

#### Transmit PDO1 Mapping Parameter

| Index  | Sub-index | Name                                | Type       | Attrb. | Default value | Meaning                                 |
|--------|-----------|-------------------------------------|------------|--------|---------------|---|
| 0x1A00 | 0         | number of entries                   | Unsigned8  | ro     | 1             | Number of object entries                |
|        | 1         | 1 <sup>st</sup> object to be mapped | Unsigned32 | ro     | 0x60410010    | Reference to 16 bit statusword (0x6041) |

#### Transmit PDO2 Mapping Parameter

| Index  | Sub-index | Name                                | Type       | Attrb. | Default value | Meaning                              |
|--------|-----------|-------------------------------------|------------|--------|---------------|--------------------------------------|
| 0x1A01 | 0         | number of entries                   | Unsigned8  | ro     | 3             | Number of object entries             |
|        | 1         | 1 <sup>st</sup> object to be mapped | Unsigned32 | ro     | 0x23010108    | Reference to 8 bit FAULHABER command |
|        | 2         | 2 <sup>nd</sup> object to be mapped | Unsigned32 | ro     | 0x23020120    | Reference to 32 bit value            |
|        | 3         | 3 <sup>rd</sup> object to be mapped | Unsigned8  | ro     | 0x23020208    | Reference to 8 bit error code        |

#### Transmit PDO3 Mapping Parameter

| Index  | Sub-index | Name                                | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|-------------------------------------|------------|--------|---------------|--|
| 0x1A02 | 0         | number of entries                   | Unsigned8  | ro     | 3             | Number of object entries                       |
|        | 1         | 1 <sup>st</sup> object to be mapped | Unsigned32 | ro     | 0x23040120    | Reference to 32 bit trace value of Parameter 1 |
|        | 2         | 2 <sup>nd</sup> object to be mapped | Unsigned32 | ro     | 0x23040220    | Reference to 32 bit trace value of Parameter 2 |
|        | 3         | 3 <sup>rd</sup> object to be mapped | Unsigned32 | ro     | 0x23040308    | Reference to 8 bit timecode                    |

## 8 Parameter description

### 8.2 Manufacturer-specific objects

#### FAULHABER Command

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                            |
|--------|-----------|-------------------|------------|--------|---------------|------------------------------------|
| 0x2301 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries           |
|        | 1         | command           | Unsigned8  | rw     | 0             | Command byte for FAULHABER channel |
|        | 2         | argument          | Unsigned32 | rw     | 0             | Argument for FAULHABER command     |

This object is written by RxPDO2 and always contains the last FAULHABER command to be transmitted.

#### Return value of FAULHABER Command

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                                  |
|--------|-----------|-------------------|------------|--------|---------------|--|
| 0x2302 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                 |
|        | 1         | value             | Unsigned32 | ro     | 0             | Argument for FAULHABER command           |
|        | 2         | error             | Unsigned8  | ro     | 0             | Error code: 1 = OK, for other errors see |

The content of this object is requested by a request (RTR) on TxPDO2 and delivers the return value for commands on the FAULHABER channel.

#### Trace Configuration

| Index  | Sub-index | Name              | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|-------------------|-----------|--------|---------------|---|
| 0x2303 | 0         | number of entries | Unsigned8 | ro     | 5             | Number of object entries                        |
|        | 1         | mode1             | Unsigned8 | rw     | 0             | Trace mode for Parameter 1                      |
|        | 2         | mode2             | Unsigned8 | rw     | 0             | Trace mode for Parameter 2                      |
|        | 3         | time code         | Unsigned8 | rw     | 1             | Data with time code                             |
|        | 4         | packets           | Unsigned8 | rw     | 1             | Number of packets to be transmitted per request |
|        | 5         | period            | Unsigned8 | rw     | 1             | Time interval between packets                   |

This object is written by RxPDO3 and always contains the last trace setting to be sent.

#### Trace Data

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                   |
|--------|-----------|-------------------|------------|--------|---------------|---------------------------|
| 0x2304 | 0         | number of entries | Unsigned8  | ro     | 3             | Number of object entries  |
|        | 1         | value1            | Unsigned32 | ro     | 0             | Last value of Parameter 1 |
|        | 2         | value2            | Unsigned32 | ro     | 0             | Last value of Parameter 2 |
|        | 3         | time code         | Unsigned8  | ro     | 0             | Last time code value      |

The content of this object is requested by a request (RTR) on TxPDO3 and delivers the trace data of the set parameters. The values last requested are always temporarily stored here.



## 8 Parameter description

### 8.2 Manufacturer-specific objects

#### FAULHABER Fault Register

| Index  | Subindex | Name                    | Type       | Attrb. | Default value | Meaning  |
|--------|----------|-------------------------|------------|--------|---------------|--|
| 0x2320 | 0        | number of entries       | Unsigned8  | ro     | 4             | Number of object entries   |
|        | 1        | internal fault register | Unsigned16 | ro     | 0             | Current internal fault<br>0 = No fault   |
|        | 2        | emergency mask          | Unsigned16 | rw     | 0x00FF        | Faults which trigger an emergency message frame                                      |
|        | 3        | fault mask              | Unsigned16 | rw     | 0             | Faults which are treated as DSP402 faults and affect the state machine (fault state) |
|        | 4        | errout mask             | Unsigned16 | rw     | 0x00FF        | Faults which set the error output  |

The error coding described in [Chapter 6.8 "Error handling"](#) applies to the FAULHABER error register and the error mask.

#### Set baud rate

| Index  | Subindex | Name      | Type      | Attrb. | Default value | Meaning       |
|--------|----------|-----------|-----------|--------|---------------|---------------|
| 0x2400 | 0        | Baud rate | Unsigned8 | ro     | 0xFF          | Set baud rate |

This object can be used to query which baud rate is set. The index of the set baud rate is returned or 0xFF, if AutoBaud is set.

| Baud rate  | Index | Baud rate | Index |
|------------|-------|-----------|-------|
| 1 000 kBit | 0     | 125 kBit  | 4     |
| 800 kBit   | 1     | 50 kBit   | 6     |
| 500 kBit   | 2     | 20 kBit   | 7     |
| 250 kBit   | 3     | 10 kBit   | 8     |
|            |       | AutoBaud  | 0xFF  |

## 8 Parameter description

### 8.3 Drive profile objects according to CiA 402

#### Controlword (0x6040)

| Index  | Sub-index | Name        | Type       | Attrb. | Default value | Meaning       |
|--------|-----------|-------------|------------|--------|---------------|---------------|
| 0x6040 | 0         | controlword | Unsigned16 | rw     |               | Drive control |

The bits in the controlword are described in [Chapter 6.1 "Device Control"](#).

#### Statusword (0x6041)

| Index  | Sub-index | Name       | Type       | Attrb. | Default value | Meaning        |
|--------|-----------|------------|------------|--------|---------------|----------------|
| 0x6041 | 0         | statusword | Unsigned16 | ro     |               | Status display |

The bits in the statusword are described in [Chapter 6.1 "Device Control"](#).

#### Modes of Operation (0x6060)

| Index  | Sub-index | Name               | Type     | Attrb. | Default value | Meaning                   |
|--------|-----------|--------------------|----------|--------|---------------|---------------------------|
| 0x6060 | 0         | modes of operation | Integer8 | wo     | 1             | Operating mode changeover |

FAULHABER Motion Control systems support the following operating modes:

- 1 CiA 402 Profile Position Mode (position control)
- 3 CiA 402 Profile Velocity Mode (velocity control)
- 6 CiA 402 Homing Mode (homing)
- 1 FAULHABER specific operating mode

#### Modes of Operation Display (0x6061)

| Index  | Sub-index | Name                       | Type     | Attrb. | Default value | Meaning                           |
|--------|-----------|----------------------------|----------|--------|---------------|-----------------------------------|
| 0x6061 | 0         | modes of operation display | Integer8 | ro     | 1             | Display of the set operating mode |

The set operating mode can be queried here, the meaning of the return values corresponds to the values of the object 0x6060.

#### Position Demand Value (0x6062)

| Index  | Sub-index | Name                  | Type      | Attrb. | Default value | Meaning  |
|--------|-----------|-----------------------|-----------|--------|---------------|--|
| 0x6062 | 0         | position demand value | Integer32 | ro     |               | Last target position (scaled according to the position factor) |

#### Position Actual Value (0x6063)

| Index  | Sub-index | Name                  | Type      | Attrb. | Default value | Meaning                      |
|--------|-----------|-----------------------|-----------|--------|---------------|------------------------------|
| 0x6063 | 0         | position actual value | Integer32 | ro     |               | Actual position (increments) |

## 8 Parameter description

### 8.3 Drive profile objects according to CiA 402

#### Position Actual Value (0x6064)

| Index  | Sub-index | Name                  | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|-----------------------|-----------|--------|---------------|---|
| 0x6064 | 0         | position actual value | Integer32 | ro     |               | Actual position (scaled according to the position factor) |

#### Position Window (0x6067)

| Index  | Sub-index | Name            | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|-----------------|------------|--------|---------------|--|
| 0x6067 | 0         | position window | Unsigned32 | rw     | 20            | Target position window (scaled according to the position factor) |

#### Position Window Time (0x6068)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning                              |
|--------|-----------|----------------------|------------|--------|---------------|--------------------------------------|
| 0x6068 | 0         | position window time | Unsigned16 | rw     | 200           | Time in target position window in ms |

#### Velocity Sensor Actual Value (0x6069)

| Index  | Sub-index | Name                         | Type      | Attrb. | Default value | Meaning  |
|--------|-----------|------------------------------|-----------|--------|---------------|--|
| 0x6069 | 0         | velocity sensor actual value | Integer32 | ro     |               | Actual velocity (scaled according to the encoder resolution) |

#### Velocity Demand Value (0x606B)

| Index  | Sub-index | Name                  | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|-----------------------|-----------|--------|---------------|---|
| 0x606B | 0         | velocity demand value | Integer32 | ro     |               | Target velocity (scaled according to the velocity factor) |

#### Velocity Actual Value (0x606C)

| Index  | Sub-index | Name                  | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|-----------------------|-----------|--------|---------------|---|
| 0x606C | 0         | velocity actual value | Integer32 | ro     |               | Actual velocity (scaled according to the velocity factor) |

#### Velocity Window (0x606D)

| Index  | Sub-index | Name            | Type       | Attrb. | Default value | Meaning   |
|--------|-----------|-----------------|------------|--------|---------------|---|
| 0x606D | 0         | velocity window | Unsigned16 | rw     | 20            | End velocity window (scaled according to the velocity factor) |

#### Velocity Window Time (0x606E)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning                     |
|--------|-----------|----------------------|------------|--------|---------------|-----------------------------|
| 0x606E | 0         | velocity window time | Unsigned16 | rw     | 200           | Time in end velocity window |

## 8 Parameter description

### 8.3 Drive profile objects according to CiA 402

#### Velocity Threshold (0x606F)

| Index  | Sub-index | Name               | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|--------------------|------------|--------|---------------|--|
| 0x606F | 0         | velocity threshold | Unsigned16 | rw     | 20            | Velocity threshold value (scaled according to the velocity factor) |

#### Velocity Threshold Time (0x6070)

| Index  | Sub-index | Name                    | Type       | Attrb. | Default value | Meaning                                       |
|--------|-----------|-------------------------|------------|--------|---------------|---|
| 0x6070 | 0         | velocity threshold time | Unsigned16 | rw     | 20            | Time below the velocity threshold value in ms |

#### Target Position (0x607A)

| Index  | Sub-index | Name            | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|-----------------|-----------|--------|---------------|---|
| 0x607A | 0         | Target position | Integer32 | rw     |               | Target position (scaled according to the position factor) |

#### Homing Offset (0x607C)

| Index  | Sub-index | Name          | Type      | Attrb. | Default value | Meaning   |
|--------|-----------|---------------|-----------|--------|---------------|---|
| 0x607C | 0         | homing offset | Integer32 | rw     | 0             | Zero point displacement from the reference position (scaled according to the position factor) |

#### Software Position Limit (0x607D)

| Index  | Sub-index | Name               | Type      | Attrb. | Default value     | Meaning                       |
|--------|-----------|--------------------|-----------|--------|-------------------|-------------------------------|
| 0x607D | 0         | number of entries  | Unsigned8 | ro     | 2                 | Number of object entries      |
|        | 1         | min position limit | Integer32 | rw     | $-1.8 \cdot 10^9$ | Lower positioning range limit |
|        | 2         | max position limit | Integer32 | rw     | $+1.8 \cdot 10^9$ | Upper positioning range limit |

Each scaled according to the position factor.

#### Polarity (0x607E)

| Index  | Sub-index | Name     | Type      | Attrb. | Default value | Meaning               |
|--------|-----------|----------|-----------|--------|---------------|-----------------------|
| 0x607E | 0         | polarity | Unsigned8 | rw     | 0             | Direction of rotation |

The entries in this object can be used to change the direction of rotation of the connected encoder for the supported operating modes:

Bit 7 = 1 → negative direction of rotation in positioning mode

Bit 6 = 1 → negative direction of rotation in velocity mode

## 8 Parameter description

### 8.3 Drive profile objects according to CiA 402

#### Max Profile Velocity (0x607F)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|----------------------|------------|--------|---------------|--|
| 0x607F | 0         | max profile velocity | Unsigned32 | rw     | *)            | Maximum velocity (scaled according to the velocity factor) |

\*) Dependent on the factory configuration of the motion controller

#### Profile Velocity (0x6081)

| Index  | Sub-index | Name             | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|------------------|------------|--------|---------------|--|
| 0x6081 | 0         | profile velocity | Unsigned32 | rw     | *)            | Maximum velocity (scaled according to the velocity factor) |

\*) Dependent on the factory configuration of the motion controller

#### Profile Acceleration (0x6083)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|----------------------|------------|--------|---------------|--|
| 0x6083 | 0         | profile acceleration | Unsigned32 | rw     | 30 000        | Maximum acceleration (scaled according to the acceleration factor) |

#### Profile Deceleration (0x6084)

| Index  | Sub-index | Name                 | Type       | Attrb. | Default value | Meaning   |
|--------|-----------|----------------------|------------|--------|---------------|---|
| 0x6084 | 0         | profile deceleration | Unsigned32 | rw     | 30 000        | Maximum delay (scaled according to the acceleration factor) |

#### Quick Stop Deceleration (0x6085)

| Index  | Sub-index | Name                    | Type       | Attrb. | Default value | Meaning   |
|--------|-----------|-------------------------|------------|--------|---------------|---|
| 0x6085 | 0         | quick stop deceleration | Unsigned32 | rw     | 30 000        | Quick stop braking ramp value (scaled according to the acceleration factor) |

#### Motion Profile Type (0x6086)

| Index  | Sub-index | Name                | Type      | Attrb. | Default value | Meaning                                  |
|--------|-----------|---------------------|-----------|--------|---------------|--|
| 0x6086 | 0         | motion profile type | Integer16 | ro     | 0             | Type of motion profile<br>0: Linear Ramp |

#### Position Encoder Resolution (0x608F)

| Index  | Sub-index | Name               | Type       | Attrb. | Default value | Meaning   |
|--------|-----------|--------------------|------------|--------|---------------|---|
| 0x608F | 0         | number of entries  | Unsigned8  | ro     | 2             | Number of entries   |
|        | 1         | encoder increments | Unsigned32 | rw     | 2048          | Resolution of the external encoder for 4 edge evaluation              |
|        | 2         | motor revolution   | Unsigned32 | rw     | 1             | Number of motor revolutions with the pulse number named in subindex 1 |

## 8 Parameter description

### 8.3 Drive profile objects according to CiA 402

#### Position Factor (0x6093)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                                      |
|--------|-----------|-------------------|------------|--------|---------------|--|
| 0x6093 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                     |
|        | 1         | numerator         | Unsigned32 | rw     | 1             | Numerator of the position factor             |
|        | 2         | feed_constant     | Unsigned32 | rw     | 1             | Denominator (divisor) of the position factor |

$$\text{Factor} = \frac{\text{Numerator}}{\text{Denominator (divisor)}}$$

#### Velocity Factor (0x6096)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                                   |
|--------|-----------|-------------------|------------|--------|---------------|---|
| 0x6096 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                  |
|        | 1         | numerator         | Unsigned32 | rw     | 1             | Numerator of the speed factor             |
|        | 2         | divisor           | Unsigned32 | rw     | 1             | Denominator (divisor) of the speed factor |

#### Acceleration Factor (0x6097)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|-------------------|------------|--------|---------------|--|
| 0x6097 | 0         | number of entries | Unsigned8  | ro     | 2             | Number of object entries                         |
|        | 1         | numerator         | Unsigned32 | rw     | 1             | Numerator of the acceleration factor             |
|        | 2         | divisor           | Unsigned32 | rw     | 1             | Denominator (Divisor) of the acceleration factor |

#### Homing Method (0x6098)

| Index  | Sub-index | Name          | Type     | Attrb. | Default value | Meaning                            |
|--------|-----------|---------------|----------|--------|---------------|------------------------------------|
| 0x6098 | 0         | homing method | Integer8 | rw     | 0             | Homing method according to CiA 402 |

#### Homing Speed (0x6099)

| Index  | Sub-index | Name                           | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|--------------------------------|------------|--------|---------------|--|
| 0x6099 | 0         | number of entries              | Unsigned8  | ro     | 2             | Number of object entries   |
|        | 1         | speed during search for switch | Unsigned32 | rw     | 400           | Speed during switch search (scaled according to the velocity factor)   |
|        | 2         | speed during search for home   | Unsigned32 | rw     | 100           | Speed during search for zero (scaled according to the velocity factor) |

#### Homing Acceleration (0x609A)

| Index  | Sub-index | Name                | Type       | Attrb. | Default value | Meaning  |
|--------|-----------|---------------------|------------|--------|---------------|--|
| 0x609A | 0         | homing acceleration | Unsigned32 | rw     | 50            | acceleration during homing (scaled according to the acceleration factor) |

## 8 Parameter description

### 8.3 Drive profile objects according to CiA 402

#### Velocity Control Parameter Set (0x60F9)

| Index  | Sub-index | Name                      | Type       | Attrb. | Default value | Meaning                    |
|--------|-----------|---------------------------|------------|--------|---------------|----------------------------|
| 0x60F9 | 0         | number of entries         | Unsigned8  | ro     | 2             | Number of object entries   |
|        | 1         | gain                      | Unsigned16 | rw     | *)            | Velocity controller P term |
|        | 2         | integration time constant | Unsigned16 | rw     | *)            | Velocity controller I term |

\*) Dependent on the factory configuration of the motion controller

#### Control Effort (0x60FA)

| Index  | Sub-index | Name           | Type       | Attrb. | Default value | Meaning           |
|--------|-----------|----------------|------------|--------|---------------|-------------------|
| 0x60FA | 0         | Control Effort | Unsigned32 | ro     |               | Controller output |

#### Position Control Parameter Set (0x60FB)

| Index  | Sub-index | Name              | Type       | Attrb. | Default value | Meaning                    |
|--------|-----------|-------------------|------------|--------|---------------|----------------------------|
| 0x60FB | 0         | Number of entries | Unsigned8  | ro     | 2             | Number of entries          |
|        | 1         | gain              | Unsigned16 | rw     | *)            | Position controller P term |
|        | 2         | D constant        | Unsigned16 | rw     | *)            | Position controller D term |

\*) Dependent on the factory configuration of the motion controller

#### Position Demand Value (0x60FC)

| Index  | Sub-index | Name                  | Type      | Attrb. | Default value | Meaning                           |
|--------|-----------|-----------------------|-----------|--------|---------------|-----------------------------------|
| 0x60FC | 0         | position demand value | Integer32 | ro     | 0             | Last target position (increments) |

#### Target Velocity (0x60FF)

| Index  | Sub-index | Name            | Type      | Attrb. | Default value | Meaning         |
|--------|-----------|-----------------|-----------|--------|---------------|-----------------|
| 0x60FF | 0         | target velocity | Integer32 | rw     | 0             | Target velocity |

The target velocity is specified in the units defined by the user and is converted in the internal display (1/min) using the velocity factor.

#### Drive Data (0x6510)

| Index  | Sub-index | Name                | Type       | Attrb. | Default value | Meaning                                       |
|--------|-----------|---------------------|------------|--------|---------------|---|
| 0x6510 | 0         | number of entries   | Unsigned8  | ro     | 3             | Number of object entries                      |
|        | 1         | motor type          | Integer32  | rw     | *)            | Set motor type<br>0 BL motor<br>-1 DC motor   |
|        | 2         | speed constant KN   | Unsigned16 | rw     | *)            | Speed constant Kn of the motor<br>Unit: rpm/V |
|        | 3         | motor resistance RM | Unsigned32 | rw     | *)            | Motor resistance RM<br>Unit: mΩ               |

\*) Dependent on the factory configuration of the motion controller

## 8 Parameter description

### 8.4 FAULHABER commands

The FAULHABER commands can be used to configure and control the drive in a very easy way. All the supported ASCII commands of the serial version are available as a CAN message frame on PDO2, the first byte always contains the HEX value of the command, the following 4 bytes can then contain data:

#### RxPDO2: FAULHABER command

| 11 bit identifier      | 5 bytes user data |     |     |     |     |
|------------------------|-------------------|-----|-----|-----|-----|
| 0x300 (768d) + Node-ID | Cmd               | LLB | LHB | HLB | HHB |

The device must be in NMT "Operational" state for configuration of the drive using the FAULHABER channel.

Part of the parameter can also be set using the object dictionary, but others can only be set using the FAULHABER channel.

Several parameters can only be set and used in FAULHABER operating mode Modes of operation = -1 (Object 0x6060 or OPMOD command), as they have a direct effect on the drive behaviour.

The response behaviour of the FAULHABER commands depends on the setting of the transmission type of TxPDO2 (OD-Index 0x1801):

a.) transmission type = 0-240

The commands are not acknowledged until a SYNC object is received on TxPDO2 (see [Chapter 4.5 "SYNC object"](#)).

b.) transmission type = 252

The response to a command is not made available until a SYNC object is received and can then be requested with a request (RTR) on TxPDO2.

c.) transmission type = 253 (default)

After sending the command on RxPDO2, a request (RTR) must be performed on TxPDO2, in order to obtain the response to query commands or to check the success of send commands.

d.) transmission type = 255

The commands are immediately acknowledged on TxPDO2.

#### TxPDO2: FAULHABER data

| 11 bit identifier      | 5 bytes user data |     |     |     |     |       |
|------------------------|-------------------|-----|-----|-----|-----|-------|
| 0x280 (640d) + Node-ID | Cmd               | LLB | LHB | HLB | HHB | Error |



## 8 Parameter description

### 8.4 FAULHABER commands

6 bytes must always be returned, whereby the first byte gives the command and the following 4 bytes the required value as a long integer (for pure send commands 0) followed by an error code:

| Error | Explanation                      |
|-------|----------------------------------|
| 1     | Command successfully executed    |
| -2    | EEPROM writing done              |
| -4    | Overtemperature – drive disabled |
| -5    | Invalid parameter                |
| -7    | Unknown command                  |
| -8    | Command not available            |
| -13   | Flash defect                     |

Example:

Query of the actual position of node 3 ("POS" command):

Transmit ID 303: 40 00 00 00 00

Request ID 283

Receive ID 283: 40 A0 86 01 00 01

→ Actual position = 100000D

#### 8.4.1 Basic setting commands

The commands listed here are used to configure basic setting parameters, which are stored in the flash data memory via the SAVE command, and from there are reloaded again after switching on.

#### Commands for special FAULHABER operating modes

Only available in FAULHABER mode (Modes of operation = OPMOD = -1)

| Command   | Hex value | Data | Function                     | Description  |
|-----------|-----------|------|------------------------------|--|
| OPMOD     | 0xFD      | 0    | Operation Mode               | CANopen operating mode:<br>-1: FAULHABER mode<br>1: Profile Position Mode<br>3: Profile Velocity Mode<br>6: Homing Mode<br>Corresponds to object 0x6060 (modes of operation)   |
| SOR       | 0x8E      | 0-4  | Source For Velocity          | Source for target velocity:<br>0: CAN interface (default)<br>1: Voltage at analog input<br>2: PWM signal at analog input<br>3: Current limit value via analog input<br>4: current limiting value via analog input with evaluation of the sign for presetting the direction of rotation |
| CONTMOD   | 0x06      | 0    | Continuous Mode              | Switch back to normal mode from an enhanced mode   |
| STEPMOD   | 0x46      | 0    | Stepper motor mode           | Change to stepper motor mode   |
| APCMOD    | 0x02      | 0    | Analog Position Control Mode | Change to position control via analog voltage  |
| ENCMOD    | 0x10      | 0    | Encoder Mode                 | Change to encoder mode (not for MCDC) An external encoder serves as position detector (the current position value is set to 0)   |
| HALLSPEED | 0x3B      | 0    | Hall sensor as speed sensor  | Speed via Hall sensors in encoder mode (not for MCDC)  |
| ENCSPPEED | 0x12      | 0    | Encoder as speed sensor      | Speed via encoder signals in encoder mode (not for MCDC)   |
| GEARMOD   | 0x1D      | 0    | Gearing Mode                 | Change to gearing mode   |
| VOLTMOD   | 0x49      | 0    | Set Voltage Mode             | Activate Voltage Regulator Mode  |
| IXRMOD    | 0x50      | 0    | Set IxR Mode                 | Activate IxR control (MCDC only)   |

## 8 Parameter description

### 8.4 FAULHABER commands

#### Parameters for basic settings

| Command | Hex value | Data  | Function                | Description   |
|---------|-----------|-------|-------------------------|---|
| ENCRS   | 0x70      | Value | Load Encoder Resolution | Load resolution of external encoder (4 times pulse/rev).<br><b>Value: 8 to 65 535</b><br>Corresponds to object 0x608F                                       |
| KN      | 0x9E      | Value | Load Speed Constant     | Load speed constant $K_n$ in accordance with information in the data sheet. Unit: rpm/V.<br><b>Value: 0...16 383</b><br>Corresponds to object 0x6510        |
| RM      | 0x9F      | Value | Load Motor Resistance   | Load motor resistance RM according to specification in data sheet. Unit: m $\Omega$ .<br><b>Value: 10...320 000</b><br>Corresponds to object 0x6510         |
| STW     | 0x77      | Value | Load Step Width         | Load step width for step motor and gearing mode<br><b>Value: 1...65 535</b>   |
| STN     | 0x64      | Value | Load Step Number        | Load number of steps per revolution for step motor and gearing mode<br><b>Value: 1...65 535</b>   |
| MV      | 0x85      | Value | Minimum Velocity        | Specification of minimum velocity in rpm for target velocity via analog voltage (SOR1, SOR2)<br><b>Value: 0...30 000</b>                                    |
| MAV     | 0x83      | Value | Minimum Analog Voltage  | Presetting of minimum start voltage in mV for presetting speed via analog voltage (SOR1, SOR2)<br><b>Value: 0...10 000</b>                                  |
| ADL     | 0x00      | 0     | Analog Direction Left   | Positive voltages at the analog input result in anticlockwise rotation of the rotor (SOR1, SOR2)  |
| ADR     | 0x01      | 0     | Analog Direction Right  | Positive voltages at the analog input result in clockwise rotation of the rotor (SOR1, SOR2)  |
| SIN     | 0xA0      | 0 – 1 | Sinus commutation       | 1: No block commutation within the upper velocity range (default)<br>0: Block commutation within the upper velocity range (full modulation) (not with MCDC) |
| POLNUM  | 0xDC      | 2, 4  | Pole Number             | Number of magnetic poles of the connected motor (not for MCDC)<br>2: Two pole motor<br>4: Four pole motor (e.g. BX4)  |
| SENSTYP | 0xDE      | 4     | Load Sensor Type        | Setting of the connected AES encoder (only for MCBL AES)<br>4: AES-4 096<br>Further types available on request  |

## 8 Parameter description

### 8.4 FAULHABER commands

#### General parameters

| Command  | Hex value | Data  | Function                            | Description   |
|----------|-----------|-------|-------------------------------------|---|
| LL       | 0xB5v     | Value | Load Position Range Limits          | Load limit positions (the drive cannot be moved out of these limits). Positive values specify the upper limit and negative values the lower. The range limits are only active if APL1 is.<br><b>Value: <math>-1.8 \cdot 10^9 \dots +1.8 \cdot 10^9</math></b><br>Corresponds to object 0x607D |
| APL      | 0x03      | 0-1   | Activate/Deactivate Position Limits | Activate range limits (LL) (valid for all operating modes in FAULHABER Mode except VOLTMOD).<br>1: Position limits activated<br>0: Position limits deactivated  |
| SP       | 0x8F      | Value | Load Maximum Speed                  | Load maximum speed (rpm). Setting applies to all modes.<br><b>Value: 0...30 000</b><br>Corresponds to object 0x607F or 0x6081   |
| AC       | 0x65      | Value | Load Command Acceleration           | Load acceleration value ( $1/s^2$ ).<br><b>Value: 0...30 000</b><br>Corresponds to object 0x6083  |
| DEC      | 0x6D      | Value | Load Command Deceleration           | Load deceleration value ( $1/s^2$ ).<br><b>Value: 0 to 30 000</b><br>Corresponds to object 0x6084 or 0x6081   |
| SR       | 0xA4      | Value | Load Sampling Rate                  | Load sampling rate of the velocity controller as a multiple of the basic controller sampling rate according to the data sheet.<br><b>Value: 1...20</b>  |
| POR      | 0x89      | Value | Load Velocity Proportional Term     | Load velocity controller amplification.<br><b>Values: 1...255</b><br>Corresponds to object 0x60F9   |
| I        | 0x7B      | Value | Load Velocity Integral Term         | Load velocity controller integral term.<br><b>Value: 1...255</b><br>Corresponds to object 0x60F9  |
| PP       | 0x9B      | Value | Load Position Proportional Term     | Load position controller amplification.<br><b>Value: 1...255</b><br>Corresponds to object 0x60FB  |
| PD       | 0x9C      | Value | Load Position Differential Term     | Load position controller D-term.<br><b>Value: 1...255</b><br>Corresponds to object 0x60FB   |
| CI       | 0xA2      | Value | Load Current Integral Term          | Load integral term for current controller.<br><b>Value: 1...255</b>   |
| LPC      | 0x81      | Value | Load Peak Current Limit             | Load peak current (mA).<br><b>Value: 0...12 000</b>   |
| LCC      | 0x80      | Value | Load Continuous Current Limit       | Load continuous current (mA).<br><b>Value: 0...12 000</b>   |
| DEV      | 0x6F      | Value | Load Deviation                      | Load maximum permissible deviation of actual velocity from target velocity (deviation)<br><b>Value: 0...30 000</b>  |
| CORRIDOR | 0x9D      | Value | Load Corridor                       | Window around the target position.<br><b>Value: 1...32 767</b><br>Corresponds to object 0x6067  |

## 8 Parameter description

### 8.4 FAULHABER commands


#### Configuration of fault pin and digital inputs

| Command | Hex value | Data  | Function              | Description  |
|---------|-----------|-------|-----------------------|--|
| ERROUT  | 0x14      | 0     | Error Output          | Fault pin as error output.   |
| ENCOUT  | 0x11      | 0     | Encoder Output        | Fault pin as pulse output (not for MCDC).  |
| DIGOUT  | 0x0A      | 0     | Digital Output        | Fault pin as digital output. The output is set to low level.                                 |
| POSOUT  | 0x4C      | 0     | Position Output       | Fault pin as digital output for display of the condition: "target position reached".         |
| DIRIN   | 0x0C      | 0     | Direction Input       | Fault pin as rotational direction input.   |
| REFIN   | 0x41      | 0     | Reference Input       | Fault pin as reference or limit switch input.  |
| DCE     | 0x6B      | Value | Delayed Current Error | Delayed error output for ERROUT in 1/100 sec.<br><b>Value: 0...65 535</b>                    |
| LPN     | 0x82      | Value | Load Pulse Number     | Preset pulse number for ENCOUT.<br><b>Value: 1...255</b><br><b>Value: 1...32 in MCBL AES</b> |
| CO      | 0x05      | 0     | Clear Output          | Set digital output DIGOUT to low level.  |
| SO      | 0x45      | 0     | Set Output            | Set digital output DIGOUT to high level.   |
| TO      | 0x55      | 0     | Toggle Output         | Toggle to digital output DIGOUT.   |
| SETPLC  | 0x51      | 0     | Set PLC inputs        | Digital inputs PLC-compatible (24 V level).  |
| SETTTL  | 0x52      | 0     | Set TTL inputs        | Digital inputs TTL-compatible (5 V level).   |

#### Configuring homing and limit switches in FAULHABER mode

| Command | Hex value | Data  | Function                            | Description   |
|---------|-----------|-------|-------------------------------------|---|
| HP      | 0x79      | 0     | Hard Polarity                       | Define valid edge and polarity of respective limit switches:<br>1: Rising edge and high level valid.<br>0: Falling edge and low level valid.                  |
| HB      | 0x73      | 0     | Hard Blocking                       | Activate Hard Blocking function for relevant limit switch.  |
| HD      | 0x74      | 0     | Hard Direction                      | Presetting of direction of rotation that is blocked with HB of respective limit switch.<br>1: Clockwise rotation blocked<br>0: Anticlockwise rotation blocked |
| SHA     | 0x8A      | 0     | Set Home Arming for Homing Sequence | Homing behaviour (GOHOSEQ): Set position value to 0 at edge of respective limit switch.   |
| SHL     | 0x90      | 0     | Set Hard Limit for Homing Sequence  | Homing behaviour (GOHOSEQ): Stop motor at edge of respective limit switch.  |
| SHN     | 0x9A      | Value | Set Hard Notify for Homing Sequence | Homing behaviour (GOHOSEQ): Transmit message to Master for edge at respective limit switch (statusword Bit 14=1).   |
| HOSP    | 0x78      | Value | Load Homing Speed                   | Load speed and direction of rotation for homing (GOHOSEQ, GOHIX, FHIX).<br><b>Value: -32 767 to 32 767 rpm</b>  |
| HA      | 0x72      | 0     | Home Arming                         | Set position value to 0 and delete relevant HA bit at edge of respective limit switch. Setting is not saved.  |
| HL      | 0x75      | 0     | Hard Limit                          | Stop motor and delete relevant HL bit at edge of respective limit switch. Setting is not saved.   |
| HN      | 0x76      | 0     | Hard Notify                         | Transmit message to respective Master for edge at respective limit switch (Statusword Bit 14=1) and delete corresponding HN bit. Setting is not saved.        |

Bit mask of the limit switches:



## 8 Parameter description

### 8.4 FAULHABER commands

#### 8.4.2 Query commands for basic settings

##### Operating modes and general parameters

| Command | Hex value | Data | Function             | Description  |
|---------|-----------|------|----------------------|--|
| GOPMOD  | 0xFE      | 0    | Get Operation Mode   | Display current CANopen operating mode:<br>-1: FAULHABER mode<br>1: Profile Position Mode<br>3: Profile Velocity Mode<br>6 : Homing Mode<br>Corresponds to object 0x6061 (modes of operation display)  |
| CST     | 0x58      | 0    | Configuration Status | Set operating mode.<br>Return value binary coded (LSB=Bit 0):<br>Bit 0-2, reserved<br>Bit 3-4, Source for target velocity:<br>0: SOR0 (CAN interface)<br>1: SOR1 (Analog voltage)<br>2: SOR2 (PWM signal)<br>3: SOR3 (current limitation value)<br>Bit 5-6, reserved<br>Bit 7-9, FAULHABER mode:<br>0: CONTMOD<br>1: STEPMOD<br>2: APCMOD<br>3: ENCMOD/HALLSPEED<br>4: ENCMOD/ENCSPPEED<br>5: GEARMOD<br>6: VOLTMOD<br>7: IXRMOD<br>Bit 10, power amplifier:<br>0: Disabled (DI)<br>1: Enabled (EN)<br>Bit 11, position controller:<br>0: Switched off<br>1: Switched on<br>Bit 12, analog direction of rotation:<br>0: ADL<br>1: ADR<br>Bit 13, Position Limits APL:<br>0: deactivated<br>1: activated<br>Bit 14, sinus commutation SIN:<br>0: Allow block commutation<br>1: Do not allow block commutation |

## 8 Parameter description

### 8.4 FAULHABER commands

| Command   | Hex value | Data | Function                   | Description  |
|-----------|-----------|------|----------------------------|--|
| GMOD      | 0x28      | 0    | Get Mode                   | Set FAULHABER mode:<br>0: CONTMOD<br>1: STEPMOD<br>2: APCMOD<br>3: ENCMOD / HALLSPEED<br>4: ENCMOD / ENCSPEED<br>5: GEARMOD<br>6: VOLTMOD<br>7: IXRMOD |
| GENCRES   | 0x1E      | 0    | Get Encoder Resolution     | Set encode resolution (ENCRES)<br>Corresponds to object 0x608F   |
| GMOTTYP   | 0x29      | 0    | Get Motor Type             | Set motor type<br>0: BL motor<br>-1: DC Motor  |
| GKN       | 0x4D      | 0    | Get Speed Constant         | Speed constant in rpm/V (KN)<br>Corresponds to object 0x6510   |
| GRM       | 0x4E      | 0    | Get Motor Resistance       | Motor resistance in mΩ (RM)<br>Corresponds to object 0x6510  |
| GSTW      | 0x39      | 0    | Get Step Width             | Set step width (STW)   |
| GSTN      | 0x38      | 0    | Get Step Number            | Set number of steps per revolution (STN)   |
| GMV       | 0x2A      | 0    | Get Minimum Velocity       | Set minimum velocity in rpm (MV)   |
| GMAV      | 0x27      | 0    | Get minimum analog voltage | Set minimum start voltage value in mV (MAV)  |
| GPL       | 0x31      | 0    | Get Positive Limit         | Set positive limit position (LL)<br>Corresponds to object 0x607D   |
| GNL       | 0x2C      | 0    | Get Negative Limit         | Set negative limit position (LL)<br>Corresponds to object 0x607D   |
| GSP       | 0x36      | 0    | Get Maximum Speed          | Set maximum speed in rpm (SP)<br>Corresponds to object 0x607F ory 0x6081   |
| GAC       | 0x15      | 0    | Get Acceleration           | Set acceleration value in 1/s <sup>2</sup> (AC)<br>Corresponds to object 0x6083  |
| GDEC      | 0x1B      | 0    | Get Deceleration           | Set deceleration value in 1/s <sup>2</sup> (DEC)<br>Corresponds to object 0x6084   |
| GSR       | 0x56      | 0    | Get Sampling Rate          | Set sampling rate of the speed controller ms/10 (SR)   |
| GPOR      | 0x33      | 0    | Get Velocity Prop. Term    | Set amplification value of the speed controller (POR)<br>Corresponds to object 0x60F9  |
| GI        | 0x26      | 0    | Get Velocity Integral Term | Set integral term of the speed controller (I)<br>Corresponds to object 0x60F9  |
| GPP       | 0x5D      | 0    | Get Position Prop. Term    | Set amplification value of the position controller (PP)<br>Corresponds to object 0x60FB  |
| GPD       | 0x5E      | 0    | Get Position D-Term        | Set D-term of the position controller (PD)<br>Corresponds to object 0x60FB   |
| GCI       | 0x63      | 0    | Get Current Integral Term  | Set integral term of the current controller (CI)   |
| GPC       | 0x30      | 0    | Get Peak Current           | Set peak current in mA (LPC)   |
| GCC       | 0x18      | 0    | Get Continuous Current     | Set continuous current in mA (LCC)   |
| GDEV      | 0x1C      | 0    | Get Deviation              | Set deviation value (DEV)  |
| GCORRIDOR | 0x62      | 0    | Get Corridor               | Set window around the target position (CORRIDOR)<br>Corresponds to object 0x6067.  |
| GPOLNUM   | 0xDB      | 0    | Get Pole Number            | Number of magnetic poles of the connected motor<br>(not for MCDC)  |
| GSENSTYP  | 0xDD      | 0    | Get Sensor Type            | Setting of the connected AES encoder.<br>(only for MCBL AES)   |

## 8 Parameter description

### 8.4 FAULHABER commands

#### Configuration of fault pin and digital inputs

| Command | Hex value | Data | Function                  | Description  |
|---------|-----------|------|---------------------------|--|
| IOC     | 0x5C      | 0    | I/O Configuration         | Set input/output configuration.<br>Return value binary coded (LSB=Bit 0):<br>Bit 0-7, FAULHABER Hard Blocking:<br>0-31: Function active for input 1-5<br>Bit 8-15, FAULHABER Hard Polarity:<br>0-31: Rising edge at input 1-5<br>Bit 16-23, FAULHABER Hard Direction:<br>0-31: Clockwise movement blocked at input 1-5<br>Bit 24, state of digital output:<br>0: Low<br>1: High<br>Bit 25, Level of digital inputs:<br>0: TTL level (5 V)<br>1: PLC LEVEL (24 V)<br>Bit 26-28, function of fault pin:<br>0: ERROUT<br>1: ENCOUNT<br>2: DIGOUT<br>3: DIRIN<br>4: REFIN<br>5: POSOUT |
| GDCE    | 0x1A      | 0    | Get Delayed Current Error | Set value of the error output delay (DCE)  |
| GPN     | 0x32      | 0    | Get Pulse Number          | Set pulse number (LPN)   |

#### Configuration of the homing in FAULHABER mode

| Command | Hex value | Data | Function             | Description   |
|---------|-----------|------|----------------------|---|
| HOC     | 0x5B      | 0    | Homing Configuration | Set homing configuration.<br>Return value binary coded (LSB = Bit 0):<br>Bit 0-7, SHA setting for input 1-8<br>Bit 8-15, SHN setting for input 1-8<br>Bit 16-23, SHL setting for input 1-8<br>(Input 6-8: Reserved) |
| GHOSP   | 0x24      | 0    | Get Homing Speed     | Set homing speed in rpm (HOSP).   |

#### 8.4.3 Miscellaneous commands

| Command        | Hex value    | Data | Function              | Description  |
|----------------|--------------|------|-----------------------|--|
| SAVE<br>EEPSAV | 0x53<br>0x0D | 0    | Save Parameters       | Save current parameters and configuration setting to Flash memory. The drive will also start with these settings when next switched on.<br>Corresponds to object 0x1010.<br><b>Important:</b> Command may not be executed more than 10 000 times, as otherwise the function of the Flash memory can no longer be guaranteed.                                   |
| RESET          | 0x59         | 0    | Reset                 | Restart drive node.<br>Corresponds to NMT reset node.  |
| RN             | 0x44         | 0    | Reset Node            | Set application parameters to original values (ROM values) (current, acceleration, controller parameters, maximum speed, limit positions...); communication parameters, operating mode and hardware configuration are retained.  |
| FCONFIG        | 0xD0         | 0    | Factory Configuration | All configurations and values are reset to the delivery status.<br>After this command the drive performs a reset.<br><b>Attention:</b> Customer-specific factory settings are also lost. The Node-ID is set to 255 (unconfigured), therefore LSS configuration is necessary to establish a new connection! The command can be executed a maximum 10 000 times. |

## 8 Parameter description

### 8.4 FAULHABER commands

#### 8.4.4 Motion control commands

The commands listed here are only available in FAULHABER Mode (Modes of operation = -1).

| Command | Hex value | Data    | Function               | Description   |
|---------|-----------|---------|------------------------|---|
| DI      | 0x08      | 0       | Disable Drive          | Deactivate drive.   |
| EN      | 0x0F      | 0       | Enable Drive           | Activate drive.   |
| M       | 0x3C      | 0       | Initiate Motion        | Activate position control and start positioning.  |
| LA      | 0xB4      | Value   | Load Absolute Position | Load new absolute target position.<br><b>Value: <math>-1.8 \cdot 10^9 \dots 1.8 \cdot 10^9</math></b>   |
| LR      | 0xB6      | Value   | Load Relative Position | Load new relative target position, in relation to last started target position. The resulting absolute target position must lie between $-2.14 \cdot 10^9$ and $2.14 \cdot 10^9$ .  |
| V       | 0x93      | Value   | Select Velocity Mode   | Activate velocity mode and set specified value as target velocity (velocity control).<br><b>Value: <math>-30\,000 \dots 30\,000</math> rpm</b>  |
| U       | 0x92      | Value   | Set Output Voltage     | Output PWM value in VOLTMOD.<br><b>Value: <math>-32\,767 \dots 32\,767</math> (corresponds to <math>-U_v \dots +U_v</math>)</b>   |
| GOHOSEQ | 0x2F      | 0       | Go Homing Sequence     | Execute FAULHABER homing sequence.<br>A homing sequence is executed (if programmed) irrespective of the current mode.   |
| FHIX    | 0x35      | 0       | Find Hall Index        | Move BL 4 pole motor to Hall zero point (Hall index) and set actual position value to 0. In 4 pole motors, within a revolution, two Hall zero points exist opposite each other. The motor moves to the nearest index.<br>(only for BL 4 pole) |
| GOHIX   | 0x2E      | 0       | Go Hall Index          | Move BL motor to Hall zero point (Hall index) and set actual position value to 0 (only for BL 2 pole).  |
| GOIX    | 0xA3      | 0       | Go Encoder Index       | Move to the encoder index at the Fault pin and set actual position value to 0 (DC motor or ext. encoder).   |
| HO      | 0xB8      | 0/value | Define Home Position   | Data = 0: Set actual position to 0.<br>Otherwise: Set actual position to specified value.<br><b>Value: <math>-1.8 \cdot 10^9 \dots 1.8 \cdot 10^9</math></b>  |



## 8 Parameter description

### 8.4 FAULHABER commands

#### 8.4.5 General query commands

| Command | Hex value | Data  | Function             | Description  |
|---------|-----------|-------|----------------------|--|
| POS     | 0x40      | 0     | Get Actual Position  | Current actual position.<br>Corresponds to object 0x6063.  |
| TPOS    | 0x4B      | 0     | Get Target Position  | Target position of the positioning last started.<br>Corresponds to object 0x60FC.  |
| GV      | 0x3A      | 0     | Get Target Velocity  | Current target velocity in rpm.<br>Corresponds to object 0x606B.   |
| GN      | 0x2B      | 0     | Get Actual Velocity  | Current actual speed in rpm.<br>Corresponds to object 0x6069.  |
| GU      | 0x5F      | 0     | Get PWM Voltage      | Set PWM value in VOLTMOD.  |
| GRU     | 0x60      | 0     | Get Real PWM Voltage | Current controller output value.   |
| GCL     | 0x19      | 0     | Get Current Limit    | Current limitation current in mA.  |
| GRC     | 0x34      | 0     | Get Real Current     | Current actual current in mA.  |
| TEM     | 0x47      | 0     | Get Temperature      | Current housing temperature in °C.   |
| GADV    | 0xB2      | Value | Get Analog Voltage   | Read out the voltage applied at the given input (value).<br>Scaling: 1 000 digits = 1 V<br>1: Voltage at AnIn<br>3: Voltage at 3rd In<br>4: Voltage at 4th In (MCDC only)<br>5: Voltage at 5th In (MCDC only)<br>Return value input 1: -10 000 ... 10 000<br>Return value input 3, 4, 5: 0 ... 10 000<br><b>Value: 1, 3, 4, 5 (4 and 5 for MCDC only)</b>  |
| OST     | 0x57      | 0     | Operation Status     | Display current operating status.<br>Return value binary coded (LSB=Bit 0):<br>Bit 0: Homing running<br>Bit 1-3: Reserved<br>Bit 4: Current limitation active<br>Bit 5: Deviation error<br>Bit 6: Overvoltage<br>Bit 7: Overtemperature<br>Bit 8: Status input 1<br>Bit 9: Status input 2<br>Bit 10: Status input 3<br>Bit 11: Status input 4<br>Bit 12: Status input 5<br>Bit 13-15: Reserved for other inputs<br>Bit 16: Position attained |
| SWS     | 0x5A      | 0     | Switch Status        | Temporary limit switch settings.<br>Return value binary coded (LSB=Bit 0):<br>Bit 0-7: HA setting for input 1-8<br>Bit 8-15: HN setting for input 1-8<br>Bit 16-23: HL setting for input 1-8<br>Bit 24-31: Specifies which limit switch 1-8 has already switched (is reset again when the respective input is reset)   |

## 8 Parameter description

### 8.4 FAULHABER commands

#### 8.4.6 Command overview

| Command      | Command code | Function                            | CANopen object |
|--------------|--------------|-------------------------------------|----------------|
| AC           | 0x65         | Load Command Acceleration           | 0x6083         |
| ADL          | 0x00         | Analog Direction Left               |                |
| ADR          | 0x01         | Analog Direction Right              |                |
| APCMOD       | 0x02         | Analog Position Control Mode        |                |
| APL          | 0x03         | Activate/Deactivate Position Limits |                |
| CI           | 0xA2         | Load Current Integral Term          |                |
| CO           | 0x05         | Clear Output                        |                |
| CONTMOD      | 0x06         | Continuous Mode                     |                |
| CORRIDOR     | 0x9D         | Load Corridor                       | 0x6067         |
| CST          | 0x58         | Configuration Status                |                |
| DCE          | 0x6B         | Delayed Current Error               |                |
| DEC          | 0x6D         | Load Command Deceleration           | 0x6084         |
| DEV          | 0x6F         | Load Deviation                      |                |
| DI           | 0x08         | Disable Drive                       |                |
| DIGOUT       | 0x0A         | Digital Output                      |                |
| DIRIN        | 0x0C         | Direction Input                     |                |
| EN           | 0x0F         | Enable Drive                        |                |
| ENCMOD       | 0x10         | Encoder Mode                        |                |
| ENCOUT       | 0x11         | Encoder Output                      |                |
| ENCRES       | 0x70         | Load Encoder Resolution             | 0x608F         |
| ENCSPD       | 0x12         | Encoder as speed sensor             |                |
| ERROUT       | 0x14         | Error Output                        |                |
| FAULT STATUS | 0xDF         | Get Fault Pin Status                |                |
| FCONFIG      | 0xD0         | Factory Configuration               |                |
| FHIX         | 0x35         | Find Hall Index                     |                |
| GAC          | 0x15         | Get Acceleration                    | 0x6083         |
| GADC         | 0xB3         | Get ADC Value                       |                |
| GADV         | 0xB2         | Get Analog Voltage                  |                |
| GCC          | 0x18         | Get Continuous Current              |                |
| GCI          | 0x63         | Get Current Integral Term           |                |
| GCL          | 0x19         | Get Current Limit                   |                |
| GCORRIDOR    | 0x62         | Get Corridor                        | 0x6067         |
| GDCE         | 0x1A         | Get Delayed Current Error           |                |
| GDEC         | 0x1B         | Get Deceleration                    | 0x6084         |
| GDEV         | 0x1C         | Get Deviation                       |                |
| GEARMOD      | 0x1D         | Gearing Mode                        |                |
| GENCRES      | 0x1E         | Get Encoder Resolution              | 0x608F         |
| GHOSP        | 0x24         | Get Homing Speed                    |                |
| GI           | 0x26         | Get Velocity Integral Term          | 0x60F9         |
| GKN          | 0x4D         | Get Speed Constant                  | 0x6510         |
| GMAV         | 0x27         | Get minimum analog voltage          |                |
| GMOD         | 0x28         | Get Mode                            |                |
| GMOTYP       | 0x29         | Get Motor Type                      | 0x6510         |
| GMV          | 0x2A         | Get Minimum Velocity                |                |
| GN           | 0x2B         | Get Actual Velocity                 | 0x6069         |
| GNL          | 0x2C         | Get Negative Limit                  | 0x607D         |
| GOHIX        | 0x2E         | Go Hall Index                       |                |
| GOHSEQ       | 0x2F         | Go Homing Sequence                  |                |
| GOIX         | 0xA3         | Go Encoder Index                    |                |
| GOPMOD       | 0xFE         | Get Operation Mode                  | 0x6061         |
| GPC          | 0x30         | Get Peak Current                    |                |
| GPD          | 0x5E         | Get Position D-Term                 | 0x60FB         |
| GPL          | 0x31         | Get Positive Limit                  | 0x607D         |
| GPN          | 0x32         | Get Pulse Number                    |                |
| GPOLNUM      | 0xDB         | Get Pole Number                     |                |
| GPOR         | 0x33         | Get Velocity Prop. Term             | 0x60F9         |
| GPP          | 0x5D         | Get Position Prop. Term             | 0x60FB         |
| GRC          | 0x34         | Get Real Current                    |                |
| GRM          | 0x4E         | Get Motor Resistance                | 0x6510         |
| GRPC         | 0x61         | Get Real Current                    |                |
| GRU          | 0x60         | Get Real PWM Voltage                | 0x60FA         |
| GSENSTYP     | 0xDD         | Get Sensor Type (MCBL AES)          |                |
| GSP          | 0x36         | Get Maximum Speed                   | 0x6081         |
| GSR          | 0x56         | Get Sampling Rate                   |                |
| GSTN         | 0x38         | Get Step Number                     |                |
| GSTW         | 0x39         | Get Step Width                      |                |
| GU           | 0x5F         | Get PWM Voltage                     |                |
| GV           | 0x3A         | Get Target Velocity                 | 0x606B         |

## 8 Parameter description

### 8.4 FAULHABER commands

| Command   | Command code | Function                            | CANopen object |
|-----------|--------------|-------------------------------------|----------------|
| HA        | 0x72         | Home Arming                         |                |
| HALLSPEED | 0x3B         | Hall sensor as speed sensor         |                |
| HB        | 0x73         | Hard Blocking                       |                |
| HD        | 0x74         | Hard Direction                      |                |
| HL        | 0x75         | Hard Limit                          |                |
| HN        | 0x76         | Hard Notify                         |                |
| HO        | 0xB8         | Define Home Position                |                |
| HOC       | 0x5B         | Homing Configuration                |                |
| HOSP      | 0x78         | Load Homing Speed                   |                |
| HP        | 0x79         | Hard Polarity                       |                |
| I         | 0x7B         | Load Velocity Integral Term         | 0x60F9         |
| IOC       | 0x5C         | I/O Configuration                   |                |
| IXRMOD    | 0x50         | Set IxR Mode (MCDC)                 |                |
| KN        | 0x9E         | Load Motor Speed Constant           | 0x6510         |
| LA        | 0xB4         | Load Absolute Position              |                |
| LCC       | 0x80         | Load Continuous Current Term        |                |
| LL        | 0xB5         | Load Position Range Limits          | 0x607D         |
| LPC       | 0x81         | Load Peak Current Limit             |                |
| LPN       | 0x82         | Load Pulse Number                   |                |
| LR        | 0xB6         | Load Relative Position              |                |
| M         | 0x3C         | Initiate Motion                     |                |
| MAV       | 0x83         | Minimum Analog Voltage              |                |
| MV        | 0x85         | Minimum Velocity                    |                |
| OPMOD     | 0xFD         | Operation Mode                      | 0x6060         |
| OST       | 0x57         | Operation Status                    |                |
| PD        | 0x9C         | Load Position Differential Term     | 0x60FB         |
| POLNUM    | 0xDC         | Load Pole Number                    |                |
| POR       | 0x89         | Load Velocity Proportional Term     | 0x60F9         |
| POS       | 0x40         | Get Actual Position                 | 0x6063         |
| POSOUT    | 0x4C         | Position Output                     |                |
| PP        | 0x9B         | Load Position Proportional Term     | 0x60FB         |
| REFIN     | 0x41         | Reference Input                     |                |
| RESET     | 0x59         | Reset                               |                |
| RM        | 0x9F         | Load Motor Resistance               | 0x6510         |
| RN        | 0x44         | Reset Node                          |                |
| SAVE      | 0x53         | Save Parameters                     | 0x1010         |
| SENSTYP   | 0xDE         | Load Sensor Type (MCBL AES)         |                |
| SETPLC    | 0x51         | Set PLC inputs                      |                |
| SETTTL    | 0x52         | Set TTL inputs                      |                |
| SHA       | 0x8A         | Set Home Arming for Homing Sequence |                |
| SHL       | 0x90         | Set Hard Limit for Homing Sequence  |                |
| SHN       | 0x9A         | Set Hard Notify for Homing Sequence |                |
| SIN       | 0xA0         | Sinus commutation                   |                |
| SO        | 0x45         | Set Output                          |                |
| SOR       | 0x8E         | Source for Velocity                 |                |
| SP        | 0x8F         | Load Maximum Speed                  | 0x607F         |
| SR        | 0xA4         | Load Sampling Rate                  |                |
| STEPMOD   | 0x46         | Stepper Motor Mode                  |                |
| STN       | 0x64         | Load Step Number                    |                |
| STW       | 0x77         | Load Step Width                     |                |
| SWS       | 0x5A         | Switch Status                       |                |
| TEM       | 0x47         | Get Temperature                     |                |
| TO        | 0x55         | Toggle Output                       |                |
| TPOS      | 0x4B         | Get Target Position                 | 0x60FC         |
| U         | 0x92         | Set Output Voltage                  |                |
| V         | 0x93         | Select Velocity Mode                | 0x606B         |
| VER       | -            | Get Firmware Version                | 0x100A         |
| VOLTMOD   | 0x49         | Set Voltage Mode                    |                |

